



Remote Operating Interface Software (Caterpillar)

User Manual

Original Instruction



HIWIN INDUSTRIE 4.0 Best Partner





• KK, SK • KS, KA KU, KE, KC

Medical / FPD



Multi-Axis Robot

Pick-and-Place / Assembly / Array and Packaging / Semiconductor / Electro-Optical Industry / Automotive Industry / Food Industry

- Articulated Robot

- Integrated Electric Gripper

Torque Motor

Rotary Table

Medical / Automotive Industry / Machine Tools / Machinery Industry

RAB Series

- RAS Series
- RCV Series
- RCH Series

Linear Guideway

• Quiet Type--QH, QE, QW, QR

• Other--RG, E2, PG, SE, RC

Automation / Semiconductor / Medical Ball Type--HG, EG, WE, MG, CG



Ballscrew

- Precision Ground / Rolled Super S Series
- Super T Series
- Mini Roller
- Ecological & Economical
- Lubrication Module E2

 Rotating Nut (R1)
- Energy-Saving & Thermal-Controlling (Cool Type)
- Heavy Load Series (RD)
- Ball Spline

Bearing

- Machine Tools / Robot
- Crossed Roller Bearing Ballscrew Bearing
- Linear Bearing
- Support Unit



DATORKER®

Robot / Automation Equipment / Semiconductor Equipment / Machine Tools

- WTI-PH Type
- WTI-AH Type

.



- Drives--D1, D2T/D2T-LM, E1



Direct Drive Motor

Machine Tools

- Direct Drive Motor-
- DMS, DMY, DMN, DMT Series















Linear Motor Stage

Automated Transport / AOI Application / Precision / Semiconductor

- Iron-core Linear Motor
- Coreless Linear Motor Linear Turbo Motor LMT
- Planar Servo Motor
- Air Bearing Platform
- X-Y Stage
 Gantry Systems • Single-Axis Linear Motor Stage



Strain Wave Gear

• WUT-PO Type

- WUI-CO Type

Robotic Gait Training System Robotic Endoscope Holder

Medical Equipment Hospital / Rehabilitation Centers / Nursing Homes



Torque Motor-

TM-2/IM-2, TMRW Series

Inspection / Testing Equipment / Robot



目 錄

<u>0.</u>	Warranty Terms and Conditions	<u>. 12</u>
<u>1.</u>	Introduction	. 27
1.1	Remote Robot Control Software (Caterpillar) Overview	. 27
1.2	System connection architecture overview	. 27
1.3	Windows System Recommended Environment	. 28
1.3.1	Windows System Setting for Different Area	29
1.4	Software Version Compatibility Description	. 30
1.5	Download Controller's HRSS Version of Remote operation software	. 34
<u>2.</u>	Put Into Operation of Description	<u>. 35</u>
2.1	Check Robot Plate and Software Version Data	. 35
2.2	Calibration Flow	. 37
2.3	Adjust Origin Position of Hardware Mechanism	. 38
2.3.1	Four Axes Robot Mastering Method	39
<u>3.</u>	Interface Operation Setting	<u>. 45</u>
3.1	Remote Operation Interface of software	. 45
3.1.1	Remote Operation Setting	45
3.1.1.1	Connection Operator Step Description	46
3.1.1.2	Change local PC of IP	47
3.1.2	Language Setting	48
3.1.3	Export system reports	48
3.1.4	Status Bar Display Description	50
3.1.5	Connection Level and Change Operation Mode	51
3.1.5.1	Change password	53
3.1.5.2	Changing operation password	54
3.1.5.3	Restoring operation password	54
3.1.6	Tab display function description	55
3.1.6.1	Actual Position Display	55
3.1.6.2	Real-time update of the current position	56
3.1.6.3	Display Point Page	58
3.1.6.4	Display Counter Variable Page	59
3.1.6.5	Display Timer Variable Page	60
3.1.6.6	Display Alarm Page	61

3.1.6.7	Display LogBook and Zero Position History Message63			
3.1.7	Update Controller of HRSS Software Version64			
3.1.8	Saving and reading of database66			
3.1.9	About Robot information display window70			
3.2	Coordinate System 71			
3.3	JOG Robot			
3.3.1	Manual JOG73			
3.3.2	Robot Simulation interface			
3.3.3	Base/Tool Coordinate			
3.3.4	Jogging Velocity Ratio80			
3.4	Input/Output(I/O) Setting			
3.4.1	Display Digital Input/Output80			
3.4.2	Self-defined Digital Input/Output Function83			
3.4.2.1	Clear Error Input Signal			
3.4.2.2	External Alarm Input Signal			
3.4.2.3	External Shutdown Input Signal			
3.4.2.4	Motor Warning Output Signal			
3.4.2.5	System Start Up Output Signal			
3.4.2.6	Manual/Auto Mode Output Signal84			
3.4.2.7	Restart driver signal output			
3.4.2.8	Emergency stop signal output signal85			
3.4.2.9	Restart safety relay output signal85			
3.4.3	Display External Functional Input/Output85			
3.5	Communication Part			
3.5.1	TCP/IP Connection			
3.5.2	Set up Robot Controller Ip			
3.5.3	RS232 Connection91			
3.6	Start-up Function			
3.6.1	Six Axes Robot Calibrate Tool/Base Coordinate Way92			
3.6.1.1	Calibrate Tool Coordinate92			
3.6.1.2	Four-Point Calibrate Method of Tool Coordination			
3.6.1.3	Enter Value Way of Tool Coordination95			
3.6.1.4	Calibrate Base Coordination96			
3.6.1.5	Three-Point Calibrate Method of Base Coordination			
3.6.1.6	Enter Value Way of Base Coordination99			

3.6.2	Four Axes Robot Calibrate Tool/Base Coordinate Way	
3.6.2.1	Calibrate Tool Coordination	
3.6.2.2	Three-Point Calibrate Method of Tool Coordination	
3.6.2.1	Enter Value Way of Tool Coordination	
3.6.2.1	Calibrate Base Coordination	
3.6.2.2	Three-Point Calibrate Method of Base Coordination	105
3.6.2.1	Enter Value Way of Base Coordination	
3.6.3	Home and Position Check Configuration	
3.6.3.1	Home Configuration Setting	
3.6.3.2	Position Check Setting	
3.6.3.3	Home Position Power on Check	110
3.6.4	Time Setting of Controller	
3.6.5	Payload Setting	112
3.6.6	User Self-define Alarm	113
3.6.6.1	Define Alarm Text Content Setting	113
3.6.7	Electric gripper setting	113
3.6.8	Software limit function	116
3.6.9	External axis functions	
3.6.9.1	External axis parameter settings	118
3.6.9.2	Zero point calibration for the external axis	120
3.6.9.3	External axis positive and negative limit signal monitoring	120
3.6.9.4	Manual operation of external axis	121
3.7	Display Setting	123
3.7.1	Display System Status Input/Output	123
3.7.2	Module I/O Function	124
3.7.3	Position Register (PR) Setting	125
3.7.4	Display Utilization Rate	
3.7.5	Display Robot Data	129
<u>4.</u>	M otion Program Base Design Description	130
4.1	Motion Overview	130
4.2	Point-to-point (PTP) Motion	130
4.3	Liner Motion (LIN)	131
4.4	Circular Motion(CIRC)	132
4.5	Robot Singular Point Description	132

4.6	Blend (Continuous Trajectory)	. 134
4.7	Continuous/ Discontinuous Trajectory Description	. 135
<u>5.</u>	Program Editor Setting and Operator	. 142
5.1	Manage Program List	. 142
5.2	Add and Delete File/Folder	. 142
5.3	Copy File/Folder	. 143
5.4	Cut File/Folder	. 144
5.5	Rules of name Files	. 145
5.6	HRSS Program Commend Structure Description	. 145
5.7	Program Operator Description	. 147
5.7.1	Set Program Ratio	147
5.7.2	Start A Program	147
5.8	Edit Program Page Function Description	. 149
5.8.1	Editor State Description	150
5.8.2	Comment Program Line(s)	150
5.8.3	Uncommand Program Line(s)	151
5.8.4	Indent Program Line(s)	151
5.8.5	Cancel indent Program Line(s)	151
5.8.6	Command Tip Button Description	151
<u>6.</u>	Conveyor tracking function application	. 15 <u>3</u>
6.1	Overview of the conveyor tracking system	. 153
6.1.1	Description of the conveyor tracking application process	153
6.1.1.1	Sensor waits to detect the status of the workpiece:	155
6.1.1.2	Sensor detects the status of the workpiece:	155
6.1.1.3	Workpiece enters the working range of the robot:	156
6.1.1.4	Robot executes pick workpiece:	156
6.1.1.5	Robot successfully picked up workpiece:	157
6.1.1.6	Workpiece exceeded the working range of the robot:	158
6.2	Layout of the conveyor tracking system configuration	. 159
6.2.1	Description of the system configurations/specifications	159
6.2.2	Basic installation process	160
6.2.3	Description of electrical wiring connection	161



7.3	Setting ModbusTCP Server Connection Parameters	235	
7.2	Setup Profinet Connection Parameters	233	
7.1	Setup CC-Link connection parameters	232	
<u>7.</u>	FieldBus Communication (SI/O) Application	232	
6.9	Conveyor tracking function status monitor	230	
6.8.2.6	Vision triggered-calibration of the conveyor and robot work ranges	.227	
6.8.2.5	Vision triggered-conveyor motion ratio calibration	.221	
6.8.2.4	Vision triggered-vision and base coordinate calibration	.216	
6.8.2.3	Vision triggered-vision system calibration & adjustment	.215	
6.8.2.2	Vision triggered-install calibration fixture and tool coordinate calibration	.215	
6.8.2.1	Vision triggered-select the calibration template		
6.8.2	Calibration for vision triggered method	.214	
6.8.1.5	Sensor triggered-calibration of the conveyor and robot work ranges	.205	
0.0.1.3 6 8 1 <i>1</i>	Sensor triggered-conveyor motion ratio calibration	200	
6.8.1.2	Sensor triggered-install calibration fixture and tool coordinate calibration	.196	
6.8.1.1	Sensor triggered-select the calibration template	.195	
b.8.1	Calibration for sensor triggered method	.195	
ö.ö	Collibration for concernmining and mathe	10E	
b./	Sensor triggered object setting	194	
0.0 c =	vision triggered object setting	192	
0.5	Vision triggorod object cotting	100	
65	Conveyor tracking vision image parameters	199	
6.4.4	Description of conveyor digital input/output interface settings	.185	
6.4.3	Description of conveyor custom packet interface settings	.184	
6.4.2	Description of conveyor motion interface settings	.178	
6.4.1	Description of conveyor tracking interface settings	.176	
6.4	Conveyor tracking object parameter setting	175	
6.3.2	Communication format and example description17		
6.3.1	Description of HRSS conveyor tracking and machine vision communication timing	.169	
6.3	Explanation of conveyor tracking system communication format	169	
6.2.3.4	Encoder connection method for the combination of pick and place tasks	.168	
6.2.3.3	Encoder connection method for single placement tasks	.167	
6.2.3.2	Encoder connection method for single pick tasks		
6.2.3.1	Description of the encoder module input terminal (Encoder Socket)	.161	



7.4	Setting ModbusTCP Client Connection Paramedics 236	
7.5	Setting ModbusRTU Server Connection Parameters	
7.6	ModbusRTU Client connection parameter settings 239	
7.7	Modbus Monitor Page 241	
7.8	FieldBus Application Description	
7.8.1	Field Bus Input(SI[n])242	
7.8.2	Field Bus Output(SO[n])243	
7.8.3	FieldBus Register Mapping245	
7.8.4	Field Bus Register(SRR 、 SRW)249	
7.8.5	Fieldbus EtherNet IP251	
<u>8.</u>	Inquire Error Message And Solution Description	
8.1	Robot system software,01-XX-XX) 252	
8.1.1	System Error Message(01-01-XX)252	
8.1.2	Program Error(01-02-XX)257	
8.1.3	Motion Error(01-03-XX)	
8.1.4	Operation Erro(01-04-XX)	
	IO & Communication(01-05-XX)275	
8.1.5	275	
8.1.6	Operator Error(01-06-XX)	
8.1.7	External Axis Error(01-07-XX)279	
8.1.8	Conveyor Tracking Error(01-08-XX)	
8.1.9	User-Defined Error(01-09-XX)282	
8.1.10	Authorization Error(01-0B-XX)283	
8.1.11	Windows Information	
8.2	HIWIN robot controller(02-XX-XX)	
8.2.1	Safety Input(02-01-XX)285	
8.2.2	Hardware Error(02-02-XX)	
8.3	Axis amplifier(03-XX-XX) 286	
8.3.1	Function Name and Number Description286	
8.3.2	Driver Alart Number	
8.3.3	DAC - Y Driver Alarm Code(Y-XXX)	

8.3.4	DAC – S Driver Alarm Code(S-XXXX)	
8.4	Electric gripper(04-XX-XX)	306
8.4.1	Hardware Error(04-01-1X)	
8.4.2	Operation Error(04-01-2X 、 04-01-8X)	
8.4.3	Electric Gripper Controller Alarm Signal Error(04-01-3X)	
8.4.4	Electric Gripper Commend Communication Timeout(04-01-4X)	
<u>9.</u>	Program Examples	
9.1	Register Class	
9.1.1	COUNTER Register	
9.1.2	TIMER Register	
9.2	Variable Type Class	
9.2.1	REAL (Floating Point)	
9.2.2	INT (Integer)	
9.2.3	UINT (Unsigned Integer)	
9.2.4	BOOL	
9.2.5	CHAR (Character)	
9.2.6	E6POS Point (Cartesian Coordinate Point)	
9.2.7	E6AXIS Point(Joint Coordinate Point)	
9.2.8	E6POINT (Cartesian Coordinate Point and Joint Coordinate Point)	
9.3	Logical Operator Class	
9.3.1	Arithmetic Operator	
9.3.2	Logical Operator	
9.3.3	Relation Operator	
9.4	Input / Output Class	315
9.4.1	Digital Input	
9.4.2	Digital Output	
9.4.3	Robot Input	
9.4.4	Robot Output	
9.4.5	Valve Input	
9.5	Motion Function Class	316
9.5.1	PTP (Point-to-point Absolute Motion)	

9.12	Conveyor Configuration Class	351		
9.11	NET(Network) Communication Configuration Class	350		
9.10	RS232 Communication Configuration Class	349		
9.9.2	Definition & Using Method of External Subprogram(EXT)	348		
9.9.1	Definition & Using Method of External Function(EXTFCT)	347		
9.9	External Function & Subprogram Class	347		
9.8.2	Definition & Using Method of Subprogram	345		
9.8.1	Definition & Using Method of Function			
9.8	Function and Subprogram Class	343		
9.7	Definition of Structure Class	342		
9.6.9	QUIT	341		
9.6.8	WAIT	341		
9.6.7	SWITCH	337		
9.6.6	GOTO	335		
9.6.5	REPEAT	333		
9.6.4	WHILE	332		
9.6.3	LOOP	331		
9.6.2	FOR	329		
9.6.1	IF	327		
9.6	Contol Flow Function Class	327		
9.5.12	EXT_TCP(Option)	326		
9.5.11	BRAKE	325		
9.5.10	CT_A6 (Axis 6 Continuous Turning)	324		
9.5.9	Array Accumulation	323		
9.5.8	SPLINE (Spline Motion)	323		
9.5.7	CIRC_REL (Arc, Relative Motion)	322		
9.5.6	CIRC (Arc, Absolute Motion)	321		
9.5.5	LIN_REL_TOOL (Linear, Relative Motion for Tool coordinate)	320		
9.5.4	LIN_REL (Linear, Relative Motion)			
9.5.3	LIN (Linear, Absolute Motion)	318		
9.5.2	PTP_REL (Point-to-point Relative Motion)	317		



9.12.1	CNV_START
9.12.2	CNV_END
9.12.3	CNV_PICK_QUANTITY
9.12.4	CNV_TRIGGER_TIMES[NUM]352
9.12.5	CNV_PICK
9.12.6	CNV_PLACE
9.12.7	CNV_OBJECT
9.12.8	CNV_FULL
9.12.9	CNV_EMPTY
9.12.10	CNV_SET_DELAY_TIME[NUM]356
9.12.11	CNV_QUEUE_SIZE[NUM]
9.12.12	CNV_OBJ_CNT_DIST[NUM]359
9.12.13	CNV_PLACE_BATCH[NUM]
9.12.14	CNV_RESET_ENC
9.12.15	CNV_QUEUE_REMOVE[NUM]
9.12.16	CNV_PICK_ACC[NUM]
9.12.17	CNV_OFFSET_X[NUM]
9.12.18	CNV_OFFSET_Y[NUM]
9.12.19	CNV_OFFSET_Z[NUM]
9.12.20	CNV_SPEED[NUM]
9.13	Do Switching on the Path(SYN Out) Class
9.13.1	Program Example 1 of SYN
9.13.2	Program Example 2 of SYN
9.13.3	Program Example 3 of SYN
9.13.4	Program Example 4 of SYN
9.13.5	Program Example 5 of SYN
9.14	Issue Self-defined Alarm Text Command 368
<u>10.</u>	Functional Program Application Example
10.1	Motion Commands Description 369
10.2	Register Commands Description 370
10.3	Variable Type Commands Description



10.4	Trigonometric Function of Math Calculation Commands Description	372
10.5	Control Flow Function Commands Description	372
10.6	Other Function Commands Description	374
10.7	External Axis Commands Description	375
10.8	Network and RS232 Communication Application Example	377
10.9	Conveyor Tracking Application Example	379
10.9.1	Visual Way A Conveyor Pick/Place Object to B Conveyer Example(A)	.379
10.9.2	Sensor Way A Conveyor Pick/Place Object to B Conveyer Example(B)	.380
10.9.3	Sensor Way A Conveyor Pick/Place Objects to B Conveyer Example(C)	.381
10.10	External Axis Application Example	383
10.11	Gripper Commands Description	383
<u>11.</u>	Safety Certification	387



o. Warranty Terms and Conditions

The period of warranty shall commence at the received date of HIWIN product (hereafter called "product") and shall cover a period of 12 months. The warranty does not cover any of the damage and failure resulting from:

- 1. The damage caused by using with the production line or the peripheral equipment not constructed by HIWIN.
- 2. Operating method, environment and storage specifications not specifically recommended in the product manual.
- 3. The damage caused by changing installation place, changing working environment, or improper transfer after being installed by the professional installer.
- 4. Product or peripheral equipment damaged due to collision or accident caused by improper operation or installation by the unauthorized staff.
- 5. Installing non-genuine HIWIN products.

The following conditions are not covered by the warranty:

- 1. Product serial number or date of manufacture (month and year) cannot be verified.
- 2. Using non-genuine HIWIN products.
- 3. Adding or removing any components into/out the product without authorized.
- 4. Any modification of the wiring and the cable of the product.
- 5. Any modification of the appearance of the product; removal of the components inside the product. e.g., remove the outer cover, product drilling or cutting.
- 6. Damage caused by any natural disaster. i.e., fire, earthquake, tsunami, lightning, windstorms and floods, tornado, typhoon, hurricane etc.

HIWIN does not provide any warranty or compensation to all the damage caused by above-mentioned circumstances unless the user can prove that the product is defective.

For more information towards warranty terms and conditions, please contact the technician or the dealer who you purchased with.

	*	Improper modification or disassemble the robot might
		reduce the robot function, stability or life.
	*	The end-effector or the cable for devices should be installed
		and designed by a professional staff to avoid damaging the
WARNING		robot and robot malfunction.
	*	Please contact the technician for special modification coming
		from production line set up.
	*	For the safety reason, any modification for HIWIN product is
		strictly prohibited.



Safety Precautions

1.Safety Information

- Safety Responsibility and Effect
- 1. This chapter explains how to use the robot safely. Be sure to read this chapter carefully before using the robot.
- 2. The user of the HIWIN industrial robot has responsibility to design and install the safety device meeting the industrial safety regulations in order to ensure personal safety.
- 3. In compliance with the safety information on industrial robot described in this manual can't guarantee that *HIWIN* robot will not occur any safety problems.
- 4. This machine is defined as a partly completed machinery, the associated hazards must be handled by system integrator in accordance with ISO 102018-1/ ISO 102018-2.
- 5. A safety-related part of control system (SRP/CS) should conform to the requirement of performance level d and category 3 according to ISO 13849-1.
- 6. The installation for emergency functions shall be defined by the system integrator in accordance with ISO 10218-1/ ISO 10218-2.
 - Safety Operation Principle
- 1. Before connecting the power supply for HIWIN industrial robot startup assembly procedure, check whether the specification of factory output voltage matches the specification of input voltage of the product. If it does not match, ensure to use the corresponding transformer (HIWIN optional transformer is recommended).
- 2. Emergency Stop button (on Teach Pendant or from external emergency stop switch) must be pressed before turning off the power, and then switch off the power switch.
- 3. While connecting to the external I/O or the signal, please operate in the condition that the power switch is turned off to prevent from a shortcut caused by mistaken touch in the process, and resulting in damage.



Safety Precautions

i.General

All personnel involved in the use or setup of the industrial robot arm must read the safety related literature for the robot arm and instruction manual in detail and operate it in accordance with the specifications.

Safety Symbol

Symbol	Description
5911661	Description
	Failure to follow instructions with this symbol may result
DANGER	in serious hazard or personal injury. Please be sure to
	comply with these instructions.
	Failure to follow instructions with this symbol may result
WARNING	in personal injury or product damage. Please be sure to
	comply with these instructions.
	Failure to follow instructions with this symbol may result
CAUTION	in poor product performance. Please be sure to comply
	with these instructions.
! CAUTION	Failure to follow instructions with this symbol may result in poor product performance. Please be sure to comply with these instructions.

Use Limit

Robotic arm is prohibited for use in the following environments and uses

- Personnel carrying purposes
- Explosive environment
- Environment without safety precautions
- Outdoor environment
- Environment affected by oil, water, dust, etc.



ii.Relevant Personnel

Electrical or mechanical work on industrial robot arms is only permitted by professionals.



WARNING

All personnel working on industrial robotic arms must read and understand the manual containing the safety section of the system of the robotic arm All personnel working on industrial robotic arms must read and understand the manual containing the safety section of the system of the robotic arm.

System Integrator

Refers to the person who integrates the industrial robot arm into a set of equipment according to safety regulations and puts it into operation.

The system integrator is responsible for the following tasks:

- Install industrial robot arm.
- Industrial machinery arm related equipment connection work.
- Risk assessment of the overall system.
- Use safe guard devices.
- Confirm that the components used by the safe guard devices are in compliance with regulations.
- Placement, replacement, setup, operation, maintenance and repair work is only permitted for specially trained personnel in accordance with the operating instructions for the components of the industrial robot arm.

User	

Users must be professionally trained, have the knowledge and experience in this area, and be familiar with the prescribed standards, and thus be able to make a correct judgment of the work to be performed and identify potential hazards.

Users can be defined into three categories based on operational permissions:

- 1. Operator
 - System startup and shutdown
 - Power on and off
 - Alarm system status recovery

2. Engineer

- Operating personnel usage authority
- Programming and changing
- Arm teaching operation
- 3. Expert



Engineer usage authority
 Mechanical arm maintenance work



System Operation

Those who do not use functional safety kits must implement safety-fence guidance.

The system operation of personnel is divided into the following three levels

- 1. Operator
- 2. Engineer
- 3. Expert

Its control permissions are shown in the following table.

No	Eunction	Оре	Monitor	
INO	Function	Manual Mode	Automation Mode	Monitor
	Function Table			
1	Interface Languages	0	0	0
2	Permission Selection	0	0	0
3	Mode Selection	Х	0	Х
4	Velocity Adjustment	0	0	Х
5	Tool/Base Selection	0	Х	Х
6	Update Software	0	Х	Х
7	Save Database	0	Х	Х
8	Load Database	0	Х	Х
9	Program execution	0	0	Х
10	Hold Program	0	0	Х
11	Stop Program	0	0	Х
12	Homing	0	Х	Х
13	Jog	0	Х	Х
14	Program Edit	0	Х	Х
15	Program Update /Download	0	Х	Х
16	Add Point	0	Х	Х
17	Counter	0	Х	Х
18	System I/O	0	0	Х
19	RSR Setting	0	Х	Х
20	Fieldbus	0	0	Х
Nic		Оре	erator	
NO	Function	Manual Mode	Automation Mode	Monitor
21	Clear Alarm	0	0	Х
22	Conveyer Track ->Setting	0	Х	Х
23	Conveyer Track -> Vision Setting	0	Х	Х
24	Conveyer Track -> Vision Object Setting	0	Х	Х
25	Conveyer Track ->Sensor Object Setting	0	Х	Х



26	Conveyer Track ->Setting Calibration	0	Х	х
27	Conveyer Track ->Setting Monitor	0	0	0
28	Axis Zero Position/calibration	0	Х	Х
29	Tool/Base calibration	0	Х	Х
30	Logbook	0	0	0
31	Network Config	0	Х	Х
32	Home Setting	0	Х	Х
33	Time Setting	0	Х	Х
34	RS-232	0	Х	Х
	Interface			
35	Add Robot	0	0	0
36	Close All	0	0	0

\rm MARNING

Electrical or mechanical work is only allowed to be carried out by professionals .

Operator Safety Precautions

The manner and scale of the work and the possible hazards must be explained to the relevant personnel before work, and relevant training courses must be carried out on a regular basis. In the event of an accident or technical correction, a training course must be re-run.

System Set Up Safety Precautions

The system set up only allows specially trained personnel to perform and work in accordance with the installation, setup, operation and other relevant documents provided by the original manufacturer.

Maintenance Personnel's Precautions

Maintenance should only be carried out by specially trained personnel in accordance with the instructions and operating instructions.



iii.Robotic Arm Working Range Definition

Working area

The working area of the robot is defined as the area of motion under motion constraints, and the working area must be limited to the minimum required.

Protective area

Operation must be carried out outside the protected area.

A protected area is an area of the working area that is protected by a safe guard device. Please ensure the protective area includes working area of the robot. A safety-related part of control system (SRP/CS) should conform to the requirement of performance level (PL)= d and category 3 according to ISO 13849-1.



- Please ensure the emergency stop switch is in reset status before the robot functions.
- The external device connected to the emergency stop switch circuit should be dry contact (uncharged) switch. It is forbidden to use a live circuit to connect to the controller emergency stop switch circuit.







●It must use EMO-Emergency stop (EN 60947-5-1 positive opening) with safety module to meet ISO 13849-1 performance level (PL)= d





iv.Description of Safety Functions

Industrial robotic arms must have the following safety features:

- Selection of operating mode of the robot arm
- Safe guard devices
- Emergency stop device
- Teach pendant enable switch

The safety function of the robot arm system is to prevent loss of personnel or property. If the function is not complete or in failure state, the industrial robot arm must be prohibited from operating.

Manual Mode

The manual mode is used for program design, program operation check or teaching, etc. When performing manual operation, pay attention to the followings:

- All actions must be operated within the protection area.
- Do not damage or potentially damage the relevant equipment due to operates the robotic arm.
- Operation must be carried out outside the protected area as much as possible.

Both manual and automatic modes of operation in the protected area are not permitted unless the arm is equipped with a certified speed monitoring accessory from the manufacture.



Automatic Mode

The automatic mode startup should include the following conditions:

- The safe guard devices have been set up and confirmed that their functions are working properly.
- All suspended security should restore its full functionality.
- Confirm that there are no people in the protected area.
- Relevant workflow rules are complied.

To enter the protection area in this mode, the emergency stop function must be activated before entering.

Safe Guard Devices Description

The safe guard device must use the components approved by the safety regulations and set and plan according to the relevant regulations.

The robotic arm system must be automatically activated to receive the safety signal. In the event of a connection failure during automatic mode operation, an emergency stop must be triggered. When reconnecting after disconnection, the device cannot be automatically started directly and must be started manually. Manual slow running (T1) and manual fast running (T2) modes allow the guard not activate. A method must be provided to confirm that no personnel are in the protected area when the automatic mode is activated.

Users must strictly abide by the content description, otherwise it will cause serious casualties.

Temporary fences can be used during system installation and can be set according to ISO 10218-2 regulations

Stop Functions

Emergency Stop Description

Emergency stop related precautions

- Confirm that the function is functioning normally every six months.
- System integrators should provide emergency stop devices to ensure that the machine is operational or that a hazardous situation exists.
- At least one external emergency stop device is installed. Make sure that additional emergency stop devices are available for use without or losing the teach pendant.
- Provide interface to connect external emergency stop devices.
- The emergency stop function can be triggered when the safety control system connected to the robot arm is cut off.
- The risk assessment should assess whether the emergency stop is not triggered when the robotic arm control system is turned off and provides a response.



If a tool or other device connected to the robot is dangerous, it must be connected to the emergency stop circuit on the equipment side.

v.Warnings and Precautions

General considerations

A DANGER

- 1. All operating procedures should be assessed by professional and in compliance with related industrial safety regulations.
- 2. When operating robot, operator needs to wear safety equipment, such as workwear for working environment, safety shoes and helmets.
- 3. When encountering danger or another emergency or abnormal situation, please press the emergency stop button immediately. After danger is eliminated, move the robot away with low speed in manual mode.
- 4. When considering safety of the robot, the robot and the system must be considered at the same time. Be sure to install safety fence or other safety equipment and the operator must stand outside the safety fence while operating the robot.
- 5. A safety zone should be established around the robot with an appropriate safety device to stop the unauthorized personnel from access.
- 6. While installing or removing mechanical components, be aware of a falling piece which may cause injury to operator.
- 7. Ensure the weight of workpiece does not exceed the rated load or allowable load moment at wrist. Exceeding these values could lead to the driver alarm or malfunction of the robot.
- 8. Do not climb on manipulator.
- 9. Do not store the machine in the environment with corrosion and flammable gas or close to the flammable object.
- 10. Do not operate the machine in the environment with moisture, water or grease.
- 11. Do not operate the machine at the place where vibration or the strong impact occurs.
- 12. Do not immerse the electric wires into grease or water.
- 13. Do not connect or operate the machine with wet hands.
- 14. Do not operate the machine in potentially explosive environment.
- 15. Please ensure the controller is grounded.
- 16. Keep hands away from the inner part of the controller while it is connecting to the power or during operating.
- 17. Do not touch the heat sink, regenerative resistance, the power supply or the computer inside the controller while it is operating due to its high temperature.
- 18. Be sure power is disconnected prior to repair and maintenance, and ensure to operate under the condition of no electrical shock risk.



19. Do not disassembly the controller without permission. If there's any issues, please contact our engineers.



- 1. The personnel installing robot should be trained and licensed.
- 2. To ensure personal safety, robot installation must comply with this manual and related industrial safety regulations.
- 3. The control cabinet should not be placed near high voltage or machines that generate electromagnetic fields to prevent interference that could cause the robot to deviation or malfunction.
- 4. Using non-HIWIN spare parts to repair may cause robot damage or malfunction.
- 5. Beware of the heat generated by the controller and servo motor.
- 6. Do not overbend the cable to avoid poor circuit contact or unexpected damage.
- 7. Do not stand on the controller or put heavy objects on it.
- 8. Do not block the vent or put foreign objects into the controller.
- 9. Please ensure the controller is fixed on the base.
- 10. Do not pull the connector violently or twist the electric wires excessively.
- 11. Do not frequently switch ON/OFF the power switch and the control button.
- 12. Please ensure that the robot, the emergency stop switch and the controller are functioning properly before performing any work.
- 13. Do not shutdown the power switch during the operation.
- 14. Do not open, modify, disassemble and maintain the machine without permission.
- 15. The power must be disconnected when the machine does not operate in a long time.
- 16. Do not turn off the power of the controller when modifying the program or parameter. Otherwise, the data stored in the controller will be damaged.
- 17. When changing the program or parameters inside the robot controller, do not turn off the power of the controller. Otherwise, the internal data of the controller will be damaged.
- 18. After the brake of a servo motor is released, the robot will be moved due to gravity and it may injure the operator.
- 19. The industrial robots can be applied for the different industrial environments.
- 20. When the operating procedures are interrupted, the special attention should be paid during the troubleshooting.



Precautions during operations

🛕 DANGER

- 1. Teaching, jogging or programming should be done outside of the safety fence. If it is inevitable to enter the safety fence, press the emergency stop button before entrance. Operation should be restricted at low speed and beware of surrounding safety.
- 2. All operations shall be executed by trained staff.
- 3. All operations are required to perform in the safe area.

Maintenance Precautions

\rm ADANGER

- 1. Please contact us if the procedure not specified by HIWIN is needed.
- 2. Please contact us if the replacement of the component not specified by HIWIN is needed.
- **3.** Be sure to carry out regular maintenance, otherwise it will affect the service life of the robot or other unexpected danger.
- 4. Prior to repair and maintenance, please switch off power supply.
- 5. Maintenance and repair should be performed by a qualified operator with a complete understanding of the entire system to avoid risk of robot damage and personal injury.
- 6. When replacing the components, avoid foreign object going into the robot.

Precautions for using End Effector

End effectors can be basically divided into the following two categories:

- A. Gripper: Mainly for pick and place operations, such as pneumatic, electric gripper, vacuum suction cup, etc.
- B. Tools: Mainly for processing operations, such as welding, cutting, surface treatment, etc.

A DANGER

- 1. More attention must be paid to the design of the end effector to prevent power loss or any other errors that could lead to workpiece falling or damage.
- 2. The tool-type end effector is usually equipped with high voltage, high temperature and active rotary shaft. Special attention should be paid to the operating safety.
- 3. The end effector should be mounted firmly on the robot to avoid workpiece fall during operation which may cause personal injury or hazard.

A WARNING

- 1. The end effector may be equipped with its own control unit. During installation, pay attention to installed location. Ensure that the control unit does not interfere with robot operation.
- 2. The gripper-type end effector should prevent the workpiece from dropping or damaging when the robot experiences a power error or other errors. If potential dangers or abnormal situations exist when using end effector, the associated hazards must be handled by the system integrator in accordance with the related standards.



Precautions for using Hydraulic and Pneumatic

DANGER

- 1. When using the pneumatic or hydraulic system, the gripped workpiece may fall due to insufficient pressure or gravity.
- 2. The pneumatic or hydraulic system must be equipped with the relief valve, so that it can be applied in an emergency.

A WARNING

- 1. More attention should be paid to the pressure remained in the pneumatic systems after the power is disconnected.
- 2. The internal pressure must be released before the pneumatic systems are maintained.
- 3. More attention should be paid to the pressure in the pneumatic system as it is several times more than the atmosphere pressure.

Emergency Stop Switch Precautions

🚹 DANGER

- 1. The robot or other control component should have at least one device for immediate halt, such as an emergency stop switch.
- 2. The emergency stop button must be installed in an easily accessible location for quick stop.
- 3. While executing an emergency stop, power to the servo motor will be cut, and all movements will be stopped. And the control system will be shut down. Emergency stop should be reset if the restoration of operating procedure is wanted.
- 4. Avoid using emergency stop to replace a normal stop procedure. This could reduce the lifespan of the robot.

A WARNING

- 1. When an emergency stop is performed, the power of the drive is cut off, all operations are stopped, and the control system of the robot arm is turned off.
- 2. To resume execution, reset the emergency stop switch.
- 3. Emergency stop is immediate stop: Immediately stop the movement of the robot arm and cut off the power of the drive.
- 4. The emergency stop switch is for emergency stop only.
- 5. HIWIN's industrial robot arm has two emergency stop switches, one of which is located on the teach pendant and the other is automatically connected to the controller via a dedicated cable. If there is a need for other emergency stop switches, the other means of connection can be used to achieve the purpose of emergency stop.
- 6. Based on the relevant industrial safety regulations, the emergency stop switch needs to be directly connected to the control box of the robot arm through a physical connection line.
- 7. Additional installed safety equipment must comply with PLD level.



1. Introduction

1.1 Remote Robot Control Software (Caterpillar) Overview

Welcome to the Remote Robot Control Software management and development environment; features of the Remote Robot Control Software includes:

Can be run under Microsoft Windows 7 and Windows 10

Communicate with robot controller through Ethernet

■Allow personal computer to connect to single or multiple robot controllers. Maximum number of connections is four.

■HIWIN Robot language editor

- ■Robot program files management
- ■I/O management
- ■TCP/IP and RS232 management
- ■Logbook

1.2 System connection architecture overview

The following system block diagram displays how remote-control robot software connects to single or multiple robot controllers. :

System 1 : Connect a robot controller to personal computer through Ethernet



System 2 : Connect multiple controllers to personal computer through Ethernet



System Block Diagram



1.3 Windows System Recommended Environment

- Robot controller does not support TCP/IPv6. TCP/IPv4 is allowed.
- .NetFrameWork 4.6.1 ∘
- Visual studio 2017 redistributable
- Resolution 1024x768 above
- Support robot type: RS405-500-200-LU 、 RS405-500-400-LU 、 RS405-400-200-LU 、 RS405-400-400-LU 、 RS410-600-200-LU 、 RS410-700-400-LU 、 RS410-800-400-LU

At least one external emergency stop button is installed

Caterpillar DPI will be set automatically upon start up so that the user interface can be displayed correctly; if the setting fails, users must set it manually to ensure normal operation •

Resolution	Setting
	Resolution DPI (Dots Per Inch) MUST be correct then run Caterpillar ! 1. Right-click the Caterpillar.exe, select "Properties" 2. Select "Compatibility" then "Change high DPI settings". 3. Check the "override high DPI scaling behavior" box. 4. Choose "System" from the drop-down menu.
	Do not show this dialog again OK

Adjust display settings for Windows scaling issues with high-DPI devices. Right-click the application (Caterpillar.exe), select "Properties", select "Compatibility" tab, and then select the "Change high DPI settings". Check the "override high DPI scaling behavior" box and choose "System" from the drop-down menu. Finally, click "OK".

General Compatibility Security Details Previous Versions	Caterpillar Properties X
If this program isn't working correctly on this version of Windows, try running the compatibility troubleshooter. Run compatibility troubleshooter How do I choose compatibility settings manually? Compatibility mode Run this program in compatibility mode for: Windows 8 Settings Reduced color mode 8-bit (256) color	Choose the high DPI settings for this program. Program DPI Use this setting to fix scaling problems for this program instead of the one in Settings Open Advanced scaling settings A program might look blurry if the DPI for your main display changes after you sign in to Windows. Windows can try to fix this scaling problem for this program by using the DPI that's set for your main display when you open this program. Use the DPI that's set for my main display when I signed in to Windows
Run in 640 x 480 screen resolution Disable fullscreen optimizations	Learn more
Change high DPI settings	High DPI scaling override Override high DPI scaling behavior. Scaling performed by:
Change settings for all users	System V
OK Cancel Anniv	OK Cancel



1.3.1 Windows System Setting for Different Area

- ■Select Control Panel\All Control Panel Items => Region and Language => Other Settings
- ■Custom Format => Numbers
- ■Select. for the decimal symbol
- ■Select, for the digit quantile

🔗 自訂格式	×		
數字 貨幣 時間 日期 排序	Ē		
鲍例 正值: 123,456,789.00	負值: -123,456,789.00		
小數符號(<u>D</u>):			
小數點位數(<u>N</u>):	2		
數字分位符號(D):	, 🗸		
數字分位(G):	123,456,789 🗸		
負號(E):	- •		
負數格式(1):	-1.1 🗸		
顯示前置 '0' 字元(<u>P</u>):	0.7 🗸		
清單分隔字元(L):			
度量單位系統(<u>M</u>):	公制 ▼		
標準數字(<u>S</u>):	0123456789 🗸		
使用當地化數字(U):	不使用 ▼		
按一下 [重設],將數字、貨幣、時間及 定。	日期還原為系統預設設 重設(R)		
(確定取消		



1.4 Software Version Compatibility Description

Please refer to the following table for the software version compatibility correspondence between Caterpillar (remote connection interface software) and HRSS (HIWIN robot software system): Caterpillar and HRSS version Correspondence table

Edition	Date	Applicable Software	Applicable Range	Remark
1.0.1.5952	2020.01.01	HRSS 3.3.2a.5953	RS405 RS410 系列	SDK 2.2.1
1.0.2.6133	2020.02.27	HRSS 3.3.3a.6128	RS405 RS410 系列	SDK 2.2.2
1.0.3.6314	2020.03.27	HRSS 3.3.4a.6309	RS405 RS410 系列	SDK 2.2.3
1.0.4.6478	2020.04.27	HRSS 3.3.6a.6472	RS405 RS410 系列	SDK 2.2.4
1.0.5.6779	2020.07.10	HRSS 3.3.7a.6777	RS405 RS410 系列	SDK 2.2.5
1.0.6.6940	2020.08.05	HRSS 3.3.8a.6933	RS405 RS410 系列	SDK 2.2.6
1.0.7.7071	2020.09.01	HRSS 3.3.9.7074	RS405 RS410 系列	SDK 2.2.7
1.0.8.7244	2020.10.01	HRSS 3.3.10.7245	RS405 RS410 系列	SDK 2.2.8
1.0.9.7487	2020.11.01	HRSS 3.3.11.7492	RS405 RS410 系列	SDK 2.2.9
1.0.10.7634	2020.11.30	HRSS 3.3.12.7633	RS405 RS410 系列	SDK 2.2.10
1.0.11.7843	2020.12.29	HRSS 3.3.13.7842	RS405 RS410 系列	SDK 2.2.11
1.0.12.7958	2021.01.29	HRSS 3.3.14.7959	RS405 RS410 系列	SDK 2.2.12
1.0.13.8062	2021.02.26	HRSS 3.3.15.8063	RS405 RS410 系列	SDK 2.2.13
1.1.0.8168	2021.03.30	HRSS 3.3.16.8169	RS405 RS410 系列	SDK 3.0.1

Update Version Notice

🦺 WARNING

1. The software update package contains the robot system software HRSS and the remote control software Caterpillar. The two versions have the corresponding relationship as above, and must be updated at the same time.

2. When Caterpillar is used for connection, the HRSS version will be detected automatically; a window prompt will appear if the HRSS is too old, ; notifying that the HRSS version must be updated.

3. Next, select the Upgrade HRSS page to upload the updates file in order to get a new version of HRSS as shown below:

Software Update SOP

1. Download the latest version of Caterpillar (folder) and the HRSS update package (.exe file).

2. Open your old version of Caterpillar and connect to the robot. An option window will pop up

automatically for choosing whether the HRSS need to upgraded or download Caterpillar (this feature will work for HRSS 3.3.10 and Caterpillar 1.0.8 or above), as shown in Figure (Img 0.1).

3-1. Select the Upgrade HRSS option, and upload the HRSS update package (.exe file) to update (there will be a disconnection when the update is completed). As shown in Figure (Img 0.2).



3-2. Select the Downgrade Caterpillar option to download the correspondence HRSS version of Caterpillar (Img 0.3)

4.Refresh the Caterpillar and connect the HIWIN robot with a new version of Caterpillar after updates. (Do not use the old version of Caterpillar).

Caterpillar 1.0.8_	250								
Add Robot	Languages	Close All	System	About			2020/09/15	14:47:15	
			С	Version Not Mate	h Caterpillar ve HRS version: :	rsion: 1.0.8 3.3.10	8		
					Upgrade HRSS 3.3.10	Downgrade Caterpillar 1.0.8			

(Img 0.1)

Upgrade HRSS	Downgrade Caterpillar
Upgrade file Browse	Downgrade File Save As
Upload Cancel	Download Cancel

(Img 0.2)

(Img 0.3)

Software Compatibility Description

Description

Caterpillar version 1.1.0 (included) and above can operate any version of HRSS 3.3.16 (included) and above without version restrictions; if Caterpillar and HRSS versions are does not match during the login process, a prompt message window pop-up as "some of the functions are not available", but still you can "skip update" and continue to the HIWIN robot connection if the updates is minor. The update cannot be skipped when there are major revisions (when the first digit of the local terminal connection is different); users will be forced to update HRSS to the latest version in order to continue using it.



There are 4 different versions; refer to the figure below:

(1). Caterpillar's software version, for example: Caterpillar 1.1.0

- (2). Caterpillar's local terminal connection version, for example: 1.21.
- (3). HRSS' software version, for example: HRSS 3.3.13.
- (4). HRSS' connection version, for example: 1.0.

The pairing of Caterpillar and the robot is based on the Caterpillar and HRSS's connection version digits. If their first digits are different; they must be updated in order to work. If their second digits are different; then some of the functions are not supported, but still can "skip update" can be selected to continue operation.



HRSS & Caterpillar version description window

Prerequisites

1.Must be download the compatible versions of Caterpillar 1.1.0 and HRSS 3.3.16 (included) or above.

Instructions

As previously described, the release methods include major versions (changes in the first digit) and general versions (changes in the second digit):

⇒Release steps for major revisions:

1. When major revisions are released, updating is mandatory; the Figure that will appear when connecting two different versions as shown below.



Major revision connection window (Chinese on the left and English on the right)



2.Clicking on "Details" on the screen will connect to the figure below; it will explain 4 different connection versions details.

Version Not Match	Σ	Version Not Match		
連線版本不匹配,請更新	f或下載軟體。	The connection version does not match, please		
Caterpillar 版本:	1.1.0	update or download software.		
本地端連線版本:	2.0	Caterpillar Version: 1.1.0		
HRSS 軟體版本:	3.3.13	Local connection Ver: 2.0		
HRSS 連線版本:	1.0	HRSS software Ver: 3.3.13		
		HRSS connection Ver: 1.0		
更新到	下載	Update to Download		
HRSS 3.3.16	Caterpillar	HRSS 3.3.16 Caterpillar		

Detail description figure (Chinese on the left and English on the right)

3. The "Update to HRSS" or "Download Caterpillar" button must be selected to update the HRSS software or to download the Caterpillar software for the current controller.

⇒Release steps for general versions:

1. The skip update figure will appear when connecting different version of Caterpillar and HRSS as shown below.



Gerneral versions description figure (Chinese on the left and English on the right)

2. Three are three options are available; "Update to HRSS", "Download Caterpillar," or "Skip update".

3. Pressing the "Update HRSS" button can update the HRSS with respective specified version.

4.Pressing the "Download Caterpillar" button will obtain the currently connected operating software from the controller; refer to Chapter 1.5.

5. "Skip update" will perform the connection directly (this function appears on Caterpillar 1.1.0 and HRSS 3.3.16 (included) or above); however, some of the new/old functions are not supported. This means the two versions are compatible.



1.5 Download Controller's HRSS Version of Remote operation software

Description

When Caterpillar and HRSS versions does not match, users can choose to update HRSS or download the Caterpillar version with respect to the HRSS version which is currently connected. This function is only supported for HRSS 3.3.10 and Caterpillar 1.0.8 (included) or above.

Operator Step

1.When Caterpillar version 1.0.8 and HRSS version 3.3.10 or above are opened and does not match; if the Caterpillar version is newer than HRSS, a selection window will pop up to either Upgrade HRSS or Downgrade Caterpillar.

P Caterpillar 1.0.9_7280			
Add Robot Languages Close All System	About	2020/09/15 15:45:11	
C	Version Not Match Caterpillar version: 1.0.9 HRS version: 3.3.10 Upgrade HRSS 3.3.11 Downgrade Caterpillar 1.0.8		

Selection of Upgrade HRSS or Downgrade Caterpillar

2.Clicking Upgrade HRSS will allow the user to update the HRSS version.

3.Clicking Downgrade Caterpillar will download the remote operator interface software that matches with the currently connected HRSS.

4. If the HRSS version is newer than Caterpillar, there is only the option to Upgrade Caterpillar.

	Upgrade Caterpilla	r	1
		Caterpillar version: 1.0.8 HRS version: 3.3.10	
\mathbf{C}		Upgrade Caterpillar 1.0.8	

Download Caterpillar



2.Put Into Operation of Description

2.1 Check Robot Plate and Software Version Data

Operation Steps

1. The correct robot program data must be loaded. During parameter check, the loaded robot data must match with the data of the model plate.

2.If loading the new data is required, the status of the robot data must fully match with the HRSS. This is to ensure that when the data is applied, it can be submitted with the HRSS.

3. When connecting the robot system software HRSS, be sure to use the delivered Caterpillar for connection to avoid incompatible versions and cause injury to the robot system.

4. When updating the software, be sure to download HRSS on the official website and Caterpillar at the same time to update.

5.As described in section 1.4, first update the new version of HRSS with the old version of Caterpillar. After the update is successful, you must copy your program to the new Caterpillar folder. Only new HRSS can be connected with the new Caterpillar.

💧 DANGER

If the wrong data is loaded, the robot should not be operated! Failure to take these measurements could lead to serious injury, death or equipment damage

HIWIN Articulated Robot	HIWIN Robot Controller
Read the instruction manual carefully before operate the product.	Read the instruction manual carefully before operate the product.
Model: PA605-710-GB	Model: <u>RCA605-GC</u> Robot Model: <u>RA605-GC</u> Controller S/N: <u>R200045-3-04</u> Robot S/N: <u>R200032-1-04</u> Manufacture Date: <u>Apr.2021</u> Weight: <u>29 KG</u> Power Supply: <u>10, 200-240 VAC</u> Rated Current: <u>8A</u> Eroquence: <u>50/60 Hz</u>
Robet S/N: 0210029 1 05	
Controller 5/N. R210026-1-05	
Controller 5/10. R19000B-1-06	
Manufacture Date: Apr.2021	
Weight: 40 KG	
Rated Payload: 5 KG	
Max. Reach: 710 mm	
Pneumatic Pressure: 2-7 Bar	
Robot Type: Industrial	Protection Class: IP23
	Document No.: C24U104
Made in Taiwan No. 7, Jingke Road, Taichung Precision Machinery Park, Taichung 40852, Taiwan	Made in Taiwan No. 7, Jingke Road, Taichung Precision Machinery Park, Taichung 40852, Taiwan

Name Plate (Example RA605 model)

Operation steps

View the [About] page on the above side of the remote interface software.


About			
L. T	Caterpillar: HRSDK: HRSS: Robot Type: Robot ID:	1.0.3.6324 2.2.3.6324 3.3.1a_6323 RS405-400-200-LU yc.lin.405 OK]

About interface

■ View the [System] page on the life side of the remote interface software.

System	
Update	
Save Database	
Load Database	
Import Comment	
Set password	
Shutdown	
System Report	



2.2 Calibration Flow

Below Figure is the calibration flowchart of robot. According to the user's requirements, they are: Adjusting the origin position $(3.6) \rightarrow$ Calibrate the base coordinate system $(3.4.1 \times 3.5.1) \rightarrow$ Calibrate the tool coordinate system $(3.4.2 \times 3.5.2) \rightarrow$ Calibration of conveyor image $(2.12.1) \rightarrow$ Calibration of conveyor and robot $(2.12.2) \rightarrow$ Configure the parameters of conveyor image $(2.12.3) \rightarrow$ Configure the parameters of conveyor image $(2.12.3) \rightarrow$ Configure the parameters of conveyor object (2.12.4).

The above-mentioned calibration steps will be introduced in the subsequent sections.







2.3 Adjust Origin Position of Hardware Mechanism

Overview

Each robot must be mastered. The robot can make Cartesian motion only after being mastered and moved to the programmed position. The mechanical position of the robot will be made consistent with the encoder during mastering. The robot must be placed on a defined mechanical position, which is the mastered position. The encoder value of each axis will be saved.



Adjust the approximate position of origin

position of origin calibrate distinguish two method : Zero position(定位校正)與 Calibration(校正),

(1) [Calibration] Click this to return to the origin position set by the manufacturer; the robot posture must be close to the origin of the mechanism.

(2) [Zero position] Click this to modify the origin position set by the manufacturer.

distinguish position of origin mastering situation of method to select:

	nastering situation of method table	
Situation (put into Operation)	Method	
The value of motor position is lost after	Execute [Calibration] type	
maintenance such as replacement of a motor	Execute [Calibration] type	
After replacement of gear unit (pulley、 belt)	Execute [Calibration] type	
After a collision, if robot's position has offset state.	Execute [Calibration] type	
If the absolute position is missing after replacing the battery.	Execute [Zero position] type	

distinguish position of origin mastering situation of method table



2.3.1 Four Axes Robot Mastering Method

Description

Operate the various axes to make the mechanism adjustment marks overlap and use the calibration function of the software to redefine the origin position.

Å WARNING

Special note: Performing this operation will lose the origin position originally set for the robot by the manufacturer; improper operations may cause errors to the positions of the corresponding surrounding points and deviation to the absolute accuracy!



Mastering mark of robot

Pin postion of first axis figure

! CAUTION

Depending on the model of the robot, the position of the mastering mark may be slightly different from the illustration. For the origin calibration method and image, please refer to the manual of each model.

<u>Prerequisites</u>

1.Manual mode.

2.Open function tab [Mastering].





Zero position interface

[?] This button shows/hides the description texts; press it once to show the texts, and press it again to hide the texts.

Zero Position: Click to restore the robot's origin position to the factory value. The posture of the manipulator must be close to the mechanical origin of the robot. The mechanical origin is described in each model's respective user manual.
 Calibrate: Click to calibrate a new origin position of the robot, this must be done with the help of the appropriate calibration tool provided with the manipulator.

Operator Step

<u>|</u> CAUTION

If the simulated robot position outside the limit and cannot move, please execute Reset first

Setting origin of first-axis Step:

- Step1 : Press the emergency stop button and push the A arm with your hand until the A arm matches the calibration hole in the base.
- Step2 : Use the calibration tool (ψ4 bar) and insert it into the calibration hole from top to bottom; if the bar could not be inserted, use the jog screen to slowly adjust the angle until the calibration tool can be inserted into the calibration hole, and make the adjustment marks overlap. This completes the adjustment of the hardware mechanism's origin.
- Step 3: Use software positioning calibration (Mastering) → [Positioning calibration Zero Position] button or [Calibration button, click [Reset J1], setting origin. Please refer to the identify origin calibration situation and practice table above for the position calibration or calibration button selection.
 - Positioning calibration method: After pressing the [Positioning calibration Zero Position] button, the following figure will appear; perform return to default origin position and then press the [Yes] button to confirm the execution, or press the [No]



button to cancel execution. Press [Yes] to complete the origin position setting for the first axis; the adjustment method for this origin position is based on the origin set by the manufacturer and performing angle conversion. The angle at this time will be closer to the calibration position; for example, the first axis of RS405-400-200-LU should be close to 0 degrees.



[Zero Position] reset interface

(2) Calibration method: After pressing the [Calibration] button, perform modification to the manufacturer's origin position and a message window will pop up, saying "You want to calibrate Joint1", and at the bottom of the text, it shows whether to agree to execute the item, as shown in the figure below. Agree must be selected and check the field, then can the [OK] button be pressed. This adjustment method of the origin position saves the robot's current encoder value, and modifies the origin position set by the manufacturer. The [Cancel] button cancels the execution.



[Calibration] reset interface

Step4 : After software the position is determined, remove the calibration tool.





Illustration of first-axis mastering figure

Setting origin of Second-axis Step:

- Step1 : Press the emergency stop button and push the B arm with your hand until the B arm matches the calibration hole of the A arm.
- Step2 : Use the calibration tool (ψ 4 bar) and insert it into the calibration hole from bottom to top; if the bar could not be inserted, use the jog screen to slowly adjust the angle until the calibration tool can be inserted into the calibration hole, and make the adjustment marks overlap. This completes the adjustment of the hardware mechanism's origin.
- Step 3: For the software origin calibration method, please refer to the origin setting method for the first axis; click [Reset J2], setting origin.
- Step 4: After the software position is determined, remove the calibration tool.



Illustration of Second-axis mastering figure



Setting origin of third-axis & fourth-axis:

- Step1. Confirm that the distance between the stop ring and the spline is 30mm, as shown below \circ
- Step2. After pressing the emergency stop button, hold the brake release button and push the spline by hand until the stop ring contacts the body of the robot arm.
- Step3. Turn the spline by hand until the upper surface of the spline is facing directly in front of the B arm, and release the brake release button.
- Step4. Make sure that the stop ring is in contact with the body of the robot arm, and the upper surface of the spline is facing directly in front of the B arm.
- Step5. Through the software, software calibration refers to the first home position way, after executing origin calibration for the third axis, at this time, the position for the third axis of RS405 will be recorded as +10.9mm, and the position of RS410 will be recorded as +10mm (please note that after calibrating the origin during the initial setting of the software, it will no longer be displayed as 0mm).

Model	RS405	RS410
J3 axis after calibration software display position(mm)	+10.9	+10

Step6.Through the software, select the axis 4 and set the origin position. (software calibrate refer to the first home position way)

Step7.Press the brake release button again and push the spline down about 50mm.



Illustration of third-axis & fourth-axis mastering figure



A WARNING

Please read the warning notes before performing the calibration: Four-axis robot:

When performing motor calibration for the third axis, operators must confirm whether the motor angle of the fourth axis is 0° and the encoder value must be in the odd turn at first; if not, motor calibration must be performed for the fourth axis first.

Note: Performing this operation will lose the origin position originally set for the robot by the manufacturer; improper operations may cause errors to the positions of the corresponding surrounding points and deviation to the absolute accuracy!

After calibration is completed, press the Home button and confirm whether the angle is correct. If the actual position of the robot is different from the drawing , please confirm whether the various axes have returned to their default mechanical origins and completed calibration.

3.Interface Operation Setting

3.1 Remote Operation Interface of software

3.1.1 Remote Operation Setting



Remote Operation Interface

No	Function Name	Description	
1	Connect Menu	Add robot and close all robot connections.	
2	Language Change	Change language to English, Traditional Chinese and Simplified Chinese.	
3	Connect Function	Close All connection.	
4	About	Display the version of HRSS and robot type. Update HRSS software. IF connect to Robot, will display HRSS Vision.	
5	Operation Mode Area	Connection Permission and operation mode setting. Change manual and automation mode.	
6	Velocity Ratio	Display by the program to change the ratio.	
7	Tool and Base Setting	Display the selected tool and base number. Click to change the tool and base number.	
8	Payload	RS405 and RS410 is supported to set acceleration time (ms).	
9	System Function	Update software Save and load database and password Setting.	
10	Program Execution Buttons	The buttons are used for start, pause and stop the program. Hold home button to return the robot to the home position. Click motion button to next step.	



11	Step Motion	Change step motion and continue motion.
12	Teach button	Display/undisplay teach of operation window.
13	3D Simulation	Display/undisplay 3D simulation of robot.
14	Program Editor	Edit robot program window.
15	Status Bar	Display driver and interpreter status
16	Battery Figure	Display the status of absolute encoder's battery.
17	Program List	Program files on robot controller and local computer
18	Function Page	Switch the setting function
19	Execution State Bar	Execution state and alarm display.

3.1.1.1 Connection Operator Step Description

Operation Steps

1. Wait for controller power switch is on and startup finish. (The robot's LED light is flashing.)

- 2.Press "Add Robot" and choose a network card to detect robots.
- 3. Select to connect robot IP and Type, press "Connect" button.

Robot List			
ID	IP	Туре	Version
RCA00000000	10.177.36.36	RA610_1876	3.3.3_6128
SDK Google Test - #2	10.177.36.94	RS405_500_400	3.3.1a_6566
sdfsassss	10.177.36.96	RS405_400_200	3.3.1a_6600
vc.lin.410	10.177.36.34	RS410_600_200	3.3.1a_6597
Device IP 10 .177	. 36 . 36	Network Card Z	大網路 2(10.177.36.96) 🗸 [

Connection Interface

Description

1. The default IP is 192.168.0.3 on RC4 robot controller.

2.If failed to detect robot, please check the internet connection to see if it is connected properly.



3.1.1.2 Change local PC of IP

Operation Steps

1.Select "Change IP" button $\,\circ\,$

2.Go to Change local IP interface and Setting IP $\,\circ\,$

	Network Card 乙太網路 2(10.177.36.96) V LET Cancel Change IP	
	Change Local IP x	l
1-	——Network Card : 乙太網路 2	
2-	Type O DHCP Static 	
3-	IP Addres 192.168.0.100 Set Cancel	
	4 5	

Change local IP Interface

No.	Name	Description	
1	Network Card name	Select network card name	
2	Change Connect Type	IP Change Connect to DHCP/Static Type	
3	IP Address	Want to Change IP Address \circ	
4	Setting	Enter in parameters and save setting.	
5	Cancel	Cancel setting, and close the window.	



3.1.2 Language Setting

Description

Setting remote operation robot software of language.

The interface enables five different languages to be selected for the setting: English(en-US),

Traditional Chinese(zh-TW), Simplified Chinese(zh-CN), Japanese(ja-JP), and Korean(ko_KR).

When setting is completed, Software will close the interface and restart Caterpillar software. The change language is successful $\,^\circ$

🔗 Caterpillar 1.1.0.82	290		
Add Robot	Languages	Close All	About
	English		
RCA00000000 x	Chinese(繁體中文)		
	Chinese	(简体中文)	
Start	Japanes	e(日本語)	🕨 Step
Robot Setting	Korean(한국어)	ditor
KODOL Setting			ultor

語言切換設定

ltem	Description
English	English. (en-US)
Chinese(繁體中文)	Traditional Chinese.(zh-TW)
Chinese(繁体中文)	Simplified Chinese.(zh-CN)
Japanese(日本語)	Japanese(ja-JP)
Korean(한국어)	Korean(ko_KR)

3.1.3 Export system reports

Description

When errors occur on the software system, please use the "System report" button to backup the current logbook of the errors (compressed Zip file). Then send this compressed file back to the manufacturing engineers; the engineers can analyze the cause of the system faults from this file.

Instructions

- 1. Click the "System Report" button on left side of the system interface as shown below.
- 2. A file window will pop up; select the storage path and then click the "Save" button.



System	
Update	
Save Database	
Load Database	
Import Comment	
Set password	
Shutdown	
System Report	



₽ 另存新檔			×
○○○ □ 桌面 →		▼ f	٩
組合管理 ▼ 新増資料夾			0
	 ▲ 名稿 ▲ 名稿 ▲ 保護 ● 陳英雄-上級科技 ● 電腦 ● 202104更新會網手冊 ● H11 ● HSS 3.2.15.5045_G8 offline ● 年度資料 ● 目主協憲表 ● 佩服校績完成 ● 符合北企畫-佩羅塞枝 ● 評畫核文件 		* = · · ·
 ● 陽藏資料夾 		存檔(S) 取消	

Saving the system logbook window



3.1.4 Status Bar Display Description



HRSS tatus Block of Driver

Figure	Color	Description
1	Green	Driver ready
0	Gray	Driver not ready

HRSS status Block of execution

Figure	Color	Description
R	Orange	Interpreter running
R	Gray	Interpreter failure or stop



RCA000000000 x					
Start	Pause	Stop	F Home	Step	¢

Program operation control buttons description.

Figure	Description
Start	Start program. Press F5
Pause	Pause program. Press F6
Stop	Stop program. Press F7
F Home	Return to origin.
Step	Step execution.
\$	Program cycle/step execution switch button.

3.1.5 Connection Level and Change Operation Mode

■There are two connection levels: Controller and Monitor. If the Controller's level is green level color, and monitor's level is blue level color

Single connection with controller level is allowed on a robot.

The default connection level is Monitor.



Operator mode interface



Å WARNING

Don't modify the operation mode during programming period. If it is changed, the robot will stop.

<u>Prerequisite</u>

1. The controller doesn't process any program.

Operation Steps

1.Select operation mode , If switch operation mode is needed, enter password ("HIWIN") and login. Default password is allowed to modify by user self-defined.

Log in	2
ID : RCA000000000	
****	Enter

Login Window

2.Select the operation mode have Manual or Auto mode, change mode don't need key in password.

3. When operation mode on the Manual mode, select program to run. Choose running velocity if Manual is selected. There are Testing Speed and Normal Speed.

Permission	Permission
Permission O Monitor O Controller	Permission O Monitor O Controller
Mode	Mode
Manual O Auto	O Manual Auto

Change operation mode interface

Mode	Application	Running Velocity	JOG Velocity	
		Safety Speed:		
Manual	Use for test operation,	maximum 250 mm/s	Maximum 250 mm/a	
wanuai	programming and teaching	Normal Speed:	Waximum 250 mm/s	
		maximum 2000 mm/s		
Auto	Used for the robot with the higher-		Unavailabla	
Auto	level controllers (For example, PLC)	maximum 2000 mm/s	Unavallable	



		_
Choose Velocity	x	l
Which speed to Test your pro	gram ?	
Safety Speed (T1)	Normal Speed (T2)	

Choose Running Velocity Window

3.1.5.1 Change password

Instructions: -

- 1. Connect the robot at first.
- 2. Click Set password button in the left side of "System" interface.

Update	
Save Database	
Load Database	
Set password	
Shutdown	

System Interface



Setting passwo	ord	x
	Change password	
ß	Reset password	

Change password window

- 3. Click change password to change the operation password.
- 4. If users forgot the operation password; click Reset password to restore the factory password.
 - 3.1.5.2 Changing operation password

Instructions

1.Select Change password.

2.Users must enter the original password at first, and then enter the new password, confirm the new password, and press OK to set the password.

3.Selecting Cancel will return to the previous Set custom password screen.

When the incorrect password is entered or the new password and check new password does not

match, a prompt window will say failed. When it is match, a prompt window will say password changed successfully.

Setting password	×
Old password	****
New password	****
Check new password	жжж
OK	Cancel

Reset password window

3.1.5.3 Restoring operation password

Instructions

1. Select Reset password.

2. Users must call customer service and provide the Mac serial number (displayed in About section) and the year and month of the robot.



3. Customer service will provide a set of Reset key for the user to enter; setting successful will appear if entered correctly, otherwise setting failed will appear.

Setting password	x
Reset key	****
	ရန္ Cancel

Restoring operation password page

3.1.6 Tab display function description

3.1.6.1 Actual Position Display

Operation steps:

1.Click the operating tab of [Position] •

Description:

Display the motor position, the axis and the Cartesian coordinate of current base.

If the 6-axis robot is operated, 6-axis information will be displayed.

If the 4-axis robot is operated, 4-axis information will be displayed.

If the soft limit function is enabled, the limit value on the interface will be updated according to the user setting.

Only when the soft limit function is enabled for the Cartesian coordinates will the upper and lower limit values of the Cartesian coordinates be displayed.

Refer to Chapter 3.6.8: Soft limit function.





Actual Position Interface

No.	Description
1	Lower limit value on the axis
2	Home point position.
3	Upper limit value on the axis

3.1.6.2 Real-time update of the current position



Click the left mouse button on the label of each tab to update the current axis coordinates, Cartesian coordinates and motor encoder information under the Position page in real-time.





The axis coordinates bar will turn red if it reaches ±10 degrees/ ±10mm of the maximum reach.





3.1.6.3 Display Point Page

If there is the need to change point coordinates, click on the Cartesian coordinates and modify the values directly; the values of the axis coordinates on the point list will be updated synchronously. If the modified coordinates are connected with external axes, the external axes coordinates will also be updated synchronously.

Operation steps:

■Click the operating tab of [Point].

Description:

sition Point	Counter 1/0	Fieldb	us Alarm	Tracking	Mastering	Calibration	LogBook N	etwork Config	Home Set	ing Time Se	etting RS-232	2							
Add	Delete	C	Overwrite		PTP	LIN	4			(Commer	nt	Axis	Cartes	ian	ToolBase			
IAME 🔺	COMMENT	,-A1	A2	A3	A4	A5	A6	x	Y	Z	A	В	с	E1	E2	E3	TOOL	BASE	ElMode
PO		-3.468	-0.114	0.114	0.000	-90.000	-3.468	22.300	368.000	293.500	180.000	0.000	90.000	0.000	0.000	0.000	0	0	
P1	{	0.000	0.000	0.000	0.000	-90.000	0.000	0.000	368.000	293.500	-180.000	0.000	90.000	0.000	0.000	0.000	0	0	
P10		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P11		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P12		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P13		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P2		0.000	0.000	0.000	0.000	-90.000	0.000	0.000	368.000	293.500	-180.000	0.000	90.000	0.000	0.000	0.000	1	1	NULL
P3		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P4		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P5		-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P6	1	-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P7	1	-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
P8	1	-50.827	-43.785	59.941	0.000	-106.155	-50.822	448.706	365.594	291.428	179.999	0.000	89.994	0.000	0.000	0.000	1	1	NULL
		1						and the second					la serie de la compañía de la						2

Point interface

No.	Description
1	Point name.
2	Point comment. (It can be modified.)
	Information for points, includes angle of each axis
3	(A1~A6), Cartesian coordinates (X,Y,Z,A,B,C), and number of
	Tool/Base used.
4	Add a new point with the current information.
5	Delete a selected point.
6	Overwrite a selected point.
7	Move to selected point by PTP.
8	Move to selected point by LINE.
9	Adjust the data arrangement.

Description of adjusting arrangement of data:

Press the button will hide the corresponding point information, and then display it in the order of clicking.



3.1.6.4 Display Counter Variable Page

Operation steps:

Click the operating tab of [Counter].

Description:

	(1)				3			
Posit	ion P	oint Cour	nter	I/O	Fieldbu	is Alarm	Mastering	Calibrati
	NO.	. Value			Name			
	1	877	do					
•	2	4120						
	3	-520						
	4	87	catc	h			-	
	5	1000						
	6	0						
	7	0						
	8	0					-	
	9	0					-	
	10	0					-	
-	11	0					-	
	12	0					-	
	13	0						
	14	0	fhfgl	h				
	15	0						
	16	0						
	17	0						

Counter interface

No.	Description
1	Counter No.
2	Counter value.(Double click to modify.)
3	Counter name.(Double click to modify.)



3.1.6.5 Display Timer Variable Page

Operating steps

Click the function tab [Timer].

Description

osition	Point	I/O	Timer	Counter	Alarm	LogBo
NO.	Status	Value[ms]		Name	e	
1	Off	0				
2	Off	0				
3	Off	0				
4	Off	0				
5	Off	0				
6	Off	0				
7	Off	0				
8	Off	0				
9	Off	0				
10	Off	0				
11	Off	0				
12	Off	0				
13	Off	0				
14	Off	0				
15	Off	0				
16	Off	0				
		7				

Timer interface

No.	Description
1	Timer number
2	Timer state
3	Timer value (Double click to modify.)
4	Timer name (Double click to modify.)



3.1.6.6 Display Alarm Page

Operating steps

Click the function tab [Alarm] •

Description



Alarm interface

If the alarm sounds, the alarm information will be displayed permanently on the status bar until it is cleared, as shown in the below figure:

🧬 Caterpillar 1.0.5		- 🗆 ×
Add Robot Languages Close	All About 2020	/06/04 15:01:30
RCA000000000 x		
▶ Start 📔 Pause 🔳 S	op 🗗 Home 🕞 Step 🚺 JOG Display	I R
Robot Setting	Robot Editor	Robot List
Permission ^	i Di ga ga E So Q. 25 (20 ga	
Permission Monitor © Controller Mode Manual © Auto	OFF OFF <thoff< th=""> <thoff< th=""> <thoff< th=""></thoff<></thoff<></thoff<>	Common Co
	11 12	✓ ✓ Tethl(✓ < >
	Position Point VO Timer Counter Alarm LogBook Communication Start Up	Fieldbus Tracking Display
Tool/Base	Base DI DI SIM DI Value DI Comment	~
Tool: 0 ~ Base: 0 ~	Df1 □ Off D2 □ Off 03 □ Off 04 □ Off	
Payload Mass (Kg) 1	05 00ff 06 00ff 07 00ff 08 00ff	×
	02-01-10 Emergency input - (0)	Check Fault

Click "Check" Button , change to "Alarm" tab:



🧈 Caterpillar 1.0.5			- 🗆 X
Add Robot Languages Close All	About	2020/06/04 15	5:03:12
RCA000000000 x			
Start II Pause Stop	€ Home ► Step	JOG Display	I R
Robot Setting R	Robot Editor		Robot List
Permission ^			C RSR - MI5
Permission Mode Mode Mode Seeed 10 < > p	2 F/F FORT Solve Velation 3 F/F FIC Solve Solve	Altern LogBesk Communication Start Up Accellink TOOL(0) BAst (0) Start (0) Start Accellink TOOL(0) BAst (1) Maccellink TOOL(0) BAst (1) Start (1) DBAst (1) BAst (1) BAst (1) BAst (1) DBA Accellink TOOL(0) BASt (1) BAst (1) DBA Accellink TOOL(0) BASt (1) BAst (2)	Controller Contro
Tool/Base	Clear		
Tool: 0 2 Base: 0 - Mass (Kg) - -	Uate Ime Error Code 2020/06/04 14:59:21 02:01-10	Descryton Emergency input - (0)	
	02-01-10 Emergency in	put - (0) Check	Fault



3.1.6.7 Display LogBook and Zero Position History Message

Operating steps

Click the function tab [LogBook] •

Description

Record alarm occurrences and events.





LogBook interface

LogBook description table

No.	name	Description
1	Alarm type of record	Displays error and event record lists that includes information such as
L L	button	the time, error code and error description.
2	Origin calibration type	Displays the mechanism origin adjustment record list that includes
2	record button	information such as time, error code and error description.
		Can Download the record file. This record file will be exported as a
2	Export record button	compressed file. Entire history records can be viewed from this file.
5	Export record button	The related files can be sent back to the technical staff of the
		manufacturer for troubleshooting purpose.
		Refreshes and send the list of information from controller terminal's
4	Reset button	to the local terminal. The last updated time will be displayed on the
		screen.
F	Display error list	Records list; the errors details will be displayed.
5	window	E.g Home calibration (ZeroPosition).



3.1.7 Update Controller of HRSS Software Version

Description

Users can download the HRSS and Caterpillar software update files at the same time from the official HIWIN website, and operate update in Caterpillar interface.

Operation steps

1.Connect to the official website of HIWIN (www.hiwin.tw)

2.On the web page select: Support>Multi axis Robot>SCARA.

HIWIN.	SUPPORT	Solution				l
ABOUT HIWIN	Ballscrew Linear Guideway	Multi-Axis Robot ·	End Effector			
PRODUCTS	Single-Axis Robot	Articulated Rob	ot			
SUPPORT	Multi-Axis Robot 🔹					
INVESTOR AREA	End Effector	RA605-710-GC	RA605-909-GC	RT605-710-GB	RT605-909-GB	RA610-1355-GC
CONTACT HIWIN Bao Bao	Datorker Robot Reducer	RA610-1476-GC	RA610-1672-GC	RA610-1869-GC	RA620-1621	RA620-1739
LINKS	Bearings					
	Torque Motor Rotary Table	Delta Robot	PD402 1100 PD	C.P.		
Search Q	Product patent list	Scara Robot RS405-LU Standar	d RS405-LU Pro	tection RS410-LI	U Standard RS	410-LU Protection
		Wafer Robot				
		RWS RWD				
		Software				
		Functional Suppor	t Software GitH	ub HIWIN ROS Down	load ROS on V	Vindows Case Study
		OTHERS				
		OTHERSDownlaod	I			

official website of HIWIN figure

- Choose robot type, enter the website.
- Download Caterpillar and HRSS update file.

Software		
Remote Operating Interface Software	Caterpillar 1.1.1	٩
HIWIN Robot System Software	HRSS 3.3.18 x86 offline	٨
Please decompress the offline file to CA, then set the screen resoluti [Software requirements: Redistributable Packages for Visual Studio	ion over then 1360x768. 2013 download]	
HIWIN Robot System SoftwareUpdate File	HRSS 3.3.18 x64 update	٨

Download update file



After download file, then zip the file.

下載 🕨 Caterpillar_1.0.3.6133 🕨 Caterpillar 🕨			▼ ∳ 搜尋 Caterpillar	Q
			8= - [1 0
▲ 名稱 ^^	修改日期	領型 大小		
\mu Caterpilar_6133	2020/3/27 上午 11:46	留案資料夾		
HRSS_6128	2020/3/27 上午 11:46	冒案資料夾		
📔 Redistributable	2020/3/27 上午 11:46	富案資料夾		
ReadMe.docx	2019/12/31 下午 03:55	Vicrosoft Word 203	KB	
E				

■Read "ReadMe" document. This folder includes a new version of the HRSS update file and Caterpillar.

■Click left side "System" Interface, Update button.

٥	System	
	Update	6
	Save Database	
	Load Database	
	Import Comment	
	Set password	
	Shutdown	
	System Report	

Update HRSS button

Choose HRSS updatefile (.exe), to do update.

下載 , Caterpill	ar_1.	0.3.6133 🕨 Caterpillar	HRSS_6128		•	€		٩
共用對象 ▼	新	増資料夾					• ==	0
ſ	^	名稱		修改日期	類型	大小		
		HRSS 3.3.3.6128	4_update.exe	2020/2/19 上午 09:32	應用程式	46,950 KB		

Choose HRSS update file figure



Update HRSS	×
Update file	Browse
HRSS 3.3.3.6128_x64_update.exe	
Update	Cancel



🔔 CAUTION

- 1. The software update package contains HRSS and Caterpillar. The two versions are dependent and must be downloaded at the same time and updated together.
- 2. Update the HRSS before you can use the new Caterpillar.
- Before updating the software, please check current software version, for example: HRSS
 3.2.1.2673, please download version with same two number at the front, e.g. HRSS 3.2.2.2775
 or HRSS 3.2.4.2925. Do not download version that has two different number at the front, e.g.
 HRSS 3.3.x.x to avoid incompatible.
- 4. Download the Caterpillar update package with the HRSS update file.
- 5. Open the old version of Caterpillar, update the controller software after connecting the robot. Press Update button in the lower left corner, and select the HRSS update package .exe file to do update procedure. (It will be disconnected after the update)
- 6. Copy the .hrb files from the old Caterpillar directory to the new one.
- 7. Open the new Caterpillar and connect the robot (Do not use the old version of Caterpillar to connect the robot after updating the controller software.)

3.1.8 Saving and reading of database

Description

Saves and reads the contents of the database; the extension of database files is .db files. The recorded contents in the database the tool/base coordinate systems, comment of the I/O window (DI/O, RI/O, MI/O, SI/O), comment of the counter register, comment of the position register, setting information of the network connection interface and the setting information of the RS-232 communication interface. There are three options for the database: Save Database, Load Database and Import Comment.



System	
Update	
Save Database	
Load Database	
Import Comment	
Set password	
Shutdown	
System Report	

Save Database, Load Database and Import Comment interfaces

Description of Save Database:

Description

Save Database is used to backup the database file (.db) of the controller terminal. If there is a need to restore database settings, it can be done through the Load Database function.

Operation steps

1. Click the Save Database button on the left side interface of System.

2.A save window will pop up; select the storage path and then click the "Save" button.

Description of Load Database:

Description

Load (restore) the database to overwrite the database file (.db) of the controller terminal, replacing the contents of the existing database.

(The name of the database file must be "Custom.db", otherwise it could not load successfully).

! CAUTION

The restoring data & the robot where you would like to load this restoring data must have the same robot model and software version. If you load other database files, the following results may occur:

- 1. Wrong information.
- 2. Robot controller cannot operate.
- 3. Personal injuries and property loss.

Operation steps

1. Click the Load Database button on the left interface of the SYSTEM.

2.A load data window will pop up; after selecting the load path file (.db), press the "Open" button.



3. The power of the controller must be restarted. Only by the restarting; the loading data will become effective.

■ Import comment: This is only applicable to Caterpillar version 1.1.0 and above

Description

Import comment is importing the text comments of the controller terminal from the database file (.db), overwriting the contents of existing text comments. Users can choose the option to overwrite manually to perform either a single or multiple import operations.

Users can backup the comment files when they want to import them into the different robots.

⇒ Usage scenarios:

After editing the comments offline, first export them into files through Caterpillar, and then import them into the robot to complete related comments and supplements.



Operating steps

1. Click the Import Comment button under System on the left interface.

A load data window will pop up; after selecting the database file (.db) to import, press the "Open" button.

2.Below shown Check options window will pop up for the selected database to import; tick the required data base items of the to import, multiple choices can be made. Take the below figure below for example. The Tool and Base databases are ticked simultaneously for import operation. (If Sel. on top of the window is checked, all options will either be checked likewise unchecked).

			×	
Sel.	Commer	nt		
	Digital I/)		
	Robot I/C)		
	Module I.	ю		
	Field bus l	Fieldbus I/O		
	Fieldbus Register			
	Position Register			
	Counter			
Timer				
🔽 Tool				
☑ Base				
ОК		Ca	incel	

Import comment selection window

3.Click "OK" button to confirm. The saved database will be imported into the control system of the robot; click the "Clear" button to return to the Load Database screen. Press the "Yes" button for a overwriting message, and confirm that the database text comment is displayed in the window (no need to restart); please note that the existing text comment will be overwritten.



Import Comment overwrite confirmation window



3.1.9 About Robot information display window

Description

Displays the version and model number information of the robot currently connected; it is used for confirming robot information. Take the figure below for example: The model number of the robot is RS405-500-200-LU, the HRSS software version is 3.3.18_8699, the version of the Caterpillar software with the opened remote connection version is 1.1.1_8696. <u>Operation steps</u>

View the [About] page above the remote interface software.

About			
•	Caterpillar: connection Ver: HRSS: connection Ver: Robot Type: Robot ID: RBT: Rtdll: Hrc: EGdll:	1.1.1.8696 1.1,8696 3.3.18_8699 1.1.8699 RS410-600-400-LU RCA00000000 1.3.37.8695 1.0.2.2705D offline 8080 1.1.1.823 OK]

[About] page robot infromation figure



3.2 Coordinate System

Define following Cartesian coordinate system in robot controller system:

- **ROBOT**
- BASE
- TOOL



Coordinate System Overview

Description

ROBOT

The Robot used the Cartesian coordinate system. If it is a 6 axes robot, it will be fixed at the location of the 1st-axis center point and the 2nd-axis center point of the robot. If it is a 4 axes robot, it will be fixed at the robotic foot. This is used as the origin coordinate system of the base coordinate system.

In the default configuration, the coordinate system of ROBOT is consistent with the BASE coordinate system.

BASE

The BASE Coordinate System is Cartesian system used to describe the position of the workpiece. It is based on the ROBOT Coordinate System. By default, the Base Coordinate System is consistent with the ROBOT system. A user can move it to the workpiece.


T00L

The TOOL Coordinate System is a Cartesian system, located at the tool center point.

By default, the home of the Tool Coordinate System is located at the flange center point (called the Flange Coordinate System). The Tool Coordinate System is offset to the tool center point by the user.

Rotation of the six-axis robot coordinate system

Corner	Rotation around axis				
А	Rotate around X axis				
В	Rotate around Y axis				
С	Rotate around Z axis				

Rotation of scara robot coordinate system

Corner	Rotation around axis					
A4	Rotate around Z axis					



3.3 JOG Robot

Description:

There are two types of jogging:

- Cartesian jogging, TCP (Tool Center Point) is jogged in the positive or negative direction along an axis of the coordinate system.
- Axis-specific jogging, each axis can independently be moved in a positive or negative direction.



3.3.1 Manual JOG

Prerequisite:

- 1.Connection level need to be Controller.
- 2.Mode needs to be Manual.

Description:

When connection level is controller and mode is manual, you could jog on TP (Teach Pendant) window.



	RCA0000000	00	-	
	D JOINT	XYZ	TOOL	Hotkey
	A1–	0.000 Go	A1+	○ Enable
	A2-	0.000 Go	A2+	O Enable
	A3-	0.000 Go	A3+	○ Enable
	A4-	0.000 Go	A4+	○ Enable
	Туре	Absolute	~	
Start Pause Stop Home JOG	Speed	10 <	>	

TP Window



教導調節視窗

Figure	Coordinates switching shortcuts
	Press Ctrl+Z to switch into the joint coordinates.
XYZ	Press Ctrl+X to switch into the Cartesian coordinates.
TOOL	Press Ctrl+C to switch into the tool coordinates

Figure	Axis switching shortcuts
Hotkey	Press Ctrl+1 to switch into the first axis.
\bigcirc Enable	
O Enable	Press Ctrl+2 to switch into the second axis.
O Enable	Press Ctrl+3 to switch into the third axis.
○ Enable	Press Ctrl+4 to switch into the fourth axis.

Figure	Operation shortcuts					
	Press Ctrl + \rightarrow to move the selected axis in the positive direction.					
	Press Ctrl + \leftarrow to move the selected axis in the negative direction.					



RCA0000000	00	_	\sim
TEJOL	xyz	TOOL	Hotkey
A1-	0.000 Go	A1+	○ Enable
A2-	0.000 Go	A2+	○ Enable
A3-	0.000 Go	A3+	○ Enable
A4-	0.000 Go	A4+	○ Enable
Туре	Absolute	~	
Speed	10 <	>	



3.3.2 Robot Simulation interface

Operating steps

Click the function tab [Display].

Description

Display the robot simulation figure.

1.Shift : Press the middle wheel of mouse to move.

2.Zoom In/Out: Scroll the middle wheel of mouse.

3.Rotation: Press 'shift' and scroll the middle wheel of mouse.

RCA00000000 x				1			
▶ Start	p F Home	JOG	Display		0	R	Ĩ
Robot Setting	Robot Editor				Robot I	_ist	

Display robot simulation button figure

Hide robot simulation interface, and display robot simulation interface, use "Display" button to change the Hide/Display state.





Hide robot simulation button figure



robot simulation button figure



1. Shift : Press the middle wheel of mouse to move.



Panning figure

2. Zoom In/Out: Scroll the middle wheel of mouse.



Zoom In/Out figure Rotation: Press 'shift' and scroll the middle wheel of mouse.





Rotation interface

3.3.3 Base/Tool Coordinate

Description:

View and modify the base or tool coordinate.

16 tool and 32 base coordinate systems can be saved in the control system at most. When you apply the Cartesian jogging, you must select a tool (Tool Coordinate System) and a base (Base Coordinate System).

Tool/Base	Tool: Edit
Tool: Edit	Base: Edit
Base:	Payload 2
Payload 5 6	Mass (Kg) 7 Mass (Kg) 6 5 5 5 5 5 5 5 5 5
7 Mass (Kg) 8 9 10 11	8 9 10 11 12
System 13 14 15	13 Up¢15 16
Update	Save D:17 18
Save Database	Load D. 20 21
Load Database	Shut(22 23
Shutdown	24 25 26
	27

Base/Tool interface





SCARA Robot Base/Tool calibration interface

No.	Description				
1	Base/Tool coordinate currently selected.				
2	The current position is selected as the calibration point.				
3	The current calibration canceled.				
4	Enter calculations manually.				
5	The information of calibration point.				

3.3.4 Jogging Velocity Ratio

Description:

The jogging velocity ratio is robot velocity during jogging. It's presented by percentage, based on the maximum velocity when the robot is jogging. That value is 250 mm/s \circ

٥	Spe	ed			
	_				
10	<			>	

Velocity Ratio Interface

3.4 Input/Output(I/O) Setting

3.4.1 Display Digital Input/Output

Operation steps:

1.Click the operating tab of [I/O].

2.Click the [I/O] tab of [DI/O].



Description:

Position	Point	1/0	Tir	ner	Counter	Alarm	LogBook	Communication	Start U
-DI	DO	SI/O	FI	0	PNS	DIO Sett	ing		
Base	Device 1								
DI	DI SIM	DI Val	ûe		DI Co	mment			
D149			n	lkfjdgl	fdggl				
D150			n	2					
DI51			n	2					
D152			ff	3					
D153			ff	3					
DI54			ff	誰					
D155			ff	2					
D156			ff	2					

Digital Input Interface

No.	Description									
1	Switch I/O page.									
2	Switch Basic DI (48) and external DI page.									
3	Simulation. opened as red.									
	Digital Input value. (It can be used when the simulation is selected.)									
4	ON is displayed red and showed On.									
	OFF is displayed white and showed Off.									
5	Digital Input Comment. (Double click to modify.)									





Digital Output Interface

No.	Description								
1	Switch I/O page.								
2	Switch Basic DO and external DO page.								
	Digital Output value. (It can be used when the simulation is								
2	selected.)								
5	ON is displayed red and showed On.								
	OFF is displayed white and showed Off.								
4	Digital Output Comment. (Double click to modify.)								



3.4.2 Self-defined Digital Input/Output Function

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Mastering
DI	DO	SI/O	FIO	PNS	DIO Setti	ng						
Digit Cl EX EX Sł Sł	al Input ear Error M ternal Alar N Now Text rstem Shuto	m Use down	DI[10] Disable r Define Alar Disable	~ m		Digi M Sy C M	tal Output totor Warning DO ~ ystem Start Up DO ~ tode Output DO ~	DO[10] Disable	•	Reset DO Emer DO Reset DO	: Driver gency Ou : Safety Ri	 Disable Disable Disable Disable Disable
												Save

3.4.2.1 Clear Error Input Signal

Description

User can select the specific D.I./ S.I. to trigger the error clear function.

Operating steps

- Select the specific D.I. / S.I from the Clear Error option, it will be enabled to use as the functional signal of clearing error through the configured D.I. ./ S.I
- If Disable is selected, it indicates that this function is disabled.
- Press [Save] to save the setting.

3.4.2.2 External Alarm Input Signal

Description

User can select the specific D.I. /S.I to trigger the external alarm function.

Operation steps:

- 1. Select the specific D.I. /S.I from the External Alarm option, it will enable to use as the functional signal of external alarm through the configured D.I. /S.I..
- 2. If Disable is selected, it indicates that this function is disabled.
- 3. Set the word to be appeared in Show Text when the alarm is triggered.
- 4. Press [Save] to save the setting.

3.4.2.3 External Shutdown Input Signal

Description

User can select the specific D.I. /S.I. to trigger the external shutdown function.

Operation steps:



- 1. Select the specific D.I. /S.I.from the System Shutdown option, it will enable to use as the functional signal of system shutdown through the configured D.I. /S.I..
- 2. If Disable is selected, it indicates that this function is disabled.
- 3. Press [Save] to save the setting.

3.4.2.4 Motor Warning Output Signal

Description

User can select the specific D.O. / S.O. to trigger the motor warning function.

Operation steps:

- 1. Select the specific D.O. / S.O. from the Motor Warning option, it will enable to use as the functional signal of motor warning through the configured D.O. / S.O..
- 2. If Disable is selected, it indicates that this function is disabled.
- 3. Press [Save] to save the setting.

3.4.2.5 System Start Up Output Signal

Description

User can select the specific D.O. / S.O. to trigger the system start up function.

Operation steps:

- 1. Select the specific D.O. / S.O. from the System Start Up option, it will enable to use as the functional signal of starting up through the configured D.O. / S.O..
- 2. If Disable is selected, it indicates that this function is disabled.
- 3. Press [Save] to save the setting.

3.4.2.6 Manual/Auto Mode Output Signal

Description

User can select the specific D.O. / S.O. to trigger the mode output function.

Operation steps:

1.Select the specific D.O. / S.O. from the Mode Output option, it will enable to use as the functional signal of mode output through the configured D.O. / S.O. If T1/T2 mode is selected, the specific D.O. / S.O. is OFF. If AUT/EXT mode is selected, the specific D.O. / S.O. is ON. (This function in Caterpillar software only has EXT mode output signal, HRSS software have EXT T1/T2 and AUT/EXT mode output signal)

- 2.If Disable is selected, it indicates that this function is disabled.
- 3.Press [Save] to save the setting.



3.4.2.7 Restart driver signal output

Description

Users can set specific D.O. to trigger the function to restart driver signal output.

Operation steps:

1.Select a specific D.O. in the Reset Driver option to use the configured D.O. to restart the signal outputted by the driver.

2.If Disable is selected, it means do not enable this function.

3. When finished selecting, press [Save] to save.

3.4.2.8 Emergency stop signal output signal

Description

Users can set specific D.O. to trigger the function to output emergency stop signals.

Operation steps:

1.Select a specific D.O. in the Emergency Output option to use the configured D.O. as the signal that the emergency stops outputs.

2.If Disable is selected, it means do not enable this function.

3. When finished selecting, press [Save] to save.

3.4.2.9 Restart safety relay output signal

Description

Users can set specific D.O. to trigger the function to restart safety relay output.

Operation steps:

1.Select a specific D.O. in the Safety Relay option to use the configured D.O. to restart the signal outputted by the safety relay.

2.If Disable is selected, it means do not enable this function.

3. When finished selecting, press [Save] to save.

3.4.3 Display External Functional Input/Output

Operation steps:

1.Click the operating tab of [I/O].

2.Click the [I/O] tab of [FIO].

Description:



Positi	on P	oint	I/O	Time	er 👘	Counter	Alarm	LogBook	Communication	Start U
DI	[00	SI/C	D FIO		PNS	DIO Set	ting		
Cor	nment	Va	lue	Comment	V	/alue				
S	tart		Dff	Run		Off				
H	lold		Dff	Held		Off				
s	ton	Inc)ff	Fault		Off 🗌				
	top		/11			OII				
En	able		Dff	Ready		On				
En	able	Va	Dff	Ready	Progr	On		ACK	ACK Value	
En	able RSR SR1	Val	Dff	Ready unnamed.h	Progr	On		ACK ACK1	ACK Value	
En R	able RSR SR1 SR2		Dff lue Dff Dff	Ready unnamed.h	Prog	On		ACK ACK1 ACK2	ACK Value	
En R R	able RSR SR1 SR2 SR3		Dff lue Dff Dff Dff	Ready unnamed.h	Prog	ram		ACK ACK1 ACK2 ACK3	ACK Value Off Off Off	
En R R R	RSR SR1 SR2 SR3 SR4		Dff Dff Dff Dff Dff Dff Dff	Ready unnamed.h	Prog	ram		ACK ACK1 ACK2 ACK3 ACK4	ACK Value Off Off Off Off Off	

External Functional Input/Output Interface

No.	Description
1	Switch I/O page.
2	Functional Input value.
3	Functional Output value.
4	RSR value.
5	RSR program name.
6	Functional Output ACK1~ACK4 display corresponding signal.

XON is displayed in red and showed On. OFF is displayed in white and showed Off.

When programs are executed, press the pause(Hold) button and the Held light will light up while the Run light is still on.

Comment	Value	Comment	Value
Start	□Off	Run	On
Hold	□Off	Held	On
Stop	□Off	Fault	□Off
Enable	□Off	Ready	On



3.5 Communication Part

3.5.1 TCP/IP Connection

Description

Send and transfer the data by network communication.

You can select RC as Client or Server to connect.

The parameter type is the floating decimal.

The communication format has two parentheses (The type of parenthesis can be selected.), including the value form such "{xxx}" For example, if "{123,456}" is sent, two sets of value "123" and "456" will be received, which there are up to 50 sets of parameters.



TCP/IP interface

No.	Description							
1	Target IP to communicate with.							
2	Port configuration of TCP/IP connection.							
3	Braces / Square brackets / Parenthesis selection.							
4	Separation selection.							
5	Change the robot controller IP.							
6	Connect or Disconnect button.							
7	Message sending field							
8	Send message							
Q	Message box to indicate the content which has been transmitted or							
5	received.							



10	Server/Client configuration of the local robot controller.
11	Display Content of Sending Message and Receiving Message

Operating steps

- 1.Click the function tab [Communication]
- 2.Click the sub tab [TCP/IP] in the [Communication] tab.
- ■Local RC is Client
- 1. Input the Server's IP and Port.
- 2.Click [Connect] button.
- 3."Connection is successful!" means the connection succeeds.
- ■Local RC is Server
- 1.Input the TCP/IP Port to be connected.
- 2.Click [Connect] button.
- 3. "Server is opened!" means the port succeeds in listening.



3.5.2 Set up Robot Controller Ip

Description

Configure the IP address in robot controller.

Users can configure the IP address in each Network Card.

It can be configured as DHCP (automatic obtain IP address) or Static (specify specific IP address) $\,^\circ$



Change IP interface

No.	Description
1	The button to Change Robot Controller IP.
2	Select to change network card
3	Static IP address, specific IP address
4	DHCP / Static IP mode selection
5	Confirm setting
6	Cancel setting



Operating steps

- ■Click the [TCP/IP] sub-tab in the [Communication] tab.
- ■Click Change Robot Controller IP button.
- Select the Network card.
- ■DHCP
- 1.Select [DHCP] item.
- 2.Click the [Set] button.
- 3. Wait for the bar to finish loading, setting is completed.

■Static IP

- 1.Select [Static] item.
- 2.In the [IP Address] column, assign the IP address for robot controller.
- 3.Click the [Set] button.
- 4. Wait for the bar to finish loading, setting is completed.

If setting failed message appeared, please check the internet connection to see if it is connected properly or there is a problem in IP setting.



3.5.3 RS232 Connection

Description

Send and transfer the data by serial communication.

The parameter type is the floating decimal.

The communication format has two parentheses (The type of parenthesis can be selected.), including the value form such "{xxx}" For example, if "{123,456}" is sent, two sets of value "123" and "456" will be received, which there are up to 50 sets of parameters.

Position	Point	I/O	Counter	Alarm	LogBook	Communication	Mastering	Start Up	Fieldbus
TCP/IP	RS-232								
					Me	ssage			d
Rour	Irata	110							
Bauc	rate								
Data	bits	5	~		N	ow RS232	status	s : Di	sconnect
Parit	У	None	~						
Stop	bit	1	~ (8					
Brac	kets	{}	~						
Sepa	ration			Ion Format					
				Connect	1 L				
									Send
				$ \rightarrow $					
				_ `					

RS232 interface

No.	Description							
1	RS232 Baud rate							
2	RS232 Data bit							
3	RS232 Parity							
4	RS232 Stop bit							
5	Braces / Square brackets / Parenthesis selection							
6	Separation selection							
7	Connect / Disconnect button.							
8	Cancel format							
9	Messages to be send							
10	Send message							
11	Display Content of Transmitting Message & Receiving							
11	Message							

Operating steps

Click the [RS-232] sub tab in the [Communication] tab.

1.Input RS232 paramters.

2.Click [Connect] button.

3.Display "Connection is successful!" to represent the connection success.



3.6 Start-up Function

3.6.1 Six Axes Robot Calibrate Tool/Base Coordinate Way

3.6.1.1 Calibrate Tool Coordinate

Description

When the tool is calibrated, the user will give a set of Cartesian Coordinates (Tool Coordinate System) to the tool mounted on the flange. The tool coordinate system has its origin at a user-defined point. This point is called as TCP (Tool Center Point). Usually, TCP is located at the working point of the tool.

! CAUTION

The calibration method described here must not be used to a fixed tool.

Advantage of tool calibration:

- ◆ The tool can rotate along the TCP. The position of TCP will not change.
- ◆ Program running: The track along TCP keeps the programed velocity.

16 tool coordinates can be saved at most. Variable: TOOL [0...15]).

XTOOL [0] is Default and cannot be changed.



3.6.1.2 Four-Point Calibrate Method of Tool Coordination

Description

The TCP of the tool to be calibrated is moved to a reference point from 4 different directions. The reference point can be freely selected. The robot control system calculates the TCP from the different flange positions.

! CAUTION

The four flange positions at the reference point must be sufficiently apart from one another.



Four-point method

<u>Prerequisite</u>

- 1.Manual mode.
- 2.Install the tool to be calibrated on the mounting flange.
- 3. Select a fixed reference point position, it is recommended that this reference point is a shape that is easy to recognize, for example: cuspidal point.

Operation steps

- 1. Select the tool number of [Tool / Base] on the left side of the remote operation interface.
- 2. Select the sub-tab [Calibration] of the function tab [Start Up].
- 3. Click [Tool Calibration].
- 4. Use TCP to move to the configured reference point. To confirm the reference point, click [Measure].
- 5. Use TCP to change the position of the other arm and move to the reference point. If you confirm the reference point position, click [Measure].
- 6. Repeat step 5 twice.



7. After completion, the data shows the new TOOL coordinate system reference position and is saved.



Tool / Base coordinate selection interface

Position	Point	I/O	Count	er Alarm	LogBook	Communic	ation	Mastering	Start Up	Fieldbus	Tracking	
Calibratio	on Home	Setting	Time Settin	ng								
Curro Too	ent Tool I Calibra	: 1 ition		Measure	e Ca	ncel	Ma	inual Co	mputatio	on		
			Г	Name	Х	Y	Z		A	В	С	
_				P1	0.000	368.000	293.5	i00 -18	30.000	0.000	90.000	
	HIWIN			P2	0.000	368.000	293.5	i00 -18	30.000	0.000	90.000	
			P3	0.000	368.000	293.5	i00 -18	30.000	0.000	90.000		
I		4		P4	0.000	368.000	293.5	i00 -18	30.000	0.000	90.000	
				Result								

RA605 robot tool calibration interface



3.6.1.3 Enter Value Way of Tool Coordination

Description

Tool data can be manually entered.

Possible data sources :

- In the CAD diagram file, acquire the size information of tool.
- ■Tool size from the measurement of actual object.
- ■Instruction manual of tool manufacturer.

<u>Prerequisite</u>

- 1. Manual mode.
- 2. Known X, Y, Z, A, B, C distance and orientation data relative to the flange coordinate system.

Operation Steps

- 1. Select the tool number of [Tool / Base] on the left side of the remote operation interface.
 - 2.Click [Edit].
 - 3.Enter the values in the table.
 - Click [√] button after completed. The data will be saved. Click [Clear] botton, it will delete the coordination parameter. ; Click [X] botton , cancel and exit setting interface.



Numerical input interface



3.6.1.4 Calibrate Base Coordination

Description

During base calibration, the user assigns a Cartesian coordinate system (BASE coordinate system) to a work surface or the work piece. The BASE coordinate system has its origin at a user-defined point. Calibrate base coordinate need to priority calibrate the tool coordination, First.

! CAUTION

If a workpiece has been installed on the mounting flange, the calibration described here will not apply.

Advantages of base calibration:

■TCP can be jogged along the work plane or edge of workpiece.

Points can be taught relative to base. If the base must be moved, for example,

because the work plane is moved, the points will be moved as well, and no need to be taught again.

32 base coordinates can be saved at most. Variable: BASE[0...31].

※BASE [0] is Default and cannot be changed.



3.6.1.5 Three-Point Calibrate Method of Base Coordination



Three-Point Calibrate Method

<u>Prerequisite</u>

1.Manual mode.

2.Install a calibrated tool on the mounting flange.

Operation steps

1.Select the base number of [Tools / Base] on the left side of the remote operation interface.

2.Select the sub-tab [Calibration] of the function tab [Start Up].

3.Click Base Calibration •

4. Move TCP to the origin of new base coordinate. Click [Measure].

5. Move TCP to a point on positive X axis of new base coordinate. Click [Measure].

6. Move TCP to a point with positive Y on the XY plane. Click [Measure].

7.After completed. The data will be saved.





Tool / Base selection interface

Position	Po	int I/O	Counter	Alarm	LogBook	Communic	ation N	Mastering	Start Up	Fieldbus	Tracking
Calibration Home Setting		Time Setting	9								
				Measure	e Ca	incel	Mar	nual Co	mputatio	on	
Curr	rent	Base: 1									
				Name	Х	γ	Z		Α	В	С
Bas	se C	alibration		P1	0.000	368.000	293.50	0 -18	80.000	0.000	90.000
				P2	0.000	368.000	293.50	00 -18	80.000	0.000	90.000
		z		P3	0.000	368.000	293.50	00 -18	80.000	0.000	90.000
	Ĺ	47	7	Result							

RA605 robot base calibration interface



3.6.1.6 Enter Value Way of Base Coordination

Description

Known the following values, for example, obtain from CAD:

- Distance between the base origin and global origin
- ■Rotation for base coordinate relative to global coordinate

<u>Prerequisite</u>

1.Manual mode.

2.X, Y, Z, A, B and C relative to the flange coordinate system is known.

Operation steps

1.Select the base number of the remote operation interface vertical [Tool / Base].

- 2.Click [Edit].
- 3.Enter the values in the table.
- 4. Click [✓] button after completed. The data will be saved. Click [Clear] botton, it will delete the coordination parameter. ; Click [X] botton , cancel and exit setting interface.

Edit Base 1							
Х	0						
Y	0						
Z	0						
А	0						
В	0						
С	0						
✓ Clear X							

Numerical input interface



3.6.2 Four Axes Robot Calibrate Tool/Base Coordinate Way

3.6.2.1 Calibrate Tool Coordination

Description

When the tool is calibrated, the user will give a set of Cartesian Coordinates (Tool Coordinate System) to the tool mounted on the flange. The tool coordinate system has its origin at a user-defined point. This point is called as TCP (Tool Center Point). Usually, TCP is located at the working point of the tool.

\rm LAUTION

The calibration method described here must not be used for a fixed tool.

Advantage of tool calibration:

1. The tool can rotate along the TCP. The position of TCP will not change.

2.Program running: The track along TCP keeps the programed velocity.

16 tool coordinates can be saved at most. Variable: TOOL [0...15].

XTOOL [0] is default and cannot be changed. The following data will be saved :

X, Y, Z:

The origin of tool coordinate, relative to flange coordinate

А, В, С:

The rotation of tool coordinate, relative to flange coordinate

- X: X coordinate
- Y: Y coordinate
- Z: Z coordinate
- A: Rotate along X coordinate
- B: Rotate along Y coordinate
- C: Rotate along Z coordinate



Flange coordinates



TCP calibration principle



3.6.2.2 Three-Point Calibrate Method of Tool Coordination

Description

The TCP of the tool to be calibrated is moved to a reference point from 3 different directions. The reference point can be freely selected. The robot control system calculates the TCP from the different flange positions. Achieve the tool coordinates (X, Y, Z, C value, where value of C [J4 rotational angle] is the C value of the first calibrated value).

! CAUTION

The 3 flange positions at the reference point must be sufficiently apart from one another.

<u>Prerequisite</u>

1.Manual mode

2.Install the tool to be calibrated on the mounting flange.

3.Select a fixed reference point position, it is recommended that this reference point is a shape that is easy to recognize, for example: cuspidal point.

Operation steps

1.Select the tool number of [Tool / Base] on the left side of the remote operation interface.

2.Select the sub-tab [Calibration] of the function tab [Start Up].

3. Click [Tool Calibration].

4.Use TCP to move to the configured reference point. Click [Measure] to confirm the first calibration point.

5.Use TCP to replace another posture position of arm, move to the reference point. Click [Measure] to confirm second point [,] if the position of reference point is to be confirmed, please use OK button for confirmation, otherwise, use No or Cancel to cancel the operation.

6.Repeat Step 5 to confirm third point.

7.After completion, the data will show the new TOOL coordinate system reference position and be saved.







Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicatio	n Start Up	Fieldbus	Tracking	D
Calibratio	n Home	Setting	Time Setting	User Alarn	n Setting	Soft Limit	Electric Gripper	Payload	External Axis		
Curro	ent Tool: I Calibrat	1 tion	P C E	Measure Please move Click the Me Enter the cal	C the ende asure but ibration o	ancel effector to t tton to calib data directly	Edit the first point the prate or y.	en			
				Name	х	Y	Z	А	В	С	
$\mathbf{\cap}$			P1								
	-	Î		P2							
		-		P3							
				Result							

SCARA robot tool calibration interface



3.6.2.1 Enter Value Way of Tool Coordination

Description

The tool data can be manually entered.

Possible data source :

- ■In the CAD diagram file, acquire the size information of tool.
- ■Tool size from the measurement of actual object.
- ■Instruction manual of tool manufacturer.

<u>Prerequisite</u>

1.Manual mode

2.Known X, Y, Z, A, B and C relative to flange coordinate

Operating steps

1.Select the tool number of [Tools / Base] on the left side of the remote operation interface.

2.Click [Edit].

3.Enter the values in the table.

4.Click $[\checkmark]$ button after completed. The data will be saved. Click [Clear] botton, it will delete the coordination parameter. ; Click [X] botton , cancel and exit setting interface.

Edit Tool 1						
Х	0					
Y	0					
Z	0					
А	0					
В	0					
С	0					
✓ Clear X						

Numerical input interface



3.6.2.1 Calibrate Base Coordination

<u>Description</u>

During base calibration, the user assigns a Cartesian coordinate system (BASE coordinate system) to a work surface or the work piece. The BASE coordinate system has its origin at a user-defined point. Calibrate base coordinate need to priority calibrate the tool coordination, First.

! CAUTION

If a workpiece has been installed on the mounting flange, the calibration described here will not apply.

Advantages of base calibration:

■TCP can be jogged along the work plane or edge of workpiece.

Points can be taught relative to base. If the base must be moved, for example, because the work plane is moved, the points will be moved as well, and no need to be taught again.
32 base coordinates can be saved at most. Variable: BASE[0...31].

※BASE [0] is default and cannot be changed.



3.6.2.2 Three-Point Calibrate Method of Base Coordination



Three-point calibrate method

<u>Prerequisite</u>

1.Manual mode.

2.Install a calibrated tool on the mounting flange.

Operation steps

1.Select the base number of [Tools / Base] on the left side of the remote operation interface.

2.Select the sub-tab [Calibration] of the function tab [Start Up].

3. Click Base Calibration.

4.Use TCP to move to the origin of the new base frame. Click [Measure].

5. Move TCP to a point on the positive X axis of the new base frame. Click [Measure].

6. Move TCP to a point on the XY plane with a positive Y value. Click [Measure].

7.After completion. The data will be saved.



Tool / Base selection interface



	Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicatio	n Start Up	P Fieldbus	Tracking	Dis
	Calibration	Home	Setting	Time Settin	g User Ala	m Setting	Soft Limit	Electric Gripper	Payload	External Axis		
					Measure Please mov	C e the ende	ancel effector to t	Edit he first point th	en			
	Current Base: 1				Enter the ca	easure but alibration (tton to calib data directly	orate or /.				
Base Calibration												
	buse cumbration			Name	Х	Y	Z	Α	В	С		
				P1								
					P2							
					P3							
					Result							

SCARA robot base calibration interface



3.6.2.1 Enter Value Way of Base Coordination

Description

Values are known, from CAD, for example :

- Distance between the base origin and global origin
- ■Rotation for base coordinate relative to global coordinate

<u>Prerequisite</u>

1.Manual mode

2.X, Y, Z, A, B and C relative to the flange coordinate system is known

Operation steps

1.Select the base number of [Tools / Base] on the left side of the remote operation

interface.

2.Click [Edit].

- 3. Enter the values in the table.
- 4. Click [✓] button after completed. The data will be saved. Click [Clear] botton, it will delete the coordination parameter. ; Click [X] botton , cancel and exit setting interface.

Edit Base 1							
Х	0						
Y	0						
Z	0						
А	0						
В	0						
С	0						
✓ Clear X							

Numerical input interface


3.6.3 Home and Position Check Configuration

3.6.3.1 Home Configuration Setting

Description

Self-setting or recover the origin (Home) position.

<u>Prerequisite</u>

1.Manual mode.

2. Open the adjustment operation interface.

Operation steps

1.Click the sub-tab [Home Setting] of the function tab [Start Up].

2. Move to the self-defined origin position.

3.After moving, click the [Setting Home Point] button to complete the setting.

Position	Poin	t I/O	Timer	Counter	Alarm	LogBook	Communication	Start U	P Fieldbus	Tracking	Display	Mastering	
Calibratio	on H	ome Setting	Time Setting	User Alarm	Setting	Soft Limit	Electric Gripper	Payload	External Axis				
Set I	Home	e Point	Confirr	n Home P	Point	Wa	arning Setting		E	nable			
Parame	ter	HomePos	NowPos	PrePos									
A1		0.000	0.000	8.442									
A2		0.000	0.000	-57.889									
A3		0.000	0.000	-39.751									
A4		0.000	0.000	49.447									
E1		0.000	0.000	0.000									
E2		0.000	0.000	0.000									
B		0.000	0.000	0.000									

Home Setting interface



3.6.3.2 Position Check Setting

Description

The alarm can be removed because of the difference before and after booting "Start pos declination error"

<u>Prerequisite</u>

1.Manual mode

2.Open the adjustment operation interface.

Operation steps

1.Click the sub-tab [Home Setting] of the function tab [Start Up].

2.Click [Warning Setting] button.

3.Enter the define the range of home position parameters.

4. Click "Save" button to save parameters, if setting finish to jump success windows.

5.Click "Cancel" button, no save parameters and exit.

	Н	lomeWarningSetting					×	
$\left(\begin{array}{c}1\end{array}\right)$)	 Define allowable er 	ror value					
\bigcirc		A1:± 1.00	deg	E1:± 1.00	deg			
		A2:± 1.00	deg	E2:± 1.00	deg			
		A3:± 1.00	deg	E3:± 1.00	deg			
		A4:± 1.00	deg					
		A5:±	deg					
		A6:±	deg					
(2))	 Define the range of 	home posit	ion				
\bigcirc	′ I	A1:± 1.00	deg	E1:± 1.00	deg			
		A2:± 1.00	deg	E2:± 1.00	deg			
		A3:± 1.00	deg	E3:± 1.00	deg			
		A4:± 1.00	deg			Save	(3)	
		A5:±	deg			Cancel		-(4)
		A6:±	deg					\bigcirc
Γ								
	No.			Descript	tion			
		When the dif	ference	s between th	e angl	les of each	axis before	
		power off and	d after i	power on are	great	er than the	set values	

1	power off and after power on are greater than the set values (A1-A6 & E1-3), "Start pos declination error", error code 01-04- 30 will pop up.
2	When the point check alarm appears, the robot must be moved back to the origin manually; When the position is within this set
	range, Confirm Home Point can be used to release the alarm.
3	Save Setting
4	Cancel and no save parameters.



3.6.3.3 Home Position Power on Check

Description

The alarm can be removed because of the difference before and after booting "Start pos declination error"

<u>Prerequisite</u>

1.Manual mode

2.Open the adjustment operation interface.

Operation steps

1. Click the sub-tab [Home Setting] of the function tab [Start Up].

2. The NowPos field shows the current axle angle, and the HomePos field shows the setting Home.

3. Using hand to move the robot manually, so that the angle of NowPos moves closer to HomePos.

4.When it is close to Home, even though there is an angle within 1º (Warning Setting of angle) difference, Press [Confirm Home Point]to finish the position check, and remove the alarm.5.If no need the home position check function, user can cancel the check "Enable" selection, but it will no work on the software of home postioin check.

Position	Point	I/O	Timer	Counter Alar	m LogBool	communicatio	n Start U	p Fieldbus	Tracking	Display	Mastering	
Calibratio	on Ho	me Setting	Time Setting	User Alarm Setti	ing Soft Limit	Electric Gripper	Payload	External Axis				
Set I	Home	Point	Confir	m Home Poin	nt W	/arning Settin	9	V E	nable			
Paramet	ter	HomePos	NowPos	PrePos								
A1		0.000	0.000	8.442								
A2		0.000	0.000	-57.889								
A3		0.000	0.000	-39.751								
A4		0.000	0.000	49.447								
E1		0.000	0.000	0.000								
E2		0.000	0.000	0.000								
E3		0.000	0.000	0.000								

Home Setting interface



3.6.4 Time Setting of Controller

Description

User can use the Time Setting to modify the controller time, in order to sync computer time.



Time Setting of Controller

No.	Description					
1	Click to get current local computer time.					
2	Click to save time setting into the controller.					
3	Required time setting.					

Operating steps

Sync local computer time

1.Click [Start Up] \rightarrow [Time Setting].

2.Click [Current local time] to get current local computer time.

3.Click [Set] to save time setting into the controller.

Modify time setting manually

1.Click [Start Up] \rightarrow [Time Setting].

2.Enter required time setting manually.

3.Click [Set] to save time setting into the controller.



3.6.5 Payload Setting

Description

Set the weight at the end of the robot, which including the tool and the objects are clamped. This function will improve movement performance; also adjust the speed limit of the robot and the accuracy of the collision-detection function of the robot. In terms of load estimation, we can make sure whether the robot will warm-up and how the objects size will affect the accuracy approximately.

Instructions

- 1.Select the [Start up]->[Payload] page.
- 2. According to user needs, click [Edit] and enter the various parameters.
- 3.Once finished changes, click [Confirm] to save.
- 4.Click [Set active] to set the selected load data •

						(5)			
	Position	Point	I/O	Timer	Counter Ala	rm LogBook	Communication	Start Up	Field
	Calibratio	on Home	Setting	Time Setting	User Alarm Set	ing Soft Limit	Electric Gripper	Payload	
)	Set p	oayload	data 5	o (active)	~	I			
	- Pay	/load da	ta						
_	— Ma	ass (Kg)	1.00				Edit		
							Confirm		
	Ce	nter (mr	n)			s	Set active		
-	— Хс	0.00		Yc 0.00)				
	Mo	ment of	f inertia	(kg*mm^	2)				
_	Izz	0.00							

Payload setting interface

No.	Description
1	1~20 sets of load's data can be saved.
2	Set the load quality; the unit is kilograms.
3	Set the center position of the load; the unit is millimeters.
4	Set the moment of inertia; the unit is kilograms*millimeters^2.
5	Comment on the load data.
6	Manual input parameter changes.
7	Manual input parameter save changes.
8	Seve the load group to use.



3.6.6 User Self-define Alarm

3.6.6.1 Define Alarm Text Content Setting

Description

User is able to define 10 sets of alarm text content, issued by program instruction.

Operating Steps

1.Click tab of [Start Up], click subtab of [User Alarm Setting].

2. Click twice on the column of Message, and then edit the alarm text content of that column.

Position	Point	I/0		Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	4
Calibratio	n Home	Settin	g Ti	ime Setting	User Alarn	n Setting						
NO.	Co	de					1	Message				
1	1	0	User	Setting Erro	r							
2	1	1	User	Setting Erro	r							
3	1	2	User	Setting Erro	r							
4	1	3	User	lser Setting Error								
5	14	4	User	ser Setting Error								
6	1	5	User	Setting Erro	r							
7	1	6	User	ser Setting Error								
8	1	7	User	ser Setting Error								
9	1	В	User	Jser Setting Error								
10	- 19	9	User	Jser Setting Error								

User Alarm Setting interface figure

3.6.7 Electric gripper setting

Description

Users can set a connection with the XEG electric gripper and reset it by HRSS, which allowing users to move the gripper manually, and can use HRL related instructions to controls it.

Instructions

Main menu>Start-up>Electric Gripper

1.If no drivers were installed, the driver must be installed at first; descriptions of the steps are as follows:

A.The HRSS software version must be updated to at least 3.2.5 or above.

B.Place the Electric Gripper Driver.exe file downloaded from the official website on the controller, and double click on it manually to open the gripper driver installation, and click Extract



FTDI CDM drivers	
$\langle \langle \rangle$	FTDI CDM drivers Click 'Extract' to unpack version 2.08.28 of FTDI's Windows driver package and launch the installer.
L.A.	www.ftdichip.com
	< Back Extract Cancel

Electric Gripper driver installation step 1

C.Click Next to enter the next step

Device Driver Installation Wizard	d
	Welcome to the Device Driver Installation Wizard! This wizard helps you install the software drivers that some computers devices need in order to work.
	< Back Next > Cancel

Electric Gripper driver installation step 2

D. Click and finish it after Installation is fully completed; next, restart the controller.

Device Driver Installation Wiza	rd	
	Completing the De Installation Wizard	evice Driver d
	The drivers were successfully in	stalled on this computer.
	You can now connect your devi came with instructions, please re	ice to this computer. If your device aad them first.
	Driver Name	Status
	FTDI CDM Driver Packa FTDI CDM Driver Packa	Ready to use Ready to use
	< Back	Finish Cancel

Electric Gripper driver installation step 3

- 2.Select the gripper model
- 3.Press the connect button

4. Press the reset button to reset the gripper's setting; please note that this reset is only completed when the gripper status changed from Busy to Idle

5. The detection function of the gripper is enabled by default; this function is used to notify the user when the gripper did not grip any objects. This function can be unselected if the detection function is not required.



Electric Gripper Operation Interface

No.	Description					
1	Set the gripper model					
2	Connect/disconnect to the gripper					
3	Reset the gripper connection settings					
4	Displays the current gripper's status					



5 Displays the current gripper's position

6 Grip detection status function

3.6.8 Software limit function

Description

The software limit function is provided in HRSS; this function mainly sends out alarms in real-time and stops movements. When the number of movement commands sent to the robot exceeded the limit set, or when the robot exceeded the position of the limit set during the movement process. Set the software movement range limit for the various axes and space Cartesian coordinates based on joint, SCARA or parallel robots.

The upper and lower limits of each axis and Cartesian coordinates can be set in the software limit function. The limit range of the Cartesian coordinate is to be set based on the center position of the robot tool (TCP) when the base coordinate is 0 (Base 0). Users can choose whether enable the limit check for each axis or Cartesian coordinate setting (setting interfaces are different according to the different robots). For the limits of each axis for joint robots, upper and lower limits can be set for axes A1~A6. For the Cartesian coordinate limits, upper and lower limits can be set for X, Y and Z. For SCARA robots, upper and lower limits can be set for axes A1~A4. For the limits of each axis for parallel robots, upper and lower limits are set at the same time for axes A1~A3 while the A4 axis is set separately. For the Cartesian coordinate limits, upper and lower limits are Set separately. For the Cartesian coordinate limits, upper and lower limits are set for the radius and Z axis. If the upper and lower limits are both 0, it means that the axis or the X, Y or Z functions are disabled.

Instructions

- 1.Save the changes
- 2.Enable/Disable Soft Limit.
- 3.Set software limit function for each axis
- 4.Softlimit note
- 5.Set the software limit function for space for Cartesian coordinate
- 6.Set the software limit for each Cartesian coordinates

The movement range on the coordinate display interface will be updated immediately according to the software limit settings.



ocition Roint 1//) Timor	Counter Alar	m IngPook Co	mmunication Start	In Fieldbur	Tracking Dicelay	Mastering
alibration Home Setti	ing Time Setti	ng User Alarm Setti	ing Soft Limit Elect	ric Gripper	PP Fieldbus	Tracking Display	Mastering
– Save	? ^W	/hen both the u ick save button	oper and lower li to take effect aft	mits are 0, this a er change !	xis's soft lim	it function is DIS	SABLED.
Joint			Cartesian				
– 🗹 Enable	Low Limit	High Limit	Enable	Low Limit	High Limit		
A1[degree] (-165.000~165.000)	-100	100	X[mm]	0	0		
A2[degree] (-125.000~85.000)	-100	100	Y[mm]	0	0		
_ A3[mm] (-55.000~185.000)	-10	1	Z[mm]	-10	0		
A4[degree] (-190.000~190.000)	50	80					
A5[degree] (-115.000115.000)	0	0					
A6[degree]	0	0					





SCARA robot software limit setting interface

ltem number	Description
1	Save settings
2	Enables/disables the software limit function for each axis
3	Set the software limit for each axis
4	Displays reminder texts. When the upper and lower limits are both set as 0, it is disabled.
5	Enables/disables the software limit function for space Cartesian coordinates
6	Set the software limit for each Cartesian coordinate



3.6.9 External axis functions

Description

HRSS (HIWIN-Software) provides related functions and robotic language (HRL) instructions to operate and control the external axis. After users configured the related external hardware equipment properly, they can use HRSS and it is function. For example, HRSS can be controlling the external axis to execute synchronous and asynchronous movements, or execute synchronous coordinated controls for the external axis. HRSS can currently control a maximum of 3 external axes. In terms of application, it can control linear mobile carriers, end tools and positioners, etc.

3.6.9.1 External axis parameter settings

Description

The connected external axes of the various parameters must set prior to performing operations and controls to the external axes. The parameters for each axis must be set and saved.

Instructions

1.Click the function page [Start Up] \rightarrow [External Axis] [Setting].

2.Open the function and set the parameters.

3.Set the advanced page parameters.

4. Press the [Save] button to save the settings.

	Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicatio	on Start Up	Fieldbus	Tracking	Display	Mastering
	Calibration	Home	Setting	Time Setting	User Alarm	Setting	Soft Limit	Electric Gripper	Payload	External Axis			
	Setting	Zero Po	sition F	osition Limit S	witch						_		
		_	_										
		Save											
	Axis S	ettina											
\bigcirc											G	\	
	Exte	ernal A	kis	E1	•			V E	nable		-(5)	
$\overline{\frown}$				_									
(2)	- Moo	de		Syr	nc •								
\sim													
(3)	— Higl	h Limit	[mm]	100	0.00								
\sim											-		
(4)	Low	/ Limit	[mm]	-10	00.00			A	dvanced]	-(6)	
\bigcirc											C		

External axis parameter settings

ltem number	Description										
1	ect the external axis										
2	Set the movement mode of the external axis as synchronous/asynchronous axis •Synchronous movement (Sync):										



	Synchronous movement means that the movement of
	all axes, including the robot and external axes, starts
	and ends at the same time. Calibrate their movement
	path relationship and set their kinesiology under
	synchronous movement mode allows the achieving of
	synchronous coordinated control when controlling
	external axes.
	Asynchronous movement (Async):
	Asynchronous movement means that the movements of the
	robot and external axis do not start or stop at the same
	time; the movements of the robot and external axes are not
	dependent on each other
3	Set the upper limit for the movements of the external axis
4	Set the lower limit for the movements of the external axis
5	Enables/disables the selected external axis function
6	Advanced setting page



External axis advanced parameter settings window

ltem number	Description
1	Set the external axis type to linear/rotation axis
2	Set the maximum rotation speed of the external axis motor
3	Set the resolution of the external axis motor
4	Set the reduction ratio of the reducer installed on the external axis motor
5	Set the direction of the external axis motor
6	Set the infinite rotation function of the external axis



7	Sets the acceleration and deceleration time for the external
1	axis
8	Sets the lead of the external axis
9	Cancel the changes made at this time
	Save the settings at this time temporarily; the [Save] button
10	on the home page must be pressed to make changes on this
	setting

3.6.9.2 Zero point calibration for the external axis

Description

Perform a zero point of the external axis; for safety considerations. Users must do the zero point position calibration after the completion of parameter settings for the external axis.

Instructions

1.Click the function page [Start Up] \rightarrow [External Axis] [Zero Position].

2.Select the external axis to reset and press the [Reset] button.

3.If set successfully appeared, it means reset has been completed.



Zero point calibration for the external axis

3.6.9.3 External axis positive and negative limit signal monitoring

Description

Caterpillar can set with HRSS to monitor the positive and negative limit status of the external axis driver. When the limit signal trigger is received, the instruction for movements toward the limit direction is stopped to prevent the external axis from bursting or colliding.

Instructions

1.Click the function page [Start Up] \rightarrow [External Axis] x [Position Limit Switch].

2.Select the pin and function set.

3. Press the [Save] button to complete the settings.

4. When the sensor or signal source detects the limit, the [Limit Switch Monitoring] light will turn on (invert input not set).



Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicatio	n Start Up	Field
Calibratio	n Home S	Setting Ti	me Setting	User Alarm	Setting	Soft Limit	Electric Gripper	Payload	Externa
Setting	Zero Pos	ition Posi	ition Limit S	witch					
	Save								
Posi	tion Lim	it Swite	h Config	guration					
- Evt	ernal Avi	c			E1	•			
		3							
	Enable				🗌 In	verted In	put		
Nie			• Nicconduce	_	TO				
Ne	gative Li	mitinpu	t Numbe	ſ	10				
Pos	sitive Lim	nit Input	Number		IO	-			
	imit Swi	tch Mou	nitoring						1
	init Swi						_		
<u> </u>	Negati	ve Limit			Posit	ive Limit			

External axis positive and negative limit signal monitoring interface window External axis positive and negative limit signal monitoring setting table

ltem number	ltem name	Description					
1	Save button	The Save button must be pressed after setting the interface parameters					
		to record the settings.					
2	Axis selection	The axis selection button for the external axis; it is in the form of a					
2		pull-down menu. Axes E1~E3 can be selected.					
2	Enable/Disable	To use limit signal monitoring, this function must be enabled					
5	monitoring function	To use mine signal monitoring, this function must be enabled					
		Reverses the input signal of the positive and negative limits. (If it w					
4	Reverse input signal	originally "normal-open" signal, after being reversed, it would become					
		"normal close" signal)					
Б	Sets the input pin of	Negative limit input pin selection; pins I0~I31 can be selected. (Select					
J	the negative limit	based on the external axis driver pin used)					
e	Sets the input pin of	Positive limit input pin selection; pins I0~I31 can be selected. (Select					
0	the positive limit	based on the external axis driver pin used)					
	Limit quitch	It Shows whether the positive/negative limit is currently the limit					
7	LIIIIL SWILCH	position signal; if the frame is red, it is the limit position, and if it is					
	monitoring display	white, it is a non-limit position.					

3.6.9.4 Manual operation of external axis

Description

Each of the external axes can be moved manually with a help of JOG mode in the Manual mode; each of the axes can be moved in the positive or negative direction and their speed rates can be adjusted separately.



Instructions

1.Click the [JOG] page.

2.Start moving the external axis.



JOG interface window



3.7 Display Setting

3.7.1 Display System Status Input/Output

Operation steps

■Click tab of [Display] ,Click subtab of [System I/O].

Description

			2	3			
(1)-		- NO.	Input Value	Comment	NO.	Output Value	Comment
\smile	•	10	□Off	Start	00	□Off	Red Lamp
		11	□Off	Hold	01	On	Green Lamp
		12	On	Driver Alarm	02	□Off	Yellow Lamp
		13	On	Break Release	O3	□Off	Robot IO
		14	On	Emergency Stop	04	□Off	Reset Driver
		15	□Off		O5	□Off	Kernel Alive Watchdog
		16	∎Off		O6	On	Servo ON/OFF
		17	□Off		07	□Off	Reset Safety Relay
		18	□Off		08	□Off	
		19	□Off		O9	□Off	
		110	□Off		O10	□Off	

System input/output interface

No.	Description
1	Input/Output number
n	The opened input/output signal displays in red and shows On.
Z	OFF is displayed in white and showed Off.
3	Input/output name



3.7.2 Module I/O Function

Description

User can use module I/O (DI/DO/SI/SO) to map and control to multiple inputs (DIs) or outputs (DOs).

Operating steps

Click tab of [Display], [Module I/O] tab under [Variable] tab, click tab of [MI]/ [MO].

1. Module Input setting:

"Start" is beginning Input number and "End" is the ended Input number. After setting, while the specific Module Input is ON, the mapped Inputs (DIs) will be ON as well.

Position	Point	I/O	Timer	Co	unter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	P								
System 1	/O Varial	ole Utilizat	ion Robo	ot Data	a									Positio	n	Point	I/O	Tin	mer	Counter	Alarm
Module	I/O PR													DI		DO	SI/O	FI	0	PNS	DIO Setti
MI	MI MO											Base									
	Save									DI	DI SIN	1 DI Val	lue		DI Co	mment					
															D11			n	MI		
No	. SIM.	Value	Туре	•	Start	End									DI2)n	MI		
MI		On	DI	-	1	5									DI3			n	MI		
MI2		DOff	DI	-	0	0									D14			200	NAT.		
ME		□Off	DI	-	0	0									014			11	IVII		
MI4		□Ofĭ	DI	-	0	0									DIS			n	MI		

Module input figure (right figure is DI[1]~ DI[5] ON then MI[1]ON)

2. Module Output setting:

"Start" is beginning Output number and "End" is the ended Output number. After setting, while the specific Module Output is ON, the mapped Outputs (DOs) will be ON as well.

													-	Po	sition	Point	I/O		Timer	Counter	l
Position	Point	I/O	Timer	Cou	nter 4	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	1	D	I	DO	SI/O		FIO	PNS	-
System I/	O Variable	Utiliza	tion Robot	Data										H	•		24.0				
Module I	I/O PR													E	Base						
MI	MO												_		DO	DO	Value		DO	Comment	
	Save														DO1		Dff				
N	o. V	alue	Туре		Start	End									DO2		On	мо			
M	01	On	DO	-	2	4									DO3		On	мо			
M	02	Off	DO	-	0	0							_		DO4		On	мо			
M	03 🔲	Off	DO	-	0	0									204			1110			_
M	04 🔲	Off	DO	-	0	0									DO5		Jff				

Module output figure (right figure is DO[2]~ DO[4] ON then MO[1]ON)



3.7.3 Position Register (PR) Setting

Description

User can set Position Registers. Value1 to Value6 are the angle values or coordinate values; they can be divided into angle DEG and position coordinate value POS. Value7 - Value9 are the external (E1~E3) position values of the external axis.

Operating steps

- 1. Click tab of [Display], Click subtab of [Variable], Click subtab of [PR].
- 2. Select one row of the table of registers.
- 3. Users can choose and Overwrite Degree of the current axis coordinate position and external axis or Overwrite the current Cartesian coordinate and external axis in the options below.
- 4. Clicking the [Clear] button will clear all coordinate contents and comments for the respective point.
- 5. Clicking the [PTP] button will move the robot to this point by using the point to point (PTP) method.
- 6. Clicking the [LIN] button will move the robot to this point by using the linear (LIN) method.
- 7. Double-clicking the value in the table allows modifying it directly. While modifying, users must be special attention and enter the correct value in order to prevent the robot from the abnormal positions or collisions.
- 8. User-defined comments can be entered in the Comment field to identify points during operations.

	(1	(2	(3	4)	5	(6
Position	Point I/O	Timer	Counte	r Alarm	LogBook	Communicati	on Start Up	Fieldbus	Tracking [)isplay Ma	astering
System	I/O Variable U	tilization Ro	bot Data								
Module	EI/O PR										
C	verwrite Degr	ee (Overwrite	Coordinat	e	Clear	РТ	P	LIN		
NO.	Comment	TYPE	Value1	Value2	Value3	Value4	Value5	Value6	Value7	Value8	Value9
1	Coordinate, XYZ	POS	0.000	800.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
2	Degree ,Joint	DEG	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3	PTP_speed,Acc,T	B POS	55.000	88.000	0.000	1.000	0.000	-10.862	0.000	0.000	0.000
4											
5											
6											
7											
8											
9											
10											
11											
12											

Position registers interface





Position registers setting description table

No.	Name	Description					
	Overwrite Degree	After selecting the column item (No.) to overwrite, press the button and					
1	Overwrite angle	the angles of the various axes (A1~A4) of the robot will be recorded into					
	button	the specified table columns (Value1~Value4). They are DEG angle types.					
	Overwrite Coordinate	After selecting the column item (No.) to overwrite, press the button and					
2	Overwrites the	the current angles (XYZC) of the various axes of the robot will be					
2	coordinate value	recorded into the specified table column (Value1~Value6), in which 0 is					
	angle	recorded into Value4 and Value5. They are POS position coordinate types.					
2	Clear button	After selecting the column item (No.) to overwrite, press the button to					
5	Clear Dutton	clear the current values.					
		Button used to move to this point using point to point method. After					
4	PTP button	selecting the column item (No.) to move, press this button and the robot					
		will move to the point at this position.					
		Button used to move to this point using the linear method. After					
5	LIN button	selecting the column item (No.) to move, press this button and the robot					
		will move to the point at this position.					
		Displays the information of the position register currently set; Value1 -					
		Value6 are the angle value or coordinate value, which can be divided into					
		angle DEG and position coordinate value POS, and Value7 - Value9 are					
		the E1~E3 position values of the external axis. A total of PR1 ~ PR4000					
	Information dicalay	position registers can be used, and the writing method of the					
6	table	corresponding program is \$PR[1] ~\$PR[4000] position register settings.					
	lable	User-defined comments can be entered in the Comment field to identify					
		points during operations. If users want to change the value in PR, simply					
		double-click on it to modify the value. While modifying, users must be					
		special attention and enter the correct value in order to prevent the					
		robot from having abnormal positions or collisions.					



3.7.4 Display Utilization Rate

Operating Steps

Click tab of [Display], click subtab [Utilization].

Description

Display robot utilization

working time and operation time.

Position Point	I/O Tir	ner Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Displ
System I/O Vari	able Utilization								
	— Utilization:(— Working Time).3 % ⊧: 0 year 0 mo	nth 0 day	y0 hour1 m	inute				
	 Operation Tim 	ne: 0 year 0 mo	nth 0 day	y 5 hour 32 n	ninute				
Program	Start Time	End/Pause	Time	Working	Time				
Abs	2020/03/16_11:36	2020/03/16_1	1:37	0000/00/00_0	0:01				
Abs	2020/03/16_11:36	2020/03/16_1	1:36	0000/00/00_0	0:00				
Abs	2020/03/16_11:36	2020/03/16_1	1:36	0000/00/00_0	0:00				
Abs	2020/03/16_11:36	2020/03/16_1	1:36	0000/00/00_0	0:00				
Abs	2020/03/16_11:34	2020/03/16_1	1:34	2020/03/16_1	1:34				
Abs	2020/03/03_14:18	2020/03/03_1	4:18	0000/00/00_0	0:00				
(1)	\downarrow	\perp		\perp					
	(5)	(6)		(7)					

Utilization Interface

No.	Description
1	Utilization rate
2	Total time of executing program
3	Total time of turning on power
4	Name of executing program
5	Start time of executing program
6	End/pause time of executing program
7	Working time of executing program



3.7.5 Display Robot Data

Description

Records the robot's parameter's name and parameter values, such as the system's maximum speed, rotation speed set for the first axis, upper and lower limits, gear ratio and other robots' information. It only displays the information and cannot change them; it is only used for confirming parameters and fixing problems.

Operating steps

Click tab of [Display], click subtab of [Robot Data].

Position Point I/O	Timer Counte	r Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Mastering
System I/O Variable Utilizatio	on Robot Data								
Parameter	Value								
System Max Speed	5000								
System Mode	1								
System Axis Number	4								
RobotIO Port	1								
External Port	2								
Reserved Port	3								
Driver Port	4								
TouchPancel Port	5								
TeachPendant Port	6								
Axis 1 Axis	0								
Axis 1 PPR	131072								
Axis 1 RPM	4500								
Axis 1 Pitch	360								
Axis 1 Gear Ratio	100.00								
Axis 1 High Limit	130.000								
Axis 1 Low Limit	-130.000								

Robot data interface



4. Motion Program Base Design Description

4.1 Motion Overview

Program designed by the following motion: Point-to-point motion (PTP)

Linear motion (LIN)

Circular motion (CIRC)

LIN and CIRC Motion is also called as "CP motion" (CP = Continuous Path).

A start point must begin at the end point of the previous motion.

4.2 Point-to-point (PTP) Motion

The robot guides TCP to the target point along the fastest path. Generally, the fastest path is not the shortest one. This means that it is not a straight line. Because the axis performs rotational motion, the curved path is faster than the straight one.

The motion cannot be accurately known in advance.



PTP Motion path figure



4.3 Liner Motion (LIN)



The velocity defined by the robot along a straight line moves TCP to the target point.

LIN motion path figure

TCP at the start point of motion could be in an orientation different from the target point. The orientation of TCP will gradually change during the motion. When the TCP is at the start point of motion and in the same orientation as the target point, the orientation of TCP will remain the same in the motion.



Start point in same orientation of target point



Start point in different orientation of target point



4.4 Circular Motion(CIRC)

The velocity defined by the robot along the circular path moves the TCP to the target point. A circular track is defined by the start point, auxiliary point and target point.

For the CIRC motion, the orientation guide is the same orientation as with LIN motion.

In the CIRC motion, the control system only considers the orientation of the target point. The orientation of auxiliary point is usually ignored.



CIRC motion path figure

4.5 Robot Singular Point Description

The HIWIN's robot with six degrees of freedom has three kinds of singular point.

- 1. Overhead singular point (Six-Axes robot)
- 2.Singular point at extended position(Six-Axes robot, SCARA Robot)
- 3.Singular point at wrist axis(Six-Axes robot)

It is considered as a singular point position only when one value can't be obtained by the inverse conversion (converted from Cartesian coordinate to articulated coordinate). In this situation, it is a position of singular point when the minimum Cartesian variation could cause a large change of axis angle.

Overhead

For the overhead singular point, the wrist point (the middle point of axis A5) is vertical to the axis A1.

The position of the axis A1 cannot be confirmed by the inverse conversion, and it can be any value.

At this point, if the inverse motion is performed, an error will appear.





Extended position

For the singular point at the extended position, the wrist point (the middle point of axis A5) is located in the extension of axis A2 and A3.(SCARA: A1 AND A2)

The robot is located at the edge of the workspace.

Although only one axis angle can be obtained by the inverse conversion, the small Cartesian variation will cause the large velocity of the axis A2 and A3. (SCARA: A1 AND A2)

At this point, if the inverse motion is performed, an error will appear.



■Wrist axis

For the singular point of the wrist axis, the axis A4 is parallel with A6, and the axis A5 is within the range $\pm 0.1^{\circ}$.

The positions of two axes can't be confirmed by the inverse conversion. Although the axis A4 and A6 can have many positions but the sum of the axis angle is the same.

At this point, if the inverse motion is performed, an error will appear.





4.6 Blend (Continuous Trajectory)

Blend: Not accurately moved to the point programmed. The over blending is another option that can be selected during the motion program.

■PTP motion

The TCP will leave a track where it can accurately reach the target point, and adopt the faster one. When over blending takes place in a PTP motion, the track change cannot be foreseen. The point through which side on the track cannot be forecasted.



PTP motion and P2 blended

LIN motion

TCP will leave a track where it should accurately move to the target point, and run on a shorter track. The region where the track path runs is not an arc.



LIN motion and P2 blended



■CIRC motion

TCP will leave a track where it should accurately move to the target point, and run on a shorter track. The auxiliary point can reach accurately. The region where the track path runs is not an arc.



CIRC motion and Pend blended

4.7 Continuous/ Discontinuous Trajectory Description

§Continuous Trajectory (CONT, Pre-read) Description:

If the "CONT" command is called, the robot controller will consider the next motion point, and will move in a smoother path. The path smooth level will depend on the motion velocity and acceleration.

There are three kinds of CONT command: CONT, CONT = #%, CONT = #mm. Last two kinds represent the fixed path, like CONT = 50% or CONT = 30mm.

Command Format:

Format(1):CONT	
Format(2):CONT = #%	
Format(3) : CONT = # mm	
⇔Format(1) : CONT	

If User not define smooth path percentage ratio or smooth path distance, preset parameter is 100%.

- LIN P1 CONT
- LIN P2 CONT
- LIN P3 CONT

When execute the commands open, there will be the smooth path in "LIN P2 CONT", but there won't move to P1 and P3(because they are the origin and destination).



CONT motion figure



⇒Format(2) : CONT = #%

User define smooth path percentage ratio.

LIN P1 CONT

LIN P2 CONT = 50%

LIN P3 CONT

The distance between P2, P3 is shorter than the one between P1, P2, which is called the short length. When execute the open program, the trajectory will start fairing when 50% short length away before

Ρ2.

! CAUTION

Because the "CONT= # %" command will create a fixed path, so the velocity of the robot may change.





⇒Format(3) : CONT = # mm

User define smooth path distance. LIN P1 CONT LIN P2 CONT = 5mm LIN P3 CONT

The path will start fairing when 5mm away before P2.





! CAUTION

Because the "CONT= # mm" command will create a fixed path, so the velocity of the robot may change.

1 CAUTION

When using "CONT= # mm" command, it does not mean that the value specified by the user will be exactly the same. However, the system will attempt at the distance specified by the user.

If there is "DO" command before the "CONT", then the path won't be smoothed. Example : LIN P1 CONT \$DO[1] = TRUE LIN P2 CONT LIN P3 CONT

Originally, the path moving to P1 should be faired, but in this case, the path won't be smoothed.

Line 2 have one DO signal, to reach P1 position and stop, to output DO[1] signal, then move to P2 position smoothed. CONT not work in Line 2 (not pre-read).







"FINE" command make TCP arrive the point without fairing the path. User choose kind by task state, preset define FINE=1.

	Command Format:
For	mat(1) : FINE (=0)
For	mat(2) : FINE = 1
For	mat(3) : FINE = 2

FINE has three kinds:

 \Rightarrow FINE (= 0), pre-read the next command, not check the actual position. Equal CONT commend, can save motion time.

 \Rightarrow FINE = 1 , not pre-read the next command, not check the actual position.

 \Rightarrow FINE = 2 , not pre-read the next command, check the actual position.

%Preload function description

In computer program computations, program codes are preloaded at the bottom layer of the program to be compiled and combined with multiple follow-up actions and then integrated and outputted. We call this the preload function. The benefit of the preload function is to allow the program to know the next step of action in advance, and make adjustments and simplifications to reduce time. But the drawback is that when there might be several types of processes (such as counting, statements and calculation types), that the robot timing may be inaccurate. CONT instructions all have preload functions.

For example: In the figure below, the robot moves to 5th point from P1 to P5; when the robot is moving towards P2, the program already read the P5 point, and the subsequent actions are more certain.





Preload function illustration



XIn-place function description

The in-place function refers to the accuracy level in which the program determines that the target position was reached. If the error value is extremely low, which means that in-place exits precisely. If the error value is high, which means that in-place exits roughly or not in-place, as shown in the figure below. When the in-place position is enlarged, the area inside the dotted circle is the error range of the point (error of the motor being in-place). When the P1 point position is reached, there are three precision levels: FINE(=0) is the same as the continuous CONT function, it is not in-place and not precise. A better one is FINE=1, which means that it is in-place but not precise. The best one is FINE=2; which means that it is in-place and precise because it takes a longer time to achieve precisely.



In-place function example illustration (1) Not in-place (2) In-place but not precise (3) In-place and precise

• :Denotes P1 point: X denotes the in-place point of the robot. The area inside the dotted circle is the error range of the point position.

Application program example 1: (explaining using CONT, which is the same as FINE=0)
 PTP P1 CONT
 LIN P2 CONT
 \$C[1] = \$C[1] + 1

■ Application program example 1 description:

Execute point to point movement to the P1 point, with continuous trajectory (CONT). Execute point to point movement to the P2 point, with continuous trajectory (CONT). The first counter executes the execution plus 1 calculation.

Result description: Successfully moved from P1 point to P2 point in order and complete the counting action; the connection between the actions of P1 and P2 is a continuous trajectory, which can save time. But when the P1 movement just begin, the program already preloaded and completed the counter's count+1; the count action ran without waiting for P2 to complete executing before performing the count action.

Application program example 2: (explaining using FINE = 1)



PTP P1 FINE = 1 LIN P2 FINE = 1 \$C[1] = \$C[1] + 1

Application program example 2 description:

Execute point to point movement to the P1 point, with non-continuous trajectory (FINE=1). . Execute point to point movement to the P2 point, with non-continuous trajectory (FINE=1). The first counter executes the execution plus 1 calculation.

Result description: Successfully moved from P1 point to P2 point in order and complete the counting action; the connection between the actions of P1 and P2 is non-continuous trajectory, and the in-place method of P1&P2 is not fully precise positions. The program did not preload, and the counting action was executed after P2 had finished executing.

■ Application program example 3: (explaining using FINE = 2)

PTP P1 FINE = 1 LIN P2 FINE = 2 \$C[1] = \$C[1] + 1

Application program example 3 description:

Execute point to point movement to the P1 point, with non-continuous trajectory (FINE=1). . Execute point to point movement to the P2 point, with non-continuous trajectory (FINE=2). The first counter executes the execution plus 1 calculation.

Result description: Successfully moved from P1 point to P2 point in order and complete the counting action; the connection between the actions of P1 and P2 is non-continuous trajectory, and the in-place method of P2 is fully precise positions. The program did not preload, and the counting action was executed after P2 had finished executing.



5.Program Editor Setting and Operator

5.1 Manage Program List



Program List

Description

A user can manage the program in the list.

No.	Description
1	Refresh the "Controller" and "Local" program list.
2	Setting designated program, the RSR function.
3	Setting designated program, the PNS function.
4	Controller program list.
5	Local program list.
6	Upload to Local.
7	Download to controller.
8	Change "Local" side folder path (user can select folder).

5.2 Add and Delete File/Folder

•Add file/folder steps

1.Right-mouse click on empty space of the program list to add file. (New File/New Folder).

2. Enter the name of the new file, make sure it meets the file name specification. Please see section 0.



Delete file/folder steps

1.Select file/folder and right-mouse click to delete file. (Delete File/Delete Folder).



Add file/folder

5.3 Copy File/Folder

Copy file steps

- Select file, Right-mouse click to copy file, then right-mouse click paste file on any empty space of the program. [Archival name-copy] is the new file name, If file name have [-copy] word, then [-copy(count)] is the new file name.
- 2. Example: original file name is "test.hrb", first copy file name is "test-copy.hrb". Second copy file name is "test-copy(1).hrb", as above.
- 3. Hot key use "Ctrl+X" & "Ctrl+V".
- •Copy folder steps
 - 4. Select folder, right-mouse click to copy folder, then right-mouse click paste folder on any empty space of the program. [Archival name-copy] is the new folder name, and copy original folder of all files, copy to new folder. If folder name has [-copy] word, then [-copy(count)] is the new folder name.


- 5. Example: Original file name is "test", first copy file name is "test-copy". Second copy file name is "test-copy (1)", as above.
- 6. Hot key use "Ctrl+X" & "Ctrl+V".

Choose more files : keep push "Ctrl" button and lift-mouse click choose more files/folders.



File/ Folder right-mouse click function figure(left : file; right : folder)

Å WARNING

When download the local program file to the controller, if the file name does not meet the file name specification, the file will not be opened.

5.4 Cut File/Folder

•Cut file/folder steps

1.Select file/folder, and right-mouse click to cut file/folder, then right-mouse click paste file/folder on any empty space of the program.

2.Hot key use "Ctrl+X" & "Ctrl+V".



5.5 Rules of name Files

Rules for naming files, the program file has to satisfy this rule to ensure adding or copying of the file successfully.

<u>Content</u>

- 1. Only Arabic numerals (0-9), English letters (a-z, A-Z) and underscore (_) can be used for naming.
- 2.Special symbols $\lceil \sim !@#$ \$%^&*()-+={}[]<>,.?/\| _ are not allowed.
- 3.The first character cannot be a number.
- 4.Not more than 100 words.

Å WARNING

If the name of the program file does not correspond to the rules, follow situation may occur when operating other function:

1.Unable to open the file

2.Unable to copy the file

3. Unable to be added to external startup functions list

4. Unable to use external subroutine functions

5.6 HRSS Program Commend Structure Description



Line	Description				
8	IN motion, the TCP path is liner path.				
1.4	PTP motion, point to point, the TCP path isn't liner path,				
14	like as circle path.				

User need to selecte robot path way, PTP or LIN or Circ, to finish robot suitable move path.

If the first motion command is not a default home position or that position has changed, one of the following commands must be used:

Complete PTP command

Complete LIN command

Complete motion command must enter all parameter contents about the target points.



\rm MARNING

If you change the home position, all programs will be affected and may cause the injury and property loss.



5.7 Program Operator Description

5.7.1 Set Program Ratio

Description

The program ratio is used to set the robot velocity. It is represented with a percentage, based on the programmed velocity.

! CAUTION

In manual mode, the maximum velocity is 250mm/s, nothing to do with the set value.

Operation steps

1.Adjust in program execution velocity window.

2.Set the program ratio.

5.7.2 Start A Program

<u>Prerequisite</u>

Program selected.

Operation steps

1.Select program opening.

2.Press the Start button.

3. The program starts to execute.

4.To stop a program, press the Stop button.

Image: State	Robot Eultor	
t20140916.hrb(tocal)* [new]* x x \$ \$ \$00[1] - rate x = 1 \$ \$ \$ \$00[1] - rate x = 1 x = 1		1
1 1 2 WHIT FOR SDI[] = TRUE 4 (HIT FOR SDI[] = TRUE 500(1] = FALSE FIP P10 CONT Vel=40% Acc=100% TOOL[0] BASE[0] 9 PUP P14 FIRE Vel=40% Acc=100% TOOL[0] BASE[0] 10 WAIT SEC 1 11 LIN P26 FIRE Vel=20m/s Acc=50% TOOL[0] BASE[0] 12 LIN P26 FIRE Vel=20m/s Acc=50% TOOL[0] BASE[0] 13 LIN P26 FIRE Vel=20m/s Acc=50% TOOL[0] BASE[0] 14 LIN P26 FIRE Vel=20m/s Acc=50% TOOL[0] BASE[0] 15 SUO[3] = FALSE 16 WAIT SEC 1 17 LIN P2 FIRE Vel=20m/s Acc=50% TOOL[0] BASE[0] 18 LIN P3 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 19 SUO[3] = FALSE 10 WAIT SEC 1 11 LIN P3 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 18 LIN P3 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 10 WAIT SEC 1 11 LIN P4 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 20 HIT P4 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 21 LIN P5 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FIRE Vel=200m/s Acc=100% TOOL[0] BASE[0] 21 LIN P5 FIRE	▼ 120140916.hrb(Local)* [new]*	:
<pre>2C_MMILE 1 == 1 5 SO(1) = FALSE 6 ; // ror 507(1) == TRUE 5 SO(1) = FALSE 6 ; // ror 500 CONT Vel=46% Acc=100% TOOL[0] BASE[0] 8 SO(1) = TRUE 10 WATT SEC 1 11 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0] 12 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0] 13 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0] 14 LIN P14 FINE Vel=20mm/s Acc=100% TOOL[0] BASE[0] 15 SO(1) = FALSE 16 WATT SEC 1 17 LIN P2 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 18 LIN P3 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 19 SO(1) = FALSE 20 WATT SEC 1 11 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 21 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 23 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 24 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 25 SO(1) FALSE 26 WATT SEC 1 27 Drogram editor interface 27 Drogram editor interface</pre>	1	
<pre>style(1) = rALS f ; ;ALT FOR SD[1] == TRUE SSO[1] = FALSE f ; ;rist P PP P0 CONT Vel=4% Acc=10% TOOL[0] BASE[0] SVO[3] = TRUE WATT SEC 1 11 LIN P25 FINE Vel=20mm/s Acc=5% TOOL[0] BASE[0] 12 LIN P25 FINE Vel=20mm/s Acc=5% TOOL[0] BASE[0] 13 LIN P25 FINE Vel=20mm/s Acc=5% TOOL[0] BASE[0] 14 LIN P25 FINE Vel=20mm/s Acc=5% TOOL[0] BASE[0] 15 WO[3] = FALSE 16 WATT SEC 1 11 LIN P2 FINE Vel=200mm/s Acc=10% TOOL[0] BASE[0] 12 LIN P3 FINE Vel=200mm/s Acc=10% TOOL[0] BASE[0] 13 LIN P3 FINE Vel=200mm/s Acc=10% TOOL[0] BASE[0] 14 LIN P3 FINE Vel=200mm/s Acc=10% TOOL[0] BASE[0] 15 WOT SEC 1 11 LIN P3 FINE Vel=200mm/s Acc=10% TOOL[0] BASE[0] 20 LIN P5 FINE Vel=200mm/s Acc=10%</pre>		
<pre>\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$</pre>	3 \$100[1] = 1KUE 4 = 1kuIT FOR \$DI[1] == TRUE	
6 //frsf 7 PFP P0 CONT Vel=46% Acc=100% TOOL[0] BASE[0] 9 SV0[1] - TRUE 10 WATT SEC 1 11 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0] 12 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0] 13 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0] 14 LIN P14 FINE Vel=20mm/s Acc=100% TOOL[0] BASE[0] 15 SV0[1] - FALSE 16 WATT SEC 1 17 LIN P5 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 18 LIN P5 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 19 SV0[1] - FALSE 20 WATT SEC 1 11 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 21 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 23 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 24 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 25 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 26 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 27 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 28 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 29 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 20 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 21 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 23 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 24 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 25 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 26 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 27 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 28 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 29 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 20 LIN P5 FINE Vel=200mm/s Acc=100%	5 \$D0[1] = FALSE	
PIP PP conv vel-star Acc-100% TOOL[0] BASE[0] 9 SV0[3] - TRUE WAT SEC [11 LIN P25 FINK Vel-30mm/s Acc+30% TOOL[0] BASE[0] 12 LIN P25 FINK Vel-30mm/s Acc+30% TOOL[0] BASE[0] 13 LIN P25 FINK Vel-30mm/s Acc+30% TOOL[0] BASE[0] 14 TIN P14 FINK Vel-20mm/s Acc+30% TOOL[0] BASE[0] 15 SV0[3] - FALSE 16 WAT SEC [17 LIN P2 FINK Vel-300m/s Acc+30% TOOL[0] BASE[0] 18 LIN P3 FINK Vel-300m/s Acc+30% TOOL[0] BASE[0] 19 WAT SEC [10 LIN P3 FINK Vel-300m/s Acc+30% TOOL[0] BASE[0] 11 LIN P3 FINK Vel-300m/s Acc+30% TOOL[0] BASE[0] 12 LIN P3 FINK Vel-300m/s Acc+30% TOOL[0] BASE[0] 13 LIN P3 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 14 LIN P3 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 15 SV0[3] - FALSE 12 LIN P3 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 20 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 21 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 22 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 23 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 24 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 25 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 26 LIN P5 FINK Vel-300mm/s Acc+30% TOOL[0] BASE[0] 27 LIN P5 FINK Vel-300mm/s Acc+30	6 ;First	
Program editor interface Program editor interface Program editor interface	7 PTP P0 CONT Vel=40% Acce=10% TOOL[0] BASE[0]	
10 wati šec 1 11 LIN PS6 FINE Vel-30m/s Acces08 TOOL[0] BASE[0] 12 LIN PS6 FINE Vel-20m/s Acces08 TOOL[0] BASE[0] 13 LIN PS6 FINE Vel-20m/s Acces08 TOOL[0] BASE[0] 14 LIN PS6 FINE Vel-20m/s Acces08 TOOL[0] BASE[0] 15 SV0[3] - FALSE 16 WATI SEC 1 17 LIN PS FINE Vel-100m/s Acces08 TOOL[0] BASE[0] 18 LIN PS FINE Vel-100m/s Acces08 TOOL[0] BASE[0] 19 SV0[3] - FALSE 10 WATI SEC 1 11 LIN PS FINE Vel-100m/s Acces100% TOOL[0] BASE[0] 12 LIN PS FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 13 SUNT SEC 1 14 LIN PS FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 15 SUN[3] - FALSE 16 WATI SEC 1 17 DF FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 12 LIN PS FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 13 LIN PS FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 14 LIN PS FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 15 SUN[3] - FALSE 16 LIN PS FINE Vel-200m/s Acces100% TOOL[0] BASE[0] 17 Program editor i	9 \$V031 = TNUE	
11 LIN P25 FINE Vel-50m/s Accesity TOOL[0] BASE[0] 12 LIN P25 FINE Vel-20m/s Accesity TOOL[0] BASE[0] 13 LIN P25 FINE Vel-20m/s Accesity TOOL[0] BASE[0] 14 LIN P14 FINE Vel-20m/s Accesity TOOL[0] BASE[0] 15 \$VO[3] = FALSE 16 WAT SEC 1 17 LIN P2 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 18 WIT SEC 1 19 VIN P2 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 10 WAT SEC 1 11 LIN P2 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 10 WAT SEC 1 11 LIN P2 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 20 WAT SEC 1 21 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 22 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 23 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 23 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 24 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 25 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 26 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 27 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 28 VPTOGRAM EDITION FIN	10 WAIT SEC 1	
12 LIN P26 FINE Vel-20m/s Accesity TOOL[0] BASE[0] 14 LIN P24 FINE Vel-20m/s Accesity TOOL[0] BASE[0] 15 SV0[3] = FALSE 16 WATT SEC [] 17 LIN P3 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 18 LIN P3 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 19 SV0[3] = FALSE 10 NATT SEC [] 11 LIN P3 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 20 WATT SEC [] 21 LIN P3 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 22 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 23 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 24 NATT SEC [] 25 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 26 NATT SEC [] 27 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 29 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 20 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 21 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0] 22 LIN P5 FINE Vel-200m/s Accesity TOOL[0] BASE[0]	11 LIN P25 FINE Vel=50mm/s Acc=50% TOOL[0] BASE[0]	
Lik P24 FINE Vel-200m/s Acc=30% TOOL[0] BASE[0] 14 Lik P24 FINE Vel-200m/s Acc=30% TOOL[0] BASE[0] 15 SW0[3] = FALSE WAIT SEC 1 17 Lik P2 FINE Vel-100mm/s Acc=100% TOOL[0] BASE[0] 18 Lik P3 FINE Vel-100mm/s Acc=100% TOOL[0] BASE[0] 19 SW0[1] = FALSE 10 WAIT SEC 1 21 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 21 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 22 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 23 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 24 WAIT SEC 1 25 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 26 WAIT SEC 1 21 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 22 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 23 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 24 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 25 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 26 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 27 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 28 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 29 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0] 20 Lik P4 FINE Vel-200mm/s Acc=100% TOOL[0] BASE[0]	12 LIN P26 FINE Vel=20mm/s Acc=50% TOOL[0] BASE[0]	
15 \$V0[3] - FALSE 16 WATT SEC I 17 LIN P2 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 18 LIN P3 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 20 WATT SEC I 21 LIN P4 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 23 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 24 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 25 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 24 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 25 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 26 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 27 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 28 HTM P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 29 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 29 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 29 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 20 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0]	14 [IN P43 FINE V2]=20mm/3 Arc=50% 100[0] DAS[0] 14 [IN P14 FINE V2]=20mm/3 Arc=50% 100[0] DAS[0]	
16 WATT SEC 1 17 LIN P5 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 18 LIN P5 FINE Vel=100mm/s Acc=100% TOOL[0] BASE[0] 29 WATT SEC 1 20 WATT SEC 1 21 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 20 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 23 LIN P5 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0] 24 Program editor interface	15 \$V0[3] = FALSE	
17 [LN P2 FINE Vel-100m/s Acce-100% TOOL[0] BASE[0] 18 LIN P3 FINE Vel-100m/s Acce-100% TOOL[0] BASE[0] 19 SV0[1] = FALSE 20 VAT SEC 1 21 LIN P4 FINE Vel-200mm/s Acce-100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel-200mm/s Acce-100% TOOL[0] BASE[0] 21 LIN P5 FINE Vel-200mm/s Acce-100% TOOL[0] BASE[0] 22 LIN P5 FINE Vel-200mm/s Acce-100% TOOL[0] BASE[0] 23 LIN P5 FINE Vel-200mm/s Acce-100% TOOL[0] BASE[0] 24 Program editor interface	16 WAIT SEC 1	
In PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 20 WATT SEC 21 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 22 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 23 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 24 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 25 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 26 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 27 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 28 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 29 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0] 20 UIN PS FINE Vel=200mm/s Acc=100% TOUL[0] BASE[0]	17 LIN P2 FINE Ve_1=00mm/s Acc=100% TOOL[0] BASE[0]	
20 WAT SEC 1 21 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 22 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 23 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 24 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 25 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 26 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 27 UN PS FINE VE-200mm/s Acc=100% TOOL[0] BASE[0] 20 UN PS FINE VE-200mm/s Acc=100% TOOL[0] 20 UN PS FINE	19 SVD11 = FAISF	
21 LIN P4 FINE Vel=200mm/s Acc=100% TOOL [0] BASE[0] 22 INN P5 FINE Vel=200mm/s Acc=100% TOOL [0] BASE[0] Program editor interface	20 WAIT SEC 1	
Program editor interface	21 LIN P4 FINE Vel=200mm/s Acc=100% TOOL[0] BASE[0]	,
Program editor interface	22 LITN PS FTNF Vel=200mm/c &cc=100% TOOLE01 R&SFE01	
	Program editor interface	
RC400000000 x	riogram cutor interface	
RC 400000000 v		
	DC4000000000	
KCH00000000 X	RCA0000000 X	
Start Pause Stop Home Step	Start Pause Stop Home Step	

Program running control button



Figure	Description
► Start	Start program, click button or press F5.
Pause	Pause program, click button or press F6.
Stop	Stop program, click button or press F7.
F Home	Return Home position, keep press button.
Step	Execute single step.
¢	Change program cycle or single step button.

When executing (2) the program with subroutines(1), the program will runs the subroutine (1), it will automatically display or switch to the subroutine. (1 in the figure below is a subroutine. 2 is the main program that is executing subroutine)

- Caterpillar 1.0.5	(2)			X
Add Robot Languages C	lose All About		2020/0	05/28 10:13:19	
45666 x					
Go On Pause	Stop T Home I Step	JOG	Display	1	R
Robot Setting	Robot Editor			Robot List	
Permission		0		C RSR - PNS	
•	test\A.hrb(Controller) test\test	hrb(Controller) *[new]		₹ X Controller	Local
Permission Monitor © Controller Mode Manual Auto	1: DEF a() 2 PTP P0 CONT=100 3 END 4 5 6	% Vel=100% Acc=100% 1	OOL[0] BASE[0]	RA605_Ptp_E ^ RA605_SetCr test b test	<pre>> c </pre>
Speed 10 < >	Position Point I/O Timer	Counter Alarm LogBo	ok Communication Start Up Fie	eldbus Tracking Display	
O Tool/Base	Angle				
Tool: 0 V Edit	A1 -6.956 -130	0	A3 0.000	-400	• 1
Base: 0 ~ Edit	A2 0.000 -150	٥	A4 0.000 (degree)	-360	360
Payload					
Mass (Kg) 1 🔗 Set	Cartesian				v
	v <				>
test\A.hrb					Held

Executing and subroutine window

5.8 Edit Program Page Function Description

Description



Program editor interface

No.	Description						
1	Create new file.						
2	Save file. Hot key: Ctrl+S						
3	Save all files.						
4	Increase indentation.						
5	Decrease indentation.						
6	Search a word in the editor. Hot Key: Ctrl+F						
7	Zoom in editor interface						
0	Command program code, the code is ignored, change to						
0	green word, or above the code add ";"(semicolon)						
9	Uncommand program code, the code can execute.						
10	Keyword tip, Hint(After highlighting the keyword, click on it,						
10	and a prompt will pop up), Hot Key: Selection+F1.						

! CAUTION

A running program can't be edited.



5.8.1 Editor State Description

Operating steps

Program background different color states:
 White background color –Local side edit file(s).
 green background color –Controller side edit file(s)
 Yellow background color - There are files that have been changed and have not been archived.

bb	.hrb(Local)	Abs.hrb(Controller) *a.hrb(Local)	Ŧ	x
1				
2				
3				

Local side interface(White background color)

bb.hrb(Local) Abs.hrb(Controller) *a.hrb(Lo	cal) 🗢 🗙
1 = ; LOOP	^
2 🛱 ; LOOP	
3 þ;LOOP	
4 🖯 ; LOOP	
5 ; LOOP	
6 0;LOOP	
7 🖻 ; LOOP	
8 0;LOOP	
9 i ; LOOP	v
<	>

Controller side interface(green background color)

bb	bb.hrb(Local) Abs.hrb(Controller) *a.hrb(Local) ~ X						
1	PTP	POINT	CONT=100%	Vel =100%	Acc=100%	TOOL	
2							
3							
<						>	

Edited and have not been archived interface (Yellow background color)

5.8.2 Comment Program Line(s)

Operating steps



- 1. Selected program codes (after highlighting the keyword), then click "Command" button, to ignore codes , the selected words change to green words.
- 2. Add semicolon ("; ") to the above of program line(s) that is selected to be commented.

5.8.3 Uncommand Program Line(s)

Operating steps

1.Selected program codes (after highlighting the keyword), then click "Uncommand" button, execute codes.

2.Remove semicolon (";") to the above of program line(s) that is selected to be uncommented.

5.8.4 Indent Program Line(s)

Operating Steps

1.Click [Indent] button.

*[n	ewj							
1	LOOF)						
2		PTP	P0	FINE=1	Vel=100%	Acc=100%	TOOL[0]	BASE[0]
3		PTP	Ρ1	FINE=1	Vel=100%	Acc=100%	TOOL[0]	BASE[0]
4		PTP	P2	FINE=1	Vel=100%	Acc=100%	TOOL[0]	BASE[0]
5	ENDL	.00P						

5.8.5 Cancel indent Program Line(s)

Operating Steps

1. Click [Unindent] button.

	*[r	*[new]								
	1	LOOP								
	2	PTP P0 FINE=1 Vel=100% Acc=100% TOOL[0] BASE[0]								
	3	PTP P1 FINE=1 Vel=100% Acc=100% TOOL[0] BASE[0]								
	4	<pre>PTP P2 FINE=1 Vel=100% Acc=100% TOOL[0] BASE[0]</pre>								
	5	ENDLOOP								
I										

5.8.6 Command Tip Button Description

Operating steps

1. Selected program codes(after highlighting the keyword) • Example:PTP • LIN...etc • and click [Hint] button, or hot key:press F1 button, display codes of example, user can click "INSERT" to insert the codes of example.



Robo	Robot Editor								
	🗋 🖬 💭 💀 🔍 X 🗩 💭 🌄								
*a. 1	hrb(Local) ptp	× [
	INSERT PTP								
	PTP POINT CONT=100% Vel=100% Acc=100% TOOL[0] BASE[0]								
		~							

PTP code of example figure



6.Conveyor tracking function application

6.10verview of the conveyor tracking system

The basic conveyor tracking system' illustration is as shown in the figure below.

The robot uses that the value changes from the encoder, which is installed on the conveyor to calculate the amount of movement of the conveyor. The sensors used to detect the relative position of the targeted workpiece on the conveyor; the sensors could be an optical sensors or vision systems. After receiving the value of the encoder and position information of the targeted workpiece, this info will returned to the robot controller, the robot will run the conveyor tracking function accordingly.





6.1.1 Description of the conveyor tracking application process

The robot read the encoder value on the conveyor to detect the displacement of the conveyor, and communicate with vision systems or sensors to trigger signals.

The following uses sensors method for a simple explanation (The visions method is similar).

When the sensor triggers the signal, the robot will get a queue. When the target workpiece enters the selective action range of the robot, the robot will start the conveyor tracking function to execute pick or place actions. If the target workpiece exceeds the selective action range of the robot, the robot will discard the queue.

The overall work process can be divided into several processes, (1). Hold until detecting the status of the



workpiece (2). Detect the status of the workpiece (3). Workpiece enters the working range of the robot (4). Robot pick up the workpiece (5). Robot successfully picks up one workpiece or (6). Workpiece 1 exceeded the working range (robot did not pickup the workpiece).



Conveyor pick & place process flow chart

The following chapter will explain the various statuses and corresponding handling processes when the robot executes the conveyor tracking function.



6.1.1.1 Sensor waits to detect the status of the workpiece:

Robot status (1), as shown in the figure below, workpiece 1 (orange color object) is placed on the conveyor, and is moving through the conveyor. At this time, the encoder value is 50 pulses. When the sensor has not yet detected workpiece 1, the robot did not receive the trigger signal. Therefore, there are no queues and the robot is in stand-by status. The statuses are as shown in the list below:



Sensor waiting to detect workpiece illustration

Robot status (1) list					
Encoder tracking signal	pulse=50				
Encoder pick workpiece signal	pulse=0				
Queue	None				
Robot execution status	Ready				

6.1.1.2 Sensor detects the status of the workpiece:

Robot status (2), workpiece 1 is placed on the conveyor and is moving through the conveyor. At this time, the encoder value is 100 pulses. When the sensor detects workpiece 1, the robot will receive the trigger signal. At this time, the robot will record the encoder value, and the queue count will increase by one. But since the workpiece has not yet entered in between the upper and lower limit action range of the robot, therefore, the robot is in stand-by status; the statuses are as shown in the list below:



Sensor detects the workpiece illustration



Robot status (2) list								
Encoder tracking signal	pulse=100							
Encoder pick workpiece signal	pulse=100							
Queue	Queue1							
Robot execution status	Ready							

6.1.1.3 Workpiece enters the working range of the robot:



Workpiece enters the working range of the robot illustration

Robot status (3), workpiece 1 is placed on the conveyor and is transported through the conveyor. At this time, the encoder value is 150 pulses. When the workpiece enters upper limits of action range of the robot, the robot starts executing actions; the statuses are as shown in the list below:

Robot status (3) list								
Encoder tracking signal	pulse=150							
Encoder pick workpiece signal	Queue1 pulse=100+50							
Queue	Queue1							
Robot execution status	Ready							

6.1.1.4 Robot executes pick workpiece:

Robot status (4), workpiece 1 is placed on the conveyor and is transported through the conveyor. At this time, the encoder value is 200 pulses. Parallelly, the robot is executing the pick action; since the robot already picked up workpiece 1, therefore, the encoder stops recording the value temporarily; the statuses are as shown in the list below:





Robot executes pick workpiece illustration

Robot status (4) list							
Encoder tracking signal	pulse=200						
Encoder pick workpiece signal	Queue1 pulse=100+100						
Queue	Queue1						
Robot execution status	Pick						

6.1.1.5 Robot successfully picked up workpiece:

Robot status (5), workpiece 1 is placed on the conveyor and is transported through the conveyor. At this time, the encoder value is 215 pulses. Since the robot already finished executing the action, therefore, the queue has ended, and the count subtracts one; the statuses are as shown in the list below:



Robot successfully picked up workpiece illustration

Robot status (5) list								
Encoder tracking signal	pulse=215							
Encoder pick workpiece signal	Queue1 pulse=100+100							
Queue	Remove							
Robot execution status	Place							



6.1.1.6 Workpiece exceeded the working range of the robot:

Robot status (6), workpiece 1 is placed on the conveyor and is transported through the conveyor. At this time, the encoder value is 425 pulses. Since workpiece 1 already exceeded the lower limit of action range of the robot, therefore, the queue was discarded, and the count subtracts one; the statuses are as shown in the list below:



Workpiece exceeded the working range of the robot illustration

Robot status (6) list								
Encoder tracking signal	pulse=425							
Encoder pick workpiece signal	Queue1 pulse=100+315							
Queue	Queue1 remove							
Robot execution status	Queue1 discarded							

This example is used to explain the possible statuses before picking with conveyor tracking; operators must first understand the situation of each status and their relationships with the corresponding queues in order to know the content of the tasks that need to be processed later.



6.2 Layout of the conveyor tracking system configuration

6.2.1 Description of the system configurations/specifications

The basic system configuration is as shown in the figure below:



Conveyor tracking (pick-on-the-fly) system configuration architecture diagram



Peripheral equipment specifications sheet

Robot & Controller	The conveyor pick-on-the-fly function can be used on the SCARA LU series robots and parallel robots. Refer to the conveyor's manual for if there are problems with the conveyor, and refer to RC4 or GB/GC controller for problems with the controller.
Conveyor	Conveyors with linear movements, such as roller conveyors, flat belt conveyors, and timing synchronous conveyors, can be used.
Encoder	Differential output rotary incremental type encoders can be used. Example: Omron incremental type with an outer diameter of ϕ 50 E6C2-C and 2,000P/R resolution.
Sensor	Contrast, reflective, retroreflective and limited reflective sensors can be used; laser sensors can be used for high-precision measurements. Example: Omron contrast type E3T-ST31 2M
Vision system	The communication arrangement of the vision system must meet the communication arrangement defined by HIWIN Technologies Corp.; please refer to Chapter 6.3 Description of communication formats.

Note 1: Please select the above specification based on the physical requirements.

Note 2: The speed which is selected for the conveyor specification must be constant.

Note 3: For the installation of the encoder, the axis must be parallel to the surface of the conveyor,

and cannot be inclined with the surface of the conveyor (a small amount of downforce is recommended).

6.2.2 Basic installation process

1.System configuration: Perform hardware settings such as system configuration, robot installation, conveyor configuration, vision system installation, and system power distribution. There all are done according to the different work applications.

2.Function setting: Set the conveyor tracking related parameters; the main ones include selecting the trigger method (sensor or vision system), set the workpiece height and IP setting for the vision system, etc.



3.Conveyor and coordinate system calibration: This mainly includes coordinate system calibration, work range calibration and conveyor ratio calibration. If vision systems are used, then coordinate system calibration must be performed for the robot and vision system.
4.Program writing: Based on the system configuration and setting, write the conveyor tracking instruction and plan the actions of the robot.



6.2.3 Description of electrical wiring connection

This chapter explains the wiring of the robot controller and encoder.

6.2.3.1 Description of the encoder module input terminal (Encoder Socket) The EtherCAT encoder module is an optional purchase accessory; when users specified that they need an encoder modules before the product are shipped, the optionally purchased network cable will be installed with the RC4 controller. The other end of the network cable will be exposed outside the RC4 controller. An additional expansion module will also be shipped for users to install in their electronic control panel equipment (module can be fixed in-place using aluminum extrusions that are commonly used industrially).





Encoder network roadmap after the optionally purchased encoder module is shipped

There are 3 set of channels for the encoder input terminal, which are CNV1~CNV3; each phase signal is a differential signal. Therefore, each phase signal has two types of signals + and -. Each set of channel has its own input trigger (latch) contact; the signal specification is DC24V, which are IDI1~IDI4 respectively. The IDICOM type can be changed to NPN or PNP based on its usage method. The figure below is an overview of the encoder input pins.



Encoder module appearance diagram Note: For related information, refer to the ICP DAS official website:<u>https://www.icpdas.com</u>



Description:

The encoder data capture module is used with the encoder, and its power pin definitions are as shown in the below figure.



Please use differential output of rotary incremental type encoders (optional purchase).

F.G. GND +Vs

IN

OUT



Signal pins	Pin definitions					
F.G	Frame Ground (ground)					
GND	Power supply: Ground 0V (From the negative charge contact)					
+Vs	Power supply: +24V _{DC} (from the positive charge contact)					
IN	EtherCAT signal input (signal input)					
OUT	EtherCAT signal output (signal output)					

Encoder module connection sockets and wiring diagram

Encoder input overview:



Encoder input pin diagram



Encoder capture module usage range is as shown in the figure below.



OMRON E6B2-CWZ1X

Usage example diagram using one encoder and one sensor

Pin signal	Pin definitions	Description
A0+	Encoder input A0+	
A0-	Encoder input A0-	
B0+	Encoder input B0+	Channel 0
B0-	Encoder input B0-	(Encoder channel 0)
C0+	24 VDC	
C0-	Latch NPN out	
A1+	Encoder input A1+	
A1-	Encoder input A1-	
B1+	Encoder input B1+	Channel 1
B1-	Encoder input B1-	(Encoder channel 1)
C1+	24 VDC	
C1-	Latch NPN out	
A2+	Encoder input A2+	
A2-	Encoder input A2-	
B2+	Encoder input B2+	Channel 2
B2-	Encoder input B2+	(Encoder channel 2)
C2+	24 VDC	
C2-	Latch NPN out	

Encoder capture module pin description table

Note: Encoder input is encoder input, Latch NPN out is the NPN trigger signal of the sensor.



Refer to the below figure for the encoder setting relationship in the conveyor tracking setting interface, Interface path: Conveyor tracking>> Setting>>Tracking.



Encoder channel and software setting interface relationship window

Note 1: Cable specifications & extension features recommendations:

Recommended cable specifications: PW15-W48-A017, CAT 6, 26AWG (Refer to the controller manual optional accessories)

The rising time of the waveform output will change according to the cable length, load resistance and cable type.

If the cable is extended, the rising time of the waveform output will increase, affecting the phase difference features of phases A and B; they will differ according to conditions such as frequency and noise.

Note 2: Encoder only need to connect phases A and B; phase C is used for the input signal of external sensors. Note 3: Encoder input; Latch NPN out is the NPN trigger signal of the sensor.

Note 3: For related information of the encoder module, refer to the ICP DAS official

website:<u>https://www.icpdas.com</u>.



6.2.3.2 Encoder connection method for single pick tasks Refer to the external devices connection method, as shown in the figure below:



Encoder connection-pick illustration

Note 1: The configuration in the figure above is a NPN type.



6.2.3.3 Encoder connection method for single placement tasks Refer to the external devices connection method, as shown in the figure below:



Encoder connection-place illustration

Note 1: The configuration in the figure above is a NPN type.



6.2.3.4 Encoder connection method for the combination of pick and place tasks

Refer to the external devices connection method, as shown in the figure below:





Note 1: The configuration in the figure above is NPN a type.



6.3Explanation of conveyor tracking system communication format

6.3.1 Description of HRSS conveyor tracking and machine vision communication timing

This chapter explains the series of actions of the robot and machine's vision communication and input/output trigger sequence by using the below communication networking diagram and communication sequence diagram.

Communication network diagram

The contents of this communication network case explain the integration of the robot controller, machine vision system and encoder. In which the robot controller includes the encoder capture card and HIWIN's robot software system (hereafter referred as HRSS), and the remote connection system (hereafter referred as Caterpillar). The machine vision system includes cameras.



Conveyor tracking vision and encoder communication network diagram

In the above encode communication network , the communication method between the machine vision and robot is network transmission (TCP/IP), and in terms of the definition of the connect, the vision system must be the server (slave terminal) and HRSS/Caterpillar is the client (master terminal). The encoder capture cards in the encoder and robot controller are connected using physical networks; the transmission signal is a differential signal. The encoder count value capturing action of the robot controller's encoder capture card is triggered by the encoder count value capture signal sent by the camera; it is triggered by physical circuits. Users must confirm that the encoder capture signal and the time the cameras take photos are triggered simultaneously; prevent delays from occurring when triggering. Confirm that the conveyor tracking action is accurate. In this case, the encoder capture signal uses the physical signal of the camera's exposure trigger signal as the encoder count value capture signal.



Communication sequence diagram

This contents of this communication sequence diagram for conveyor tracking explains the integration of the robot controller, machine visions and encoder. Sensors can be added according to different usage needs to be used as the trigger signal source for taking photos, or add vision exposure signals. There is a total of six steps to explain; the explanations are as below:



Communication sequence diagram for conveyor tracking

The communication sequence diagram for conveyor tracking explained in six steps as follows:

⇒Step 1: Execute the conveyor tracking instruction (CNV_START)

When the robot executes the conveyor tracking function, the CNV_START instruction must be executed at first. This instruction used to enable the setting and communication of conveyor tracking related functions. CNV_START might stop by three ways, which are: when the CNV_STOP instruction is executed, when the error signal is triggered or when the process was actively stopped.

⇒Step 2: Connect HRSS and machine vision

When the robot and machine vision are connected successfully, HRSS/Caterpillar will send the packet {CNV#}, which means it can now accept the packet transmission from the vision system. This packet will only be sent once when connection was successful. In which the CNV# in the large bracket is the conveyor number selected for tracking.

For example, the conveyor number that the user selected for tracking is 2 (CNV=2), therefore, when the robot and machine vision are connected successfully, the robot will return the packet {2} to the machine vision.

⇒Step 3: Encoder count value capturing and camera imaging



Since the machine vision itself has no installed encoder capture card, therefore, the timing for camera imaging and the encoder count value capture triggering must be done simultaneously. If there were delays between the imaging timing and encoder count value capture trigger signal, when the robot is performing tracking, the conveyor direction will fall behind.

In this case, the camera imaging and exposure time are almost simultaneous, therefore, the exposure signal is used as the trigger signal for the robot controller's encoder count capture value.

⇒Step 4: Encoder count value capture signal and encoder trigger value

When the encoder count value trigger signal is triggered, the encoder trigger value will update the encoder value. The maximum processing time for the encoder trigger value is approximately 0.8 milliseconds (ms).

⇒Step 5: Machine vision transmission packet and encoder value reading

After the machine vision processed the image, packet transmission should be performed according to the communication format. After HRSS/Caterpillar receives the packet, it will read the current encoder value and queue the object information in the packet and encoder value. If HRSS/Caterpillar received the wrong packet, HRSS/Caterpillar will ignore the wrong packet. If the machine vision takes photos at fixed times, when the shooting frequency is faster than the machine vision's processing time, or the encoder value was updated before HRSS obtained the encoder value, the reasons above will all cause incorrect alignment between the packet and the encoder value.

\Rightarrow Step 6: Object enters queue and ACK packet is returned

After HRSS/Caterpillar received the correct packet and finished queuing the object, it will return the ACK packet to the machine vision. The content of the ACK packet is {CNV#}, in which the CNV# in the large bracket is the conveyor number selected for tracking.

If the conveyor number that the user selected for tracking is 1 (CNV=1), when the robot and machine vision are connected successfully, the robot will return the packet {1} to the machine vision.

After the machine vision receives the ACK packet, it should continue to trigger photo-taking and encoder value capture signal.

Refer to the message flow illustration in the figure below.





Communication architecture message flow illustration



6.3.2 Communication format and example description

Packet format that the vision system sends to HRTS:

Packet format = { n, CNV_#, EN, OBJ_#, X_n, Y_n, Θ_n }

= { [total number of packets], [conveyor number], [encoder value], [object type number], [X coordinate of the n object number], [Y coordinate of the n object number], [Θ_n angle of the n object number] }

Format/parameter description:

⇒The packet format begins and ends using large brackets "{ }", and the comma "," is used as the separator.

⇒n: The total number of dispatched objects in this packet data must be a positive integer, n =

1,2,3,...,50; 1 packet dispatched object includes 1 set of [X, Y, Θ] coordinate information.

Similarly, n packet dispatched objects include n sets of [X_n , Y_n , Θ_n] coordinate information.

 \Rightarrow CNV_#: The conveyor number that corresponds to this packet data, #=1,2,3,4.

 \Rightarrow EN: The encoder value that corresponds to the image; it must be a positive integer.

 \Rightarrow OBJ_#: Object type number, #=1~8.

 $\Rightarrow X_n$: X coordinate of the object number n.

 \Rightarrow Y_n: Y coordinate of the object number n.

 $\Rightarrow \Theta_n$: Θ rotation angle of the object number n. (This rotation axis is $\overline{U_Z} = \overline{U_X} \times \overline{U_Y}$, which is the fourth axis rotation angle).

 \Rightarrow The maximum number of objects in a single packet is 50; the string length of the packet can contain a maximum of $2^{12} = 4096$ characters.

 \Rightarrow If the contents of the packet data sent by the vision system did not include EN encoder value, it will be represented by "NA".

 \Rightarrow Positive values can be expressed as "Xn" or "+ Xn" , negative values can be expressed as "-

 X_n "; numbers can contain a maximum of 14 characters.

Example Communication format & its explanation:

Example 1 description: (A single conveyor tracking, 1 object and 1 set of coordinate values.) ⇒The packet data is: { 1, 1, 3000, 1, X₁, Y₁, Θ₁ }

Total	Conveyor	Encoder	Object	Х	Y	Rotation	
number of	number	value	type	coordinate	coordinate	angle	
objects							
1	1	3000	1	X ₁	Y ₁	Θ1	

Description: Total number of objects in this packet is 1, the corresponding conveyor number is 1, the corresponding encoder value is 3000 pulses, the object type of the 1st object is type 1, and its coordinates and angle are expressed as X1, Y1, O1.



Example 2: (A single conveyor tracking, no corresponding encoder, 2 objects and 2 coordinate values.)

Total number of objects	Conveyor number	Encoder value	Object type	X coordinate	Y coordinate	Rotation angle
2	1	NA	1	X1	Y_1	Θ1
2	T	INA	2	X ₂	Y ₂	Θ ₂

 \Rightarrow The packet data should be: { 2, 1, NA, 1, X₁, Y₁, Θ_1 , 2, X₂, Y₂, Θ_2 }

Description: The total number of objects in this packet is 2, the corresponding conveyor number is 1, there is no corresponding encoder and is expressed as NA, the object type of the 1st object is type 1, and its coordinates and angle are expressed as X1,Y1,O1; the object type for the 2nd object is type 2, and its coordinates and angle are expressed as X2,Y2,O2.

Example 3: (A single conveyor tracking, 4 objects and 4 sets of coordinate values.)

⇒The packet data should be: { 4, 1, 3000, 1, X₁, Y₁, Θ₁, 1, X₂, Y₂, Θ₂, 2, X₃, Y₃, Θ₃, 3, X₄, Y₄, Θ₄ }

Total number of objects	Conveyor number	Encoder value	Object type	X coordinate	Y coordinate	Rotation angle
			1	X1	Y ₁	Θ1
Л	1	2000	1	X ₂	Y ₂	Θ2
4	T	5000	2	X ₃	Y ₃	Θ3
			3	X4	Y ₄	Θ4

Description: The total number of objects in this packet is 4, the corresponding conveyor number is 1, the corresponding encoder value is 3000 pulse, the object type of the 1st object is type 1, and its coordinates and angle are expressed as X1,Y1,O1; the object type for the 2nd object is type 1 (the same object type can be repeated), and its coordinates and angle are expressed as X2,Y2,O2; the object type of the 3rd object is type 2, and its coordinates and angle are expressed as X3,Y3,O3; the object type for the 4th object is type 3, and its coordinates and angle are expressed as X4,Y4,O4.



6.4Conveyor tracking object parameter setting

This chapter will start explaining the interface parameter settings of the conveyor tracking function; refer to Track Setting

Interface path: From the tab window at the bottom, select Tracking >> Setting; it is then divided into 4 tabs, tracking interface (Tracking), motion interface (Motion), custom packet interface (Ack Package) and the conveyor's digital input/output interface (DI/DO). The following chapter will describe these using different sections:

	Position	Point	t	I/O	Timer	Count	er 🛛 A	larm	Log	Book	Communi	cation	Start Up		Fieldbus	Trac	king:	Display	Mastering
	Setting	Visio	on Set	ting Visio	n Object	Sensor (Dbject	Calibra	tion	Monito	or								
Т	Tracking	Mo	tion	Ack Pack	age DI/D	0													
	ITEN	1	D	O Delay	DI Trigg	er Type	DI	Detect Ti	me	DI Ke	ep Time	S	trategy						
	CNV	1		-25	TRUE	-		300			50	Rei	move	•					
	CNV2	2		-25	TRUE	-		300			50	Rer	move	•					
	CNV	3		-25	TRUE	-		300			50	Rei	move	•					
	CNV4	4		-25	TRUE	•		300			50	Rei	move	•					
	Static(C	N		-25	TRUE	-		300			50	Rei	move	•					
		SAV	E																
				_															

Conveyor tracking setting interface



6.4.1 Description of conveyor tracking interface settings

This chapter explains the various parameter settings for conveyor tracking; please refer to the descriptions in the below figure and table.

Path: select Tracking >> Setting >> Tracking.



Conveyor tracking setting interface illustration window

Conveyor tracking	setting	interface	illustration	table
-------------------	---------	-----------	--------------	-------

NO.	Name	Description				
1	CNV STATE	Selecting "Used" enables to use this conveyor and selecting "Not Used"				
T	Conveyor usage status	disables this conveyor.				
2	DIRECTION	Selecting "Forward" will lead the conveyor in the positive direction ;				
Z	Conveyor count direction	selecting "Reverse" will lead the conveyor in the reverse direction.				
2	TRIGGER TYPE	Selecting "Vision" uses image trigger methods, selecting "Sensor" uses				
3	Trigger tracking type	sensor trigger methods.				
		Conveyor tracking status variable, only applicable for sensor trigger				
		methods. When the sensor on the conveyor is triggered, the robot will				
Λ	TRIGGER TIMES	receive a pick-on-the-fly or place-on-the-fly queue. This variable can set				
4	Trigger tracking times	the number of times the sensor must be triggered before the queue will				
		increase by one. It is a positive integer type, and the setting input range				
		is 1 to 100 times; the default value is 1 time.				
		Place-on-the-fly status variable; it is used when several objects need to				
		be placed-on-the-fly in the same queue position. When the sensor on				
		the release object conveyor is triggered, the robot will receive a queue				
5		position where place-on-the-fly can be executed, and the maximum				
	Place times	number of place-on-the-fly times for the robot at this queue position				
		can be set by this variable. It is a positive integer type and the setting				
		input range is 1 to 100 times; the default value is 1 time.				



NO.	Name	Description
	ENC SOURCE	The conveyor encoder copy function is used for shared reference of
6	Encoder source selection	conveyor encoder value; the IDI status or trigger latch value will not be
		copied, and the default value is the conveyor encoder number itself.
7	Save button	Saves setting parameters.

Example description:

⇒<u>Description of encoder source selection (ENC SOURCE)</u>:

The conveyor encoder copy function only copies the encoder value, it will not copy the IDI status or trigger (latch) value; the default value is the numbering itself, and it can be adjusted so that two entities can share and refer to the same encoder value. As shown in the example below: CNV1 is connected to a physical encoder signal, CNV2 copies the encoder signal of CNV1, and they triggered IDI1 and IDI2 respectively and received the queues Queue02, Queue04 and Queue06. The timing diagram is as shown below.



Encoder source selection timing diagram



6.4.2 Description of conveyor motion interface settings

This chapter explains the various parameter settings for conveyor motions; please refer to the descriptions in the figure and table below.

Path: In the tab window below, select Tracking >> Setting >> Motion.

P	osition	Point	I/	0	Ti	imer	Counter	Alarm	Log	Book	Commu	nication	Start Up	Fieldbus	Tracking	Display	Mastering
	Setting	Visio	n Settin	ng V	ision C	Object	Sensor Obje	ct Cali	oration	Monit	or						
	Tracking	Mot	ion	Ack F	Packag	e DI/D	00										
	ITEN	M	Track	cing D)elay	Trac	king Acc	Min La	tch Cnt	Co	ompare N	b C	ompare Dis	it 🛛			
	CNV	/1		0			40	()		0		0.00				
	CNV	/2		0			40	()		0		0.00				
	CNV	/3		0			40	()		0		0.00				
	CNV	/4		0			40	()		0		0.00				
	Static(C	NV0)		0			40	()		0		0.00				
		,	()	(2	(3		4		5				
		SAVE		-			-6										

Conveyor motion setting interface illustration window

Conveyor motion setting interface illustration table

NO.	Name	Description		
1		This sets how long the object should be followed before the pick-up		
	Tracking Delay	action. The unit is milliseconds (ms) and the setting range is 0~1500		
		ms; the default value is 0 ms. (Please refer the diagram below)		
		The acceleration and deceleration time used to synchronize with the		
	Tracking Acc	conveyor. The unit is millisecond (ms), the setting input range is 4 $^{\sim}$		
2	Tracking acceleration	1000 ms and the default value is 40 ms. The smaller the value, the		
		faster the acceleration or deceleration. (Please refer the diagram		
		below)		
		Only applicable to sensor triggered filter function, the minimum		
		trigger interval is that delaying (masking) the next signal receipt after		
	Min latah Cat	the signal is triggered (Latch). Mainly used to prevent false triggering		
3		caused by signal interference and resulting into the robot		
	winimum trigger interval	malfunctions. The unit is pulse, and users can adjust and set the		
		minimum trigger interval according to actual operation situations; the		
		default value is 0. (Please refer the example below)		
4	Compare Nb	Only applicable to Vision triggered filter functions; this setting value		
	Compare object settings	denotes the number of matching data with a repeated identified		



NO.	Name	Description
		 objects. The setting input range is 0 ~ 20, and the default value is 0, which means disable this function. The recommended setting is to set the maximum number of objects shot in a single image; it must be set with the comparison distance
		(Compare Dist) in order to this function to be effective. Set the filter buffer size; this size affects the comparison distance with the multiple previously confirmed triggered objects when the vision receives information on new objects, and then determines whether to trigger the object
5	Compare Dist Comparison distance setting	Only application to Vision triggered filter function, this setting value determines the threshold for the comparison distance length; the unit is millimeters (mm) and the default value is 0.00mm. The recommended setting is to set as the inscribed circle diameter length of the smallest object in a single image; it must be set with compare object settings (Compare Nb) in order for this function to be effective.
6	Save button	Saves setting parameters.


Example description:



⇒ <u>Description of Tracking Delay</u>, example with delay set to 50ms:

Conveyor tracking delay time setting illustration diagram

⇒ <u>Tacking acceleration time setting Tracking Acc illustration</u>, the default value is 30ms:



Conveyor tracking acceleration time setting illustration diagram

⇒<u>Minimum trigger interval count setting (Min Latch Cnt) example:</u>

For example: The difference between the previous latch object and the current latch object pulse (20) is smaller than the threshold value set for count (25); therefore, the current triggered object (Queue 2) will be ignored. The default value is 0 (which means this function is disabled). As shown in the figure below, there are three objects on the conveyor, and the minimum trigger interval counties set to 25; therefore, Queue2 (task 2) will be ignored while Queue 1 and Queue3 have normal pick intervals.





Conveyor tracking minimum trigger interval count setting illustration diagram

⇒Description of <u>compare object setting (Compare Nb)</u> and <u>compare distance setting (Compare Dist.)</u>: Description of 4 different filter examples by setting compare object setting (Compare Nb) as 2 with different comparison distance (Compare Dist.) settings.

Filter example 1: Ready Queue1 (Queue1 that is prepared and ready) is the first data entry and has no previous data entry that can be compared to; therefore, Ready Queue1 will be successfully kept as Queue1. This is when the workpiece is more independent and distributed.



Compare Nb and Compare Dist. example 1



Filter example 2: Relative distance comparison will be performed for Ready Queue2 with the Queue1; if it is greater than the value set for Compare Dist., Ready Queue2 will be successfully kept as Queue2. This is when the workpiece is more concentrated and is outside the distance range.



Compare Nb and Compare Dist. example 2

Filter example 3: Relative distance comparison will be performed for Ready Queue3 with the data of Queue1 and Queue2. If one of the data entries is smaller than the value set for Compare Dist., the Ready Queue3 data will be filtered out. This is when the workpiece is more concentrated and is within the distance range.



Compare Nb and Compare Dist. example 3



Filter example 4: Relative distance comparison will be performed for Ready Queue4 with the data of Queue1 and Queue2. If it is greater than the value set for Compare Dist., Ready Queue4 will be successfully kept as Queue3 (at the Ready Queue4 position). This is when the workpiece is more distributed and is outside of the distance range.



Compare Nb and Compare Dist. example 4

From the filter results of these four workpiece examples, the sequence of what was finally received is 3 queue entries (Queue1 ~ 3).



Compare Nb and Compare Dist. example filter results



6.4.3 Description of conveyor custom packet interface settings

Allows users to customize the contents of the signal packet returned by vision; it is applicable to the packet setting of different vision brands. The initial default is to return the "{conveyor number}". Path: In the tab window below, select Tracking >> Setting >> Ack Package.

[Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Ī
ľ	Setting	Vision Set	tting Visio	n Object	Sensor Obje	ct Calibr	ation Moni	tor				
	Tracking	Motion	Ack Pac	kage DI/	DO							
	● D: ◎ U:	efault – ser Defined				_(2)				
		SAVE			-3							

Interface diagram for customizing packet format

Illustration table for	customizing	packet format	returned	by vision
------------------------	-------------	---------------	----------	-----------

NO.	Name	Description
1	Default value	The initial default is to return the "{conveyor
L L	options	number}"
	Lloor dofined	Customize the signal packet content returned
2	Oser-defined	by the vision; it is applicable for different vision
	options	camera packet settings.
3	Save button	Saves setting parameters.



6.4.4 Description of conveyor digital input/output interface settings

The advancing or delaying of digital input and output signals can be controlled in conveyor tracking system; the following are the settings' descriptions.

Position	Point	I/O		Timer	Cou	inter	Alarm	Log	Book	Commur	ication	Start Up		Fieldbus	Tracking
Setting	Vision S	etting	Visior	n Object	Senso	r Obje	ct Calibra	tion	Monit	or					
Tracking	Motior	Ac	k Pack	age DI/	00										
ITEN	1	DO De	lay	DI Trig	ger Typ	be	DI Detect Ti	me	DI K	eep Time	9	Strategy			
CNV:	1	-25		TRU	E	•	300			50	Re	move	•		
CNV	2	-25		TRU	E	•	300			50	Re	move	•		
CNV	3	-25		TRU	E	•	300			50	Re	move	Ŧ		
CNV	4	-25		TRU	E	•	300			50	Re	move	•		
Static(C	N	-25		TRU	E	•	300			50	Re	move	•		
			I	2)		3)		4)	5	>		
	SAVE			(6										

Path: In the tab window below, select Tracking >> Setting >> Ack Package.

Conveyor digital input/output interface window

Conveyor digital input/output setting illustration table

NO.	Name	Description
		Sets the digital output (\$DO[]) time to open when robot tracking is in-
1	DO Delay	place; positive and negative values can be used to move up or delay the
T	Digital output delay	action time. The allowed input range is -1500 to 1500, and the unit is
		millisecond (ms).
С	DI Trigger Type	On/Off status setting when the robot picked up an object; the menu
2	Digital input trigger types	includes two options "TRUE" or "FALSE", and the default value is TRUE.
	DI Detect Time	The time to maintain digital input (\$DI[]) detection after the digital
3	Digital input detection	output (\$DO[]) signal is sent. The default value is 300; allowed input
	time	range is from 1 to 1500 and the unit is millisecond (ms).
		The duration to detect digital input (\$DI[]); only when this time is
л	DI Keep Time	exceeded will the detection of digital input (\$DI[]) be determined. The
4	Digital input duration	default value is 50; the allowed input range is 1 to 1500, and the unit is
		millisecond (ms).
	Stratogy	During picking, when the response strategy is detected for the digital
5	Bosponso stratogy	input (\$DI[]), the menu includes two options "Retry" or "Remove"; the
	Response strategy	default value is Remove.
6	Save button	Saves setting parameters.



Example description:

⇒Description of <u>digital output delay (DO Delay)</u>:

The parameters must be set as integer type, and the time count begins from the downforce position. If the quantity was not specified, the default value is -25ms, and the allowed input range is -1500 to 1500 ms. A positive value represents delay time and a negative value represents move up advancing time. The default value of output digital signal is 25 ms earlier.



Digital output delay (DO Delay) illustration diagram

⇒<u>Digital input (DI) trigger type</u>:

On/Off status setting of the digital input signal when the robot picked up an object; the default value is TRUE.

⇒<u>Digital input (DI) detection time</u>:

The time to detect digital input signals after the robot has picked up an object and the digital output (\$DO[]) signal was sent. The parameter setting is in floating-point number type, and the default value is 300 ms. The allowed input range is from 1 ms to 1500 ms.

⇒<u>Digital input (DI) duration Keep Time</u>:

This the duration of the digital input signal. The parameter setting is in floating-point number type, and the default value is 50 ms. The allowed input range is from 1 ms to 1500 ms.

⇒<u>Response strategy</u>:

When response strategy of the digital input DI signal is detected during pick up, the default value is the Remove strategy.





Digital input trigger, detection and duration signal of the conveyor illustration diagram After completing the basic settings for the parameters of the conveyor tracking object, the following is the description related to calibration.



6.5Conveyor tracking vision image parameters

This chapter will explain how to use the conveyor tracking vision image parameter settings. This chapter can be skipped if the sensor trigger function is used.

Path: In the tab window below, select Tracking >> Setting >> Vision Setting.

Image parameter setting interface



Conveyor image parameter setting interface diagram

NO.	Name	Description					
1	Conveyor number	Select the conveyor number tab to set; there is a total of 4 tabs, CN1 $^{\sim}$					
Ţ	tab	CN4.					
	Calibration	Calibration template distance setting; the X and Y length value of the O					
2	template distance	point and P point in the template must be set. The unit is millimeter					
	setting	(mm).					
	Vision connection	The IP and port of the vision must be set; its vision IP and local IP must					
3	sotting	have the same network domain settings (the first 3 digits of the IP must					
	setting	be the same).					
		Clears the conveyor encoder count value and resets it to zero; the					
		current position of the vision origin position setting will be 0. After					
4	Reset button	resetting, users can go to the monitor page to confirm that the encoder					
		value has been reset to zero. The reset to zero action must be performed					
		before vision calibration.					
5	Save button	Saves setting parameters.					

Conveyor image parameter setting table



⇒<u>Instructions</u>:

1.Select the conveyor number (CNV1~CNV4) to track, and record the setting information on the image parameter page according to the conveyor number separately. Therefore, please select the number first when setting parameters, then press Save after setting is completed. . 2.Before using the conveyor tracking function, the corresponding coordinate position (mm) of the calibration point in the image system must first be set; this is the distance from the origin of the calibration template to the calibration point. Set the values of POINT X Y as the straight-line distance between X and Y of P point and O point (the value is a positive integer). As shown in the diagram below, O point is the origin, and the distance between P point at the top-left and O point at the bottom-right is 130X130mm; therefore, enter the value 130 for the X distance length and enter the value 130 for the Y distance length.



Calibration template sample diagram

3. Vision Connection Setting:

1)Vision IP: Must be set as the same as the vision system IP.

2)Vision port: Must be set as the same as the vision system port.

3)Local IP:Click menu and select IP1 (top network socket) or IP2 (bottom network socket), and set the local IP address. The first 3 value of the IP must be the same as the vision system IP; the 4th byte can be compiled by the user, but cannot be the same as the vision IP.

Note 1: The coordinate system of the robot must be the same as vision calibration; the coordinate system is based on the right-hand rule.

Note 2: IP1 and IP2 cannot be used as sockets simultaneously (COPEN(ETH,...instruction cannot be used twice).



4. Vision origin position setting:

1)The encoder value must be zero; reset the encoder count value on the conveyor to zero when vision calibration is performed for the calibration template.

 \rightarrow Click the "Reset" button and confirm that the Now value is zero.

2)Vision Count: Relative offset value setting must be set for the encoder value corresponding to vision recognition; unit: pulse count. It can be changed from here. If it doesn't need to be used, the value must be set as zero.

5.Once the above settings are completed, click the "Save" button to save the parameters set. Remember to press Save before changing/switching to another tabs.



⇒Example description for setting vision image parameters:

Example:

Set the conveyor as CNV1, set the X axis length as 130mm, set the Y axis length as 130 mm, and set the vision count as 0

Set the vision IP as 192.168.0.101, set the vision port as 9876 and set the local IP as 192.168.0.5.

Position	Point	I/O	Time	er Counter	Alarm	LogBook	Communicati	on Start Up	Fieldbus	Tracking	Display	Mastering
Setting	Vision Se	etting	Vision Obje	ect Sensor Obje	ct Calibra	ation Mon	itor					
CNV1	CNV2	CN	V3 CN	V4								
>	<	(lengt distan	ce betwee ce betwee	Point O: Or Point P: Ref X length (mm) Y length (mm) en O and P po en O and P po	gin Poi erence 130 130 int on Th int on Th	nt Point e X axis e Y axis	Vision Origi Current count Vision count Vision Conn Vision IP Vision Port Local IP	n ection Setti 192 , 168 , 9876 190 , 168 ,	0 ng 0 . 101 0 . 5	LAN1 🗸	Reset	

Calibration template sample data's window



6.6 Vision triggered object setting

Before performing conveyor tracking, related parameters for conveyor tracking must be adjusted; related settings of objects can be applied directly to the conveyor's pick-on-the-fly program instructions. Path: In the tab window below, select Tracking >> Setting >> Vision Setting.



Conveyor vision triggered object setting interface diagram

1 - 1-1

Conve	yor vision triggered object settings illustration table

NO.	Name	Description
1	Convoyor number	Select the conveyor number to set; there are total of 4 conveyor settings
<u> </u>		that correspond to CN1 ~ CN4.
2	Robot height value	Displays the Z axis height value of the current robot; unit: millimeter (mm).
		Displays the height for each work object in accordance to the height value
		of the tool coordinates and base coordinates; a total of 8 objects; Object
	Object beight	from 1 to 8, can be used. Not only the current recorded height value is
3	record table	displaying, the tool coordinates and base coordinates also will be
		recorded; number height value@T#B#. There is a "*" symbol next to the
		object numbers above, which means that the value was changed but not
		yet saved.
		Click the "Write" button for the object height that needs to be set to write
4	Write button	the current height plus the tool coordinates and base coordinates into the
		fields of this object.
E	Save button	Saves the setting parameters. After saving, the "*" symbol next to Object#
5	Save bullon	on the top will disappear.
		Cancels the height value written and restores the previous height value
		entry. Since the object's height record table cannot be edited directly, to
6	Cancel button	restore objects with the "*" symbol, the Cancel button must be pressed to
		restore the previous entry of height value. If the Save button was already
		pressed, the current value can only be replaced by overwriting.



⇒<u>Description of the object height record table & write button:</u>

Example:

Select the 2nd object (Object2) recorded values on the CN1 conveyor; the current (Z axis) height is 10.000 mm. After pressing the "Write" button for the TOOL[1] coordinates and BASE[2] coordinates,

"10.000@T1B2" will be displayed in the object height record table. There will be a "*" symbol next to the object number, which means that it has not yet been saved. Remember to press the "Save" button; "*" will only disappear after the record is saved.

Position	Point	I/O		Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display
Setting	Visio	n Setting	Vision	Object	Sensor Obje	ct Calibra	tion Moni	tor				
Curr	rent h	eight:	-10.0	000		Write	e			Save	Cance	el
	Object 1* (Obj	Object 2*		3 (Object 4	Object 5	Obje	ect 6	Object 7	
CNV:	1	0.000@T	0B0	-10.000@T1B2		0.000		0.000	0.000	0.0	0.000	
CNV.	2	0.000)	0.	000	0.000		0.000 0.000		0.000		0.000
CNV	3	0.000)	0.	000	0.000		0.000	0.00 0.0		00	0.000
CNV	CNV4 0.000		0.000		0.000		0.000	0.000 0.0		00	0.000	
					· · · · ·						i	

Example Vision triggered object setting write values window



6.7 Sensor triggered object setting

Before performing conveyor tracking, related parameters for conveyor tracking must be adjusted; related settings of objects can be applied directly to the conveyor's pick-on-the-fly program instructions. Path: In the tab window below, select Tracking >> Setting >> Sensor Setting.

Position	Point	I/O		Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display
Setting	Vision S	Setting	Visio	n Object	Sensor Obje	ect Calibra	ation Mo	nitor				
								6[Save	Car	ncel —	-7
Item	1	Trigge	er	D	etect	Keep Time	(ms)	Status				
CNV1		Disable		•	40	10	0	FF:OBJ1ON:OBJ2				
CNV2	2	Disable	•	r	40	10	0	FF:OBJ3ON:OBJ4				
CNV3	3	Disable	•	•	40	10	0	FF:OBJ5ON:OBJ6				
CNV4	L 🗌	Disable	•	•	40	10	0	FF:OBJ7ON:OBJ8				
							i					
)	$\begin{pmatrix} 1 \\ 2 \end{pmatrix}$		(3	4)	5				

Conveyor sensor triggered object setting interface window

Conveyor vision triggered object settings illustration table

NO.	Name	Description
1	Convoyor number	Select the conveyor number to set; there is a total of 4 conveyor settings
L L	Conveyor number	that correspond to CN1 ~ CN4.
		Users can select the digital input \$DI if they want to perform sensor
2	cotting	triggered object signal setting. The default setting is Disable. It is a pull-
	setting	down menu and the available setting is \$DI[1] ~ \$DI[48].
	Dotoct Time	The time to maintain digital input (\$DI[]) detection after the digital
3	Detect Time	output (\$DO[]) signal is being sent. The default value is 40 and the unit is
	Detection time	millisecond (ms).
л	Keep Time	The object tracking duration after detecting digital input (\$DI[]); the
4	Duration	default value is 10 and the unit is millisecond (ms).
		Status of the detected object. Two types of objects are distinguished
	Object status	based on the ON/OFF status of the digital input (\$DI[]) selected. Take
5	Status	CN1 for an example, if the signal of CN1 is OFF, it can be considered
	Status	Object1; if the signal of CN1 is ON, it can be considered Object2. The
		same goes for CN2 ~ 4.
6	Sava hutton	Saves the setting parameters. After saving, the "*" symbol next to
0	Save button	Object# on the top will disappear.
7	Cancel button	Cancels the height value written and restores the previous height value.
/	Cancel button	Since the object height record table cannot be edited directly, to restore



NO.	Name	Description
		objects with the "*" symbol, the Cancel button must be pressed to
		restore the previous entry of height value. If the Save button was already
		pressed, the current value can only be replaced by overwriting.

6.8 Conveyor and trigger device calibration setting

This chapter explains the calibration setting between the conveyor and trigger device. Before performing conveyor tracking operation, calibration must be performed to synchronize the setting of the conveyor and trigger device; the trigger device refers to image vision or sensor trigger devices. Users can perform calibration settings based on the trigger device being used. The following are two sections used to describe the calibration methods separately.

6.8.1 Calibration for sensor triggered method

In addition to installing the electronic controls such as sensor and encoder; parameter settings (refer to Chapter 6.4) must also be completed for conveyor tracking objects. Sensor triggered calibration requires the following steps:

1.Select the calibration template.

2.Install calibration fixtures at the end of the robot, and calibrate the tool coordinates (refer to Chapter 3.3.3).

3.Base coordinate (user coordinate) calibration.

4. Conveyor motion ratio calibration.

5.Robot working range calibration.

The manual calibration process steps must be performed in order to allow the robot coordinates, conveyor encoder value and sensor position to have corresponding relationships, and to accurately perform pick-on-the-fly tasks for workpieces on the conveyor. Each of the following sections will explain them separately.

6.8.1.1 Sensor triggered-select the calibration template

Select a calibration template; this calibration template must have the same specifications as the end calibration fixtures in order to compare (point) positions. Refer the calibration template in the figure below, for example, the end calibration fixture can use the following circle diameter for the operator to compare the calibrated positions; operators can refer to the image below or design their own calibration template (the calibration template is used for measuring, therefore, it is recommended that its point positions and sizes must be tested to prevent errors occurring).







(This figure is just an example description and does not have correct distance ratios)

(This figure is just an example description and does not have correct distance ratios)

Sample Calibration template diagram (left figure 130mm square five-point figure, right figure: 10mm matrix dot plot)

6.8.1.2 Sensor triggered-install calibration fixture and tool coordinate calibration

Before starting the following sensor calibration, the calibration fixture mechanism device that corresponds to the calibration template must be installed at the end of the robot (due to the different sizes and specifications requirements, users must design the fixture mechanism themselves); this calibration fixture must be the same as the pick TCP (Tool Center Point), as this will be the most accurate method. After installing the end fixtures, corresponding tool coordinate calibration must be performed for the end fixture (calibration rod) (If base coordinate calibration cannot be performed first, then change to the tool coordinates, this is the order need to be followed).





Refer to the end fixture (calibration rod) figure

Refer to the installing end fixture to the robot end figure





Refer to the illustration diagram for using end fixture (calibration rod) with the calibration template



Description of entering the tool coordinate values using value input:

The distance of the tool can be entered manually to adjust the tool coordinate.

Possible data source:

Obtain the tool size information from the CAD file.

Physical measurement of the tool size.

User manual from the tool manufacturer.

Prerequisites

1. Manual operation mode.

2. Known X, Y, Z, A, B and C distance sizes relative to the flange coordinates.

Instructions:

1.)Switch the mode into controller permissions.

RCA000000000	x		
Start	II	Pause	Sto
Robot Setting	J		
Permission			
Permission O Monitor	⊙ Co	ntroller	
Mode O Manual	⊙ Aut	0	

Switching to controller permission diagram

2.)Enter the password (HIWIN) to switch into the manual mode.

		Robot Setting
Login		Permission
ID : RCA00000000 Enter	•	Permission Monitor Controller Mode Manual Auto

Enter the password to switch to manual mode figure



3.)Select the tool coordinate number from the tool/base interface on the left; for example TOOL[1].

Col/Base									
Tool:	1 •	Edit							
_	0								
Base:	2	Edit							
	<u> </u>								

Selecting the tool coordinate number from the tool/base interface window

1.) Then click the Edit button and the input value page will appear. .

	Edit Tool 1	
	Х	0
	Y	0
Tool/Base	Z	0
Tool: Edit	А	0
Base: 0 Edit	В	0
	С	0
	\checkmark	×

Figure1, Click the Edit button and enter the input values

2.)Enter the values for the X, Y, Z, A, B and C distance sizes of each axis in the table and tick [V];data will be saved. It can be seen from the simulated robot display of below screen; that the TOOL coordinates have shifted successfully.



Tool coordinate TOOL[1] value input interface window



6.8.1.3 Sensor triggered-base coordinate calibration

Purpose for base coordinate calibration: To rotate and shift the origin of the robot coordinates to the user's desired reference point. As shown below, the left figure is the original base coordinate figure; after user base coordinate calibration, the left figure's coordinates are shifted to the new base coordinate (right figure).



Original base coordinate BASE[0] diagram



Shifted to the new base coordinate diagram

After completing tool coordinate calibration, next is to perform base coordinate calibration. The purpose of base coordinate calibration is to move the robot coordinate onto the conveyor, and have relevant definitions for the direction. In order to make the base coordinate of the robot the same as the base coordinate of the conveyor, and to make it easier to identify, this process defines the conveying direction of the conveyor uniformly to positive X axis (+ X_Axis) and positive Z axis upwards (+ Z_Axis).

Sensor triggered base coordinate calibration includes the following 4 steps:
Step (one) Open the base coordinate setting page.
Step (two) Set the first point of the base coordinate.
Step (three) Set the second point of the base coordinate.
Step (four) Set the third point of the base coordinate.
The following are detailed introductions of the steps.



Step (one) Open the base coordinate setting page

From Tool/Base in the left interface, first select the base calibration/coordinate to set from Base (Base[1] is used as the example here), then switch to the coordinate calibration page and start the three steps for base calibration.

Path: From the tab window below, select Tracking >> Start Up >> Calibration > Base Calibration button.

Robot Setting	Robot Editor	
Permission		
Permission O Monitor O Controller	*[new] IESIU623_ime_1.nrb(Controller) 1	
Mode Manual O Auto		
Speed	=	
10 • •	Point I/O Timer Counter Alarm LogBook Communication Start Up Fieldbus Track	cing D
Tool/Base	Calibration Home Setting Time Setting User Alarm Setting Soft Limit Electric Gripper Payload External Axis Current Tool: 2	
Tool: 2 Edit	Tool Calibration	
Base: 1 Edit	Current Base: 1	
System	Name X Y Z A B C	
Update	• •	

Base coordinate BASE[2] interface diagram

	Position	Point I/O	Timer	Counter	Alarm	LogBook	Communicatio	n Start Up	Fieldbus	Tracking	Display
	Calibration	Home Setting	Time Setti	ng User Alar	m Setting	Soft Limit	Electric Gripper	Payload	External Axis		
				Measure	С	ancel	Edit				
Calibrate Base				Please mov	e the end	effector to t	he first point the	en -			
Data in Base[1] will be updated.	Curren	rrent Base: 1 E	Click the M Enter the ca	easure but alibration (ton to calib data directly	orate or /.					
Continue calibrating?	Ваѕе	Calibration		Name	х	Y	Z	Α	В	С	
	\bigcap			P1							
				P2							
			22	P3							
				Result							

Confirm the update of the Base confirmation window

Base calibration setting window

Step (two) Set the first point of the base coordinate

Place the calibration template/workpiece on the conveyor, and the workpiece must be within the range where the robot can reach, and then move the end of the robot to the position point P1 of that workpiece (the blue workpiece is used to represent this in the figure below). This position is the first point, and is the calibration origin. Press the "Measure" button to confirm it is the first point for base coordinate calibration.





First point (P1) for base coordinate calibration illustration diagram

Note 1: Point (P1) must be within the robot range; the blue workpiece can also be replaced by the calibration template.

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicatio	on Start Up	Fieldbus	Tracking	Display
Calibratio	n Home	Setting	Time Setting	User Alar	m Setting	Soft Limit	Electric Gripper	Payload	External Axis		
Measure Cancel Edit Please move the endeffector to the first point then Click the Measure button to calibrate or Current Base: 1											
Bas	e Calibra	ation		Name	Х	Y	Z	А	В	С	
\int	1			P1							
				P2							
				P3							
	T		R	Result							

Base calibration; press the measure button to set P1.

Press the "OK" button after the robot moved to the P1 point to confirm the calibration of the first point; the position information is displayed in the calibration table. The calibration of the first point has been completed.

Calibrate Tool		Measur Please mo	e Ca	ancel	Edit e second po	oint then		
Confirm the first point.	Current Base: 1	Click the M	Aeasure but	ton to calibr	ate.			
<u> </u>	Base Calibration	Name	Х	Y	Z	А	В	с
		P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
<u></u>		P2						
OK Cancel		P3						
		Result						

Confirm it is the first point of the calibration

Record the position information of the first point



Step (three) Set the second point of the base coordinate

Place the calibration workpiece on the conveyor, then start the operation of the conveyor and move the conveyor downstream for some distance (must be within a reachable range of the robot), then move the robot arm end to this point (P2). This position is the second point. This action allows the robot to obtain the conveyor coordinates in the positive X axis direction (+X_Axis).

Press the "Measure" button to confirm it is the second point for base coordinate calibration.



Second point (P2) for base coordinate calibration illustration diagram

Note: Point (P2) must be within the robot range, and the positioning point of the workpiece must not move randomly on the conveyor in order to prevent distortion.

Current Base: 1	Measur Please mo Click the M	e Ca ove the ende Measure but	ancel ffector to th ton to calibr	Edit e second po ate.	int then		
Base Calibration	Name	Х	Y	Z	A	В	С
	P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
	P2						
	P3						
	Result						

Go to base calibration and press the measure button to set P2.

After the robot moved to the P2 point, press the "OK" button to confirm the calibration of the second point. Calibration for the second point is completed.





Name γ Ζ А В С Х -200.000 300.000 -10.000 0.000 0.000 -5.471 P1 73.000 300.000 -10.000 0.000 0.000 -5.471 P2 P3 Result

Please move the endeffector to the third point then

Click the Measure button to calibrate.

Confirming the second point of the calibration

Record the position information of the second point

Step (four) Set the third point of the base coordinate

Based on the right-hand rule direction, move the robot to any position in the Y axis positive direction (Y+) (P3), and this position will be the third point. This action allows the robot to obtain the conveyor coordinates in the positive Y axis direction (+Y_Axis).



Third point (P3) for base coordinate calibration illustration diagram Press the "Measure" button to confirm it is the third point for base coordinate calibration.

Measure Cancel Edit											
Please move the endeffector to the third point then Click the Measure button to calibrate.											
Name	Х	Y	Z	Α	В	С					
P1	-200.000	300.000	-10.000	0.000	0.000	-5.471					
P2	73.000	300.000	-10.000	0.000	0.000	-5.471					
P3											
Result											

Go to base calibration and press the measure button for the third point P3.



After the robot moved to the P3 point, press the "OK" button to confirm the calibration of the third point. Calibration for the third point is completed. After the calculation result is completed, a calibration completed window prompt will appear. After pressing the "OK" button, base coordinate calibration is completed. After pressing the "OK" button, base coordinate calibration is completed. If the three points are not on the same point or calculation could not be completed, robot calculation will fail.





Confirm it is the second point diagram

Confirm calibration completed diagram

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicat	ion Start U	p Fieldbus	Tracking I
Calibration	Home	Setting	Time Settin	g User Ala	rm Setting	Soft Limit	Electric Gripper	Payload	External Axis	
Curre	nt Tool:	2	. 1	Measure	C	ancel	Edit			
Tool	Calibrat	tion		Calibration	successfu	l.		-		
Curre	nt Base:	1								
D	с. III									
Base	Calibra	tion		Name	Х	Y	Z	Α	В	С
				P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
- (9 ⁴	-	Î		P2	73.000	300.000	-10.000	0.000	0.000	-5.471
		ž	P3	86.773	349.533	-10.000	0.000	0.000	9.243	
•	T			Result	-200.000	300.000	-10.000	0.000	0.000	0.000

Record the position information of the third point and calculate the resulting diagram

After completing the four steps above, calibration for the base coordinate is completed. After calibration is completed, next is to perform the conveyor motion ratio calibration.

6.8.1.4 Sensor triggered-conveyor motion ratio calibration

This chapter explains the conveyor motion ratio calibration; this is to make the coordinates of the robot have the same ratio as the encoder motion of the conveyor,

Take the figure below for example, where the circumference is πD and the diameter (D) is 50mm, the circumference is approximately 157mm. When the encoder rotates one round, the encoder value is 2000 pulse, and the conveyor can move 157mm. Now divide the round into 4 equal parts, situation 1: The encoder value is 0, and the conveyor position is at 0mm; situation 2: The encoder value is 500, and the conveyor position is at 39.25mm; situation 3: The encoder value is 1000 and the conveyor position is at 78.5mm, and situation 4: The encoder value is 1500 and the conveyor position is at 117.75mm. It can be seen that the conveyor position has a certain motion ratio relationship with the encoder value.





Record the position information of the third point and calculate the resulting diagram Through the relationship described above, by using the position of the conveyor and the value of the encoder, we can get the parameters of the two for over 3 points in order to obtain the ratio relationship, which are the conveyor motion ratio calibration steps that are going to be performed below (the three points O0, O1 and O2 will be used below for calibration).

Calibration operation is required, the conveyor tracking object parameter setting must first be completed (refer to Chapter 6.4), and set the tool coordinate and base coordinate settings (refer to Chapter 6.8.1.2~6.8.1.3) where the end fixture (calibration rod) is installed.

Path: In the tab window below, select Tracking >> Setting >> Calibration.



Conveyor motion ratio calibration interface window (sensor triggered)

Note: Based on sensor triggered or vision triggered selected on the Tracking page, the calibration interface is different.

Illustration table for customizing packet format returned by vision



ltem number	ltem name	Description	
1	Conveyor number tab	Select the conveyor number to set; there is a total of 4 tabs, CN1 ~ CN4.	
2	Calibration setting display table	Displays the setting value table for conveyor settings, including the X axis, Y axis and conveyor encoder setting values.	
3	Encoder setting buttons	The three buttons O0, O1 and O2 are input buttons for 3 different encoder positions.	
4	Upstream/downstream setting button	Sets the working range calibration setting when the conveyor is used with robots; there is a total of four buttons, U1, U2, L1 and L2. U1 and U2 are used for upstream range setting; L1 and L2 are used for downstream range setting.	
5	Reset button	Clears the current conveyor calibration setting, and used for recalibration setting.	
6	Save button	Saves setting parameters.	

Place the calibration template/workpiece on the conveyor, and move the conveyor to the sensor trigger point.



Calibration template placed on conveyor and conveyor moves to the sensor trigger point illustration Note: O0, O1 and O2 are all the same point (the black dot position on the calibration template).



Select the conveyor tab to use (CN1 ~ CN4), and place the calibration template/workpiece on the conveyor. After moving the conveyor to the sensor trigger point (black dot at the center of the calibration template), switch to the Vision Setting page and press the "Reset" button. It can be seen that the current value of the vision (encoder) origin position is 0 pulse (or go to the Monitor page and confirm the encoder value is 0 pulse).



Vision setting interface reset encoder window

Return to the (sensor) calibration page and click on the "O0" function button on the image; check whether the value of O0 is 0 pulse in the left side table.



Conveyor motion ratio calibration O0 point interface diagram

Note: After moving the conveyor encoder value, switch to the Monitor page to confirm the changes of the encoder value. If it was discovered that the count of the encoder value (CNT) is decreasing when the conveyor is moving, open the Tracking page and select the Reverse field function to reverse the count of this conveyor, and change the encoder value to increasing count.



Slowly move the conveyor either automatically or manually to move the calibration fixture to the upstream position (reachable range of the robot, and towards the upstream end of the range); at this time, the conveyor will obtain the encoder value for the new position.



Calibration template moves to the upstream point within the robot range illustration diagram Note: The point must be within the robot range; O0, O1 and O2 are all the same point (the black dot position on the calibration template).

Move the end of the robot to where the calibration fixture (calibration rod) corresponds to the black dot on the calibration template (which is the same point position for sensor trigger). Set this point as the O1 point, and click the "O1" function button; check whether the value of O1 changed, and has X axis and Y axis coordinate values.



Conveyor motion ratio calibration O1 point interface diagram

Move the calibration fixture to the downstream position by moving the conveyor,





Calibration template moves to the downstream point within the robot range illustration diagram Note: The point must be within the robot range; O0, O1 and O2 are all the same point (the black dot position on the calibration template).

Move the end of the robot to the calibration fixture, and set this point as the O2 point. Click the "O2" function button and check whether the value of O2 changed, and has X axis and Y axis coordinate values.



Conveyor motion ratio calibration O2 point interface diagram

When the steps above are completed, click the "Save" button to save the setting parameters. This completes the conveyor motion ratio calibration.



Save		X
•	儲存成功	
		ОК



Conveyor motion ratio calibration save interface window Save successful screen window The next section explains the calibration of the downstream position within the work range.

6.8.1.5 Sensor triggered-calibration of the conveyor and robot work ranges This chapter defines the calibration settings for the work range when the conveyor is used with the robot. After defining the safety range, when the robot is executing conveyor tracking tasks, the robot will only execute the task within this work range, and will not act when exceeded this range. The monitoring screen will display exceeded range (Over_stream).



Robot and conveyor work range illustration diagram

When setting the work range for the robot and conveyor, it is set using the 4 points of a rectangle. The 2 upstream points settings are U1 and U2; when the workpiece enters this range, tracking begins (upper limit point). The 2 downstream points settings are L1 and L2; when the workpiece leaves this range, tracking is discarded (lower limit point), as illustrated in the figure below.



Robot and conveyor work range corresponding setting illustration diagram



Move the robot upstream to any two points close to the upper limit range, and press U1 and U2. Move downstream to any two points close to the upper limit range, and click L1 and L2. Check whether the values of U1, U2, L1 and L2 changed.



Conveyor upstream/downstream range calibration U1, U2, L1, L2 point interface diagram After the settings above are completed, click the "SAVE" function button to save the upstream/downstream range, and calibration is completed.





Conveyor upstream/downstream setting completed save interface window

Save successful screen window

Note 1: Points U1, U2, L1 and L2 must be within the robot range.

Note 2: Points U1, U2 and L1, L2 will each form an infinite line segment.

After completion of the calibration for the sensor triggered method; next is to be performed the programming for conveyor tracking. (Please refer to Chapters 9.12, 10.9)



6.8.2 Calibration for vision triggered method

In addition to installing the vision system, vision system input/output configuration and the electronic controls for the encoder, parameter settings (refer to Chapter 6.4) must also be completed for conveyor tracking objects. Vision triggered calibration requires the following steps:

1.Select the calibration template.

2.Install calibration fixtures at the end of the robot, and calibrate the tool coordinates (refer to Chapters

3.3.3 and 6.8.1.2).

3. Vision system calibration

4. Vision system and base coordinate (user coordinate) calibration.

5. Conveyor motion ratio calibration.

6.Robot working range calibration.

The manual calibration process steps must be performed in order to allow the robot coordinates, conveyor encoder value and vision system coordinate position to have corresponding relationships, and to accurately perform pick-on-the-fly tasks for workpieces on the conveyor. Each of the following sections will explain them separately.

6.8.2.1 Vision triggered-select the calibration template

Select a calibration template; this calibration template must have the same specifications as the end calibration fixtures in order to compare (point) positions. Refer the calibration template in the figure below, for example, the end calibration fixture can use the following circle diameter for the operator to compare the calibrated positions; operators can refer to the image below or design their own calibration template (the calibration template is used for measuring, therefore, it is recommended that its point positions and sizes must be tested to prevent errors occurring).





(This figure is just an example description and does not have correct distance ratios)

(This figure is just an example description and does not have correct distance ratios)

Sample Calibration template diagram (left figure 130mm square five-point figure, right figure: 10mm matrix grid)



Rectangular point calibration template can also be used to set the O point and P point screen diagram.



Using rectangular point calibration template to set the O point and P point

6.8.2.2 Vision triggered-install calibration fixture and tool coordinate calibration

Before starting the following vision calibration, the calibration fixture mechanism device that corresponds to the calibration template must be installed at the end of the robot (due to the different sizes and specifications requirements, users must design the fixture mechanism themselves); this calibration fixture must be the same as the pick TCP (Tool Center Point), as this will be the most accurate method. After installing the end fixtures, corresponding tool coordinate calibration must be performed for the end fixture (calibration rod) (if base coordinate calibration cannot be performed first, then change the tool coordinates, this order need to be followed)

The setting is the same as 6.8.1.2 Sensor triggered-install calibration fixture and tool coordinate calibration; please refer to the descriptions in 196(it will not be repeated here).

6.8.2.3 Vision triggered-vision system calibration & adjustment

Perform vision system calibration based on the vision system used by the user. For example, adjust the camera positions, light source, focal distance, adjust the parameters for recognition methods, and visual image curve compensation calibration. The calibration method is different for the different vision systems or brands; users must make adjustments according to the vision system will be used. This chapter will not give further explanations. After calibration is completed, the calibrated parameters can be used for follow-up adjustments.


6.8.2.4 Vision triggered-vision and base coordinate calibration Purpose for base coordinate calibration: To rotate and shift the origin of the robot coordinates to the user's desired reference point. As shown below, the left figure is the original base coordinate figure; after user base coordinate calibration, the left figure's coordinate is shifted to the new base coordinate (Right figure).



Original base coordinate BASE[0] diagram



Shifted to the new base coordinate diagram

After completing tool coordinate calibration, next is to perform base coordinate calibration. The purpose of base coordinate calibration is to move the robot coordinate onto the conveyor, and have relevant definitions for the direction. In order to make the base coordinate of the robot the same as the base coordinate of the conveyor, and to make it easier to identify, this process defines the conveying direction of the conveyor uniformly to positive X axis (+ X_Axis) and positive Z axis upwards (+ Z_Axis).

Vision triggered base coordinate calibration includes the following 4 steps: Step (one) Open the base coordinate setting page. Step (two) Set the first point of the base coordinate. Step (three) Set the second point of the base coordinate. Step (four) Set the third point of the base coordinate. The following are detailed introductions of the steps.



Step (one) Open the base coordinate setting page

From Tool/Base in the left interface, first select the base coordinate to set from Base (Base[1] is used as the example here), then switch to the coordinate calibration page and start the three steps for base calibration. Path: From the tab window below, select Tracking >> Start Up >> Calibration > Base Calibration button.

Robot Setting	bot Editor	
Permission		= * [
Permission O Monitor ③ Controller	1	
Mode ① Manual () Auto		
Speed		
10 • •	sition Point I/O Timer Counter	Alarm LogBook Communication Start Up Fieldbus Tracking D
Tool/Base	elibration Home Setting Time Setting User Alarr Current Tool: 2	n Setting Soft Limit Electric Gripper Payload External Axis
Tool: 2 Edit	Tool Calibration	
Base: 1 Edit	Current Base: 1	
System	Name	X Y Z A B C
Update	-	

Base coordinate BASE[2] interface diagram

	Position Point I/O	Timer Co	ounter Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display
	Calibration Home Setting	Time Setting Use	er Alarm Setting	Soft Limit	Electric Gripper P	ayload l	External Axis		
Calibrate Base		Mea	isure Ca	ancel	Edit				
Data in Base[1] will be updated. Continue calibrating?	Current Base: 1	Please Click tl Enter t	e move the ende he Measure but the calibration o	effector to t ton to calib lata directly	he first point ther rate or '.	I			
	Base Calibration	Nam	ie X	γ	Z	А	В	С	
		P1							
OK Cancel		P2							
		P3							
		Result	It						

Confirm the update of the Base confirmation window

Base calibration setting window

Step (two) Set the first point of the base coordinate

Place the calibration template on the conveyor; there must be information on 3 points on the calibration template, and they must have vertical angle relationships. The workpiece must also be within the reachable range of the robot (it would be best to try to place it at the center of the robot range), and move the end of the robot to the O point on the calibration template. This position is the first point, and is the calibration origin. Press the "Measure" button to confirm it as a first point for base coordinate calibration.





First point (P1) for base coordinate calibration illustration diagram

Note 1: The points (O and P points) on the calibration template must be within the robot range.

Position	Point	I,	0	Timer	Counter	Alarm	LogBook	Communicatio	n Start Up	Fieldbus	Tracking	Display
Calibratio	n Ho	me Set	ting	Time Setting	User Alarn	n Setting	Soft Limit	Electric Gripper	Payload	External Axis		
Curre	ent Ba	ise:	1	PI CI Er	Vleasure ease move lick the Mea nter the cal	C the end asure but ibration	ancel effector to t tton to calib data directl	Edit the first point th prate or y.	en			
Base	e Cali	bratio	on		Name	Х	Y	Z	Α	В	с	
ſ					P1							
					P2							
			À		P3							
					Recult							

Base calibration presses the measurement button to set P1.

Press the "OK" button after the robot moved to the O point to confirm the calibration of the first point (P1); the position information is displayed in the calibration table. The calibration of the first point has been completed.

		Measur	re Ca	ancel	Edit			
Calibrate Tool	Current Base: 1	Please mo Click the M	ove the ende Measure but	effector to th ton to calib	ie second po rate.	oint then		
<u>~~</u>	Base Calibration	Name	Х	γ	Z	А	В	с
		P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
<u></u>		P2						
OK Cancel		P3						
		Result						

Confirm it is the first point of the calibration

Record the position information of the first point



Step (three) Set the second point of the base coordinate

Place the calibration workpiece on the conveyor, and then move the end of the robot to the R point. This position is the second point. This action allows the robot to obtain the conveyor coordinates in the positive X axis direction (+X_Axis).

Press the "Measure" button to confirm it is the second point for base coordinate calibration.



Third point (P2) for base coordinate calibration illustration diagram

Current Base: 1	Measur Please mo Click the N	e Ca ove the ende Measure but	ancel ffector to th ton to calibr	Edit e second po ate.	int then		
Base Calibration	Name	х	γ	Z	A	В	с
	P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
	P2						
	P3						
	Result						

Go to base calibration and press the measurement button to set P2.

After the robot moved to the R point, press the "OK" button to confirm the calibration of the second point. Calibration for the second point is completed.





Confirming it is the second point of the calibration

Measur	e C	ancel	Edit			
Please mo Click the N	ove the ende Aeasure but	effector to t ton to calib	he third point rate.	then:		
Name	Х	γ	Z	Α	В	С
P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
P2	73.000	300.000	-10.000	0.000	0.000	-5.471
P3						
Result						

Record the position information of the second point

Step (four) Set the third point of the base coordinate

Based on the right-hand rule direction, move the robot to the P point; this position is the third point. This action allows the robot to obtain the conveyor coordinates in the positive Y axis direction (+Y_Axis).



Third point (P3) for base coordinate calibration illustration diagram

Press the "Measure" button to confirm it as a third point for base coordinate calibration.

Measur	e Ca	ancel	Edit			
Please mo Click the N	ve the ende deasure but	ffector to th ton to calibr	ie third point ate.	then:		
Name	х	Y	Z	Α	В	С
P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
P2	73.000	300.000	-10.000	0.000	0.000	-5.471
P3						
Result						



Go to base calibration and press the measure button for the third point P3

After the robot moved to the P point, press the "OK" button to confirm the calibration of the third point. Calibration for the third point is completed. After pressing the "OK" button, base coordinate calibration is completed. After the calculation result is completed, a calibration completed window prompt will appear. If the three points are not on the same point or calculation could not be completed, robot calculation will fail.





Confirming the second point of the calibration

Confirm calibration completed diagram

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communicati	on Start U	P Fieldbus	Tracking
Calibratio	n Home	Setting	Time Settin	g User Alar	m Setting	Soft Limit	Electric Gripper	Payload	External Axis	
Curre	ent Tool:	2	. 1	Measure	с	ancel	Edit			
Тоо	l Calibra	tion		Calibration	successfu	l.		-		
Curre	ent Base:	1								
Pac	o Colibra	tion								
DdSt		uon		Name	Х	Y	Z	Α	В	С
				P1	-200.000	300.000	-10.000	0.000	0.000	-5.471
	10.0	Ĵ		P2	73.000	300.000	-10.000	0.000	0.000	-5.471
		-	Ť	P3	86.773	349.533	-10.000	0.000	0.000	9.243
				Result	-200.000	300.000	-10.000	0.000	0.000	0.000

Record the position information of the third point and calculate the resulting window

After completing the above four steps, calibration for the base coordinate is completed. After calibration is completed, next is to perform the conveyor motion ratio calibration.

6.8.2.5 Vision triggered-conveyor motion ratio calibration

This chapter explains the conveyor motion ratio calibration; this is to make the coordinates of the robot have the same ratio as the encoder motion of the conveyor,

Refer to Chapter 6.8.1.4 for related explanations (it will not be repeated here). By using the position of the conveyor and the value of the encoder, we can get the two parameters for over 4 points in order to obtain the ratio relationship, which are the conveyor motion ratio calibration steps that are going to be performed below (the 4 points O1, P1, O2 and P2 will be used for calibration below).

Calibration operation is required, the conveyor tracking object parameter setting must be completed (refer to Chapter 6.4) at first, and set the tool coordinate and base coordinate settings (refer to Chapter 6.8.1.2~6.8.1.3) where the end fixture (calibration rod) is installed.

Path: In the tab window below, select Tracking >> Setting >> Calibration.





Conveyor motion ratio calibration interface window (vision triggered)

Note: Based on sensor triggered or vision triggered selected on the Tracking page, the calibration interface is different.

Illustration table for customizing packet format returned by vision

NO.	Name	Description
1	Convoyor number tob	Select the conveyor number to set; there is a total of 4 tabs, CN1 \sim
1	Conveyor number tab	CN4.
2	Calibration setting	Displays the setting value table for conveyor, including the X axis, Y
Z	display table	axis and conveyor encoder setting values.
2	Encoder setting	The four buttons O1, P1, O2 and P2 are input buttons for 4 different
5	buttons	encoder positions.
		Sets the working range calibration setting when the conveyor is
4	Upstream/downstream	used with robots; there is a total of four buttons, U1, U2, L1 and L2.
4	setting button	U1 and U2 are used for upstream range setting; L1 and L2 are used
		for downstream range setting.
-	Bosot button	Clears the current conveyor calibration settings, and use it for
5	Reset Dutton	recalibration.
6	Save button	Saves setting parameters.

Place the calibration template on the conveyor, and move the conveyor to the trigger point for vision photo-taking.





Calibration template placed on conveyor and conveyor moves to the vision trigger point illustration

Select the conveyor tab to use (CN1 ~ CN4), and place the calibration template on the conveyor. After moving the conveyor to the vision calibration photo-taking trigger point, switch to the Vision Setting page and press the "Reset" button. It can be seen that the current value of the vision (encoder) origin position is 0 pulse (or go to the Monitor page and confirm the encoder value is 0 pulse).

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communica	tion S	Start Up	Fieldbus	Tracking	Display	M
Setting	Vision Se	tting Visio	n Object	Sensor Obje	ct Calibra	tion Mor	nitor						
CNV1	CNV2	CNV3	CNV4										
	x	length					Vision Ori <u>c</u>	gin			-		
	T		P				Current cour	nt:		0			
-	ength		Poin Poin	nt O: Ori nt P: Ref	gin Poi erence	nt Point	Vision count	t	0		-		
5	▶		Xlen	gth (mm)	130		Vision Con	nectio	on Settin	ıg			
	0		M Ylen	gth (mm)	130		Vision IP	192	. 168 .	0 .101		Reset	,]
х	(length: d	listance b	etween O	and P po	int on The	e X axis	Vision Port	9876	5				
Y	length: d	listance be	etween O	and P poi	int on The	e Y axis	Local IP	190	, 168 ,	0,5	LAN1 -	Save	•

Vision setting interface reset encoder window

After the encoder is reset to zero, do not move the calibration template; instead, move the conveyor automatically/manually to where the O point and P point on the calibration template are all within the robot range (it is best to try to have them close to the upstream position of the robot), and the point that reset the calibration template to zero cannot be the same as the encoder value of O point (O1 or P1 point) (this means that the encoder value of O1 cannot be 0).





Move the conveyor within the robot range and click O1 and P1 illustration diagram After moving the conveyor encoder value, switch to the Monitor page to confirm the changes of the encoder value. If it was discovered that the count of the encoder value (CNT) is decreasing when the conveyor is moving, open the Tracking page and select the Reverse field function to reverse the count of this conveyor, and change the encoder value to increasing count.



Robot and conveyor work range corresponding setting illustration diagram



Return to the (vision triggered) calibration page, and move the end of the robot to the O point and P point of the calibration fixture respectively; then press the O1 and P1 function buttons and check whether the values of O1 and P1 have changed.



Move the conveyor to within the robot range and click the O1 and P1 buttons interface diagram Note: The points must be within the robot range.

Move the conveyor either automatically or manually for some distance downstream (the closer the distance is to the downstream position, the better it is), and the calibration template must be within the moving range of the robot.



Move the conveyor downstream for some distance and click O2 and P2 illustration diagram Note: O1 and O2 are the same point (the O point position on the calibration template); P1 and P2 are the same point (the P point position on the calibration template); and the points must be within the robot range.



Move the calibration fixture (calibration rod) at the end of the robot to the O2 point and P2 point of the calibration fixture respectively, then press the O2 and P2 function buttons and check whether the values of O2 and P2 have changed.



Move the conveyor to within the robot range and click the O2 and P2 buttons interface diagram

When the settings above are completed, click the "SAVE" function button to save the completed calibration; if settings were done poorly or need to recalibrate, please press the "Reset" button.





Conveyor motion ratio calibration save interface diagram

Save successful screen window



6.8.2.6 Vision triggered-calibration of the conveyor and robot work ranges This chapter defines the calibration settings for the work range when the conveyor is used with the robot. After defining the safety range, when the robot is executing conveyor tracking tasks, the robot will only execute the task within this work range, and will not act when exceeded this range. The monitoring screen will display exceeded range (Over_stream).



When setting the work range for the robot and conveyor, it is set using the 4 points of a rectangle. The 2 upstream points settings are U1 and U2; when the workpiece enters this range, tracking begins (upper limit point). The 2 downstream points settings are L1 and L2; when the workpiece leaves this range, tracking is discarded (lower limit point), as illustrated in the figure below.



Robot and conveyor work range corresponding setting illustration diagram



Move the robot upstream to any two points close to the upper limit range, and click the U1 and U2 buttons. Check whether the values of U1 and U2 were recorded.



Conveyor upstream range calibration U1, U2 point interface diagram

Move the robot downstream to any two points close to the lower limit range, and click the L1 and L2 buttons. Check whether the values of L1 and L2 were recorded.



Conveyor downstream range calibration for L1 and L2 points interface window



After the settings above are completed, click the "SAVE" button to save the upstream/downstream range. The calibrationhas been completed.

位置	點位	I/O	計時器	暫存器	警告提示	事件紀錄簿	通訊設定	散動設定	Fieldbus	輸送帶追蹤	顯示這
設定	視覺設定	視覺物件調	没定 感》	则器物件設定	校正	監控				_	
CNV1	CNV2	CNV3	CNV4]	上游	重置	11	存檔	下游	
Item	Х	γ		Pulse] [ι	, ₁				j [L1
U1	266.88	280.0	9						_		
U2	266.88	407.2	4				P1	Move CN\		P2	
ш	-236.87	287.6	9			01			02		
L2	-236.87	407.2	4		L	¹² X-	CN	/ Direc	tion	X+	L2
01	208.45	405.4	6 1	63560							
02	-86.82	410.0	9 3	82392							
P1	78.45	275.4	6								
P2	-216.82	280.0	9								

Save		Σ
(儲存成功	
		ОК

Conveyor upstream/downstream setting completed save interface window

Save successful screen window

Note 1: Points U1, U2, L1 and L2 must be within the robot range.

Note 2: Points U1, U2 and L1, L2 will each form an infinite line segment.

After completion of the calibration for the vision triggered method; next is to be perform the programming for conveyor tracking. (Please refer to Chapters 9.12, 10.9)



6.9 Conveyor tracking function status monitor

Performing conveyor tracking operations.

Path: In the tab window below, select Tracking >> Setting >> Monitor.



Conveyor monitor interface window

Conveyor monitor setting instruction table

NO.	Name	Description					
1	Conveyor number	Select the conveyor number; there is a total of 4 conveyor tabs that correspond to $CN1 \simeq CN4$					
2	Encoder	Displays the current encoder value that the robot received					
2	Littodei	Displays the current encoder value that the robot received.					
3	Speed	(mm/s).					
	Total Object						
4	Total number of objects	Displays the total number of queue data received by the robot.					
	Success Object						
5	Number of successful	Displays the accumulated number of queues that the robot successfully					
	objects	picked up.					
6	Latch	Trigger signal status display; the white part within the frame is not					
	Luten	triggered, and the red is triggering.					
7	Clear button	Clears the current queues that are not executed.					
0	Information on	When the robot receives unprocessed queue data, it will display how					
ŏ	incomplete queues	many objects and encoder pulses are in the queue.					
	Information on	When the robot receives processed queue data, it will display the					
9	information on	number of completed queues, the encoder pulses and the pick-up					
	completed queues	results. When the robot picked-up successfully, Success will be					



NO.	Name	Description
		displayed; and when it failed, Over_stream (range exceeded) will be
		displayed.



7. FieldBus Communication (SI/O) Application

7.1 Setup CC-Link connection parameters

Operating steps

- 1.Click the [FieldBus] sub tab.
- 2.Click the [Setting] sub tab.

Description

Position	Point	1/0	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Masterii
Register	Setting											
)	Channel 1	Cha	annel 2	1		Station Nun	nber 1	×				
)	Channel Nu	mber F	Protocol 1	~		Transmissio	on Rate 156K	~				
)	Connection	Туре (CC-Link Slav	e ~		Occupancy	Station 1	~				
)	Connect	t										

FieldBus CC-Link Setting interface

No.	Description
	Display Protocol connection status.
1	If connection is successful, it will show red block. If failed or
	disable, it will show white block.
2	Protocol selection. It can be Protocol1 or Protocol2.
3	Connection type, please select [CC-Link Slave].
4	Connect or Disconnect.
5	Station number in this CC-Link network. The range is 1~64 \circ
6	Transmission Rate for data transfer.
7	Occupancy station number for this equipment. The range is
/	1~4.

After finishing above, Click [Connect] buttont to proceed this connection and click [Save] button to save this configuration. Next time to start this system, it will use this configration to make connection.



7.2 Setup Profinet Connection Parameters

Operating steps

1.Siemens PLC need to install PROFINET IO descripted file of GSDML(download form HIWIN Website).

- 2.Click the [FieldBus] sub tab.
- 3.Click the [Setting] sub tab.

Description

 After PROFINET IO descripted file of GSDML installed, on Siemens TIA Portal Software Options menu to select Other field devices->PROFINET IO->I/O->Hilscher Gesellschaft für System automation mbH ->PNS->CIFX RE/PNS V3.5.18–V3.5.34 °

Options		
		E
✓ Catalog		
<search></search>	lini) (n
Filter Profile: <all></all>	-	1
Controllers		
🕨 🛅 HMI		
PC systems		
Drives & starters		
Image: Network components		
Detecting & Monitoring		
Distributed I/O		
Power supply and distribution		
Field devices		
 Other field devices 		
Additional Ethernet devices		
Drives		
Encoders		
Gateway		
▼ 10		
 Hilscher Gesellschaft für Systemautomation 	n mbH	
▼ Li PNS		
CIFX RE/PNS V3.1.x		
CIFX RE/PNS V3.2.x - V3.4.18		
CIFX RE/PNS V3.4.138 - V3.4.142		
CIFX RE/PNS V3.4.143 - V3.4.1xx		
CIFX RE/PNS V3.4.19 - V3.4.x		
CIFX RE/PNS V3.5.0 - V3.5.17		
CIFX RE/PNS V3.5.18 - V3.5.34	20	
CIFX RE/PNS V3.5.35 - V3.X		
Consers		

Siemens TIA Portal software Setting figure

2. Open Caterpillar [→] click FieldBus → Setting , open FieldBus Profinet setting parameters interface.



FieldBus Profinet Setting interface



No.	Description							
	Display Protocol connection status.							
1	If connection is successful, it will show red block. If failed or							
	disable, it will show white block.							
2	Protocol selection. It can be Protocol1 or Protocol2.							
3	Connection type, please select [Profinet Slave].							
4	Reconnect or Disconnect.							
E	Station name. Require to set up the same name with the							
5	Master's.							
6	IP address corresponding to the Master's.							
7	Input bytes number corresponding to the Master's. The IO							
/	maximum number support 16 Bytes.							
0	Output bytes number corresponding to the Master's. The IO							
ð	maximum number support 16 Bytes.							

After finishing above, Click [Connect] buttont to proceed this connection and click [Save] button to save this configuration. Next time to start this system, it will use this configuration to make connection.



7.3 Setting ModbusTCP Server Connection Parameters

Operating steps

- 1. Click [Fieldbus] tab.
- 2. Click [Setting] tab.

Description

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Masterin
Register	Setting											
	Channel 1	C	hannel 2	3		Local IP1		,				
 (Channel Nu	umber	Protocol 1	~		Local IP2						
	Connection	Туре	Modbus Ser	ver TCP 🗸		Loca Por	502					
·	Connec	t										

FieldBus ModbusTCP Server Setting interface

FieldBus Modbus TCP Server interface parameters description table

No.	Name	Description				
		Confirmation of protocol connection status.				
1	Protocol Connection	If connection is successful, the box will appear red, if connection is				
		failed or setting is not switched on, the box will appear white.				
		Protocol Number, can select the protocol of connection. When select				
2	Protocol Number	protocol 1, SI/O[1]~[128] can be used. When select protocol 2,				
		SI/O[129]~[256] can be used.				
3	Connection Type	Connection Type, please select $\ ^{ extsf{r}}$ Modbus Server $_{ extsf{r}}$.				
4	Connection Button	Click to connect or disconnect.				
5	Local IP1 Setting	Local IP1, setting of the local IP1address.				
6	Local IP2 Setting	Local IP2, setting of the local IP2address.				
7	Local Port	Local Port, setting of the local communication port.				

The Modbus function codes(1,2,3,15,16) are available.

Once setting is complete, click [Connect] to connect and store the setting, next reboot would use current setting for connection.



7.4 Setting ModbusTCP Client Connection Paramedics

Operating steps

1.Click the [FieldBus] sub tab.

2.Click the [Setting] sub tab.

Description



FieldBus ModbusTCP Client setting interface figure

FieldBus Modbus TCP Client interface parametic description table

No.	Name	Description
		Confirmation of protocol connection status.
1	Protocol Connection	If connection is successful, the box will appear red, if connection is
		failed or setting is not switched on, the box will appear white.
		Protocol Number, can select the protocol of connection. When select
2	Protocol Number	Channel 1, SI/O[1]~[128] can be used. When select Channel 2,
		SI/O[129]~[256] can be used.
3	Connection Type	Connection Type, please select \ulcorner Modbus Client \lrcorner .
4	Connect button	Click to connect or disconnect.
5	Remote IP	Remote IP, set corresponding to remote device.
6	Remote Port	Remote Port, set corresponding to remote device.
7	Server number	Server number setting, setting range is 1 ~ 4.
8	Discrete Input Begin	the setting of remote device SI start number, setting range is 0 ~ 256.
0		setting of SI quantity should correspond to the setting of remote
9	Discrete input size	device, setting range is 0 ~ 128 \circ If data size is 0, then disable.
10	Coil Bogin	the setting of remote device SO start number, setting range is 0 $^{\sim}$
10		256 •
11		the setting of remote device SO write number, setting range is 0 $^{\sim}$
11		128 • If data size is 0, then disable.



No.	Name	Description
12	Input Register Begin	the setting of remote device SRR register start number, setting range is 0 \sim 999 ${}_{\circ}$
13	Input Register Size	the setting of remote device SRR read quantity, setting range is 0 ~ 128 \circ If data size is 0, then disable.
14	Holding Register Begin	the setting of remote device SRW register start number, setting range is 0 \sim 999 $_{\circ}$
15	Holding Register Size	the setting of remote device SRW write quantity, setting range is 0 ~ 16 • If data size is 0, then disable.

Once setting is complete, click [Connect] to connect and store the setting, next reboot would use current setting for connection.



7.5 Setting ModbusRTU Server Connection Parameters

Operating steps

- 1. Click the [FieldBus] sub tab.
 - 2.Click the [Setting] sub tab.

Description

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Mastering
Register	Setting											
)	Channel 1	— a	nannel 2			Slave ID	0	~	Bund Rate	9600 丶	/	
		_		_		Parity	None	~	Data bits	8 \	/	
	Channel N	umber	Protocol 1	\sim		Stop bit	1	Y				
)	Connectio	n Type	Modbus Se	ver RTU 🗸								
)	Conne	ct										
								7)				
							S					
							6)				

FieldBus Modbus RTU Server Setting interface

FieldBus Modbus RTU Client interface parameter description table

No.	Name	Description					
		Confirmation of protocol connection status.					
1	Protocol Connection	If connection is successful, the box will appear red, if connection is					
	Status	failed or setting is not switched on, the box will appear white					
2	Protocol Number	Protocol selection. It can be Protocol1 or Protocol2.					
3	Connection Type	Connection type, please select \ulcorner Modbus Server RTU $ floor$ \circ					
4	Connect button	Connect or Disconnect.					
5	Slave ID	Setting local Slave ID, setting range is 0 \sim 256 \circ					
6	Darity Chaole	Setting COMPORT parity parameter ,「 Even 」:Even check,					
0		「Odd」:Odd check, 「None」: null check.					
7	Stop bits	Setting Stop bit , select 1 or 2.					
8	Baud rate	Setting Baud rate(bit/s), setting range is 110 $^{\sim}$ 115200 $^{\circ}$					
9	Data bits	Setting Data bits, setting range is 5 ~ 8 \circ					

Once setting is complete, click [Connect] to connect and store the setting, next reboot would use current setting for connection.



7.6 ModbusRTU Client connection parameter settings

Instructions

1.Click the FieldBus tab in the function tab.

2.Click the Setting tab.

Description



FieldBus Modbus RTU Client setting interface window

FieldBus Modbus RTU Client interface parameter description table

No.	Name	Description
		Confirmation of protocol connection status.
1	Protocol Connection	If connection is successful, the box will appear red, if connection is
	518185	failed or setting is not switched on, the box will appear white
2	Protocol Number	Protocol selection. It can be Channel1 or Channel2.
3	Connection Type	Connection type, please select \ulcorner Modbus Client RTU \lrcorner \circ
4	Connect button	Connect or Disconnect.
5	Slave ID	Setting local Slave ID, setting range is 0 \sim 256 \circ
6	Server number	Server number Setting, setting range is 1 ~ 4.
7	Devity Cheel	Setting COMPORT parity parameter ,「 Even 」:Even check,
/	Parity Check	「Odd 」:Odd check, 「None 」: null check.
8	Stop bits	Setting Stop bit , select 1 or 2.
9	Baud rate	Setting Baud rate(bit/s), setting range is 110 $^{\sim}$ 115200 $^{\circ}$
10	Data bits	Setting Data bits, setting range is 5 \sim 8 $_{\circ}$
11	Discrete Input Begin	the setting of remote device SI start number, setting range is 0 ~ 256.
12	Discrete Input size	setting of SI quantity should correspond to the setting of remote device, setting range is 0 ~ 128 \circ If data size is 0, then disable.



No.	Name	Description
13	Coil Begin	the setting of remote device SO start number, setting range is 0 $^{\sim}$ 256 $_{\circ}$
14	Coil Size	the setting of remote device SO write number, setting range is 0 ~ 128 ° If data size is 0, then disable.
15	Input Register Begin	the setting of remote device SRR register start number, setting range is 0 \sim 999 $_{\circ}$
16	Input Register Size	the setting of remote device SRR read quantity, setting range is 0 $^{\sim}$ 128 \circ If data size is 0, then disable.
17	Holding Register Begin	the setting of remote device SRW register start number, setting range is 0 \sim 999 $_{\circ}$
18	Holding Register Size	the setting of remote device SRW write quantity, setting range is 0 \sim 16 \circ If data size is 0, then disable.

Once setting is complete, click [Connect] to connect and store the setting, next reboot would use current setting for connection.



7.7 Modbus Monitor Page

Instructions:

1.On the Function tab, click the FieldBus tab \rightarrow click the Modbus Monitortab.

Description:

This interface is used to display Modbus communication messages.

	Positio	n Point		V0	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Mastering					
1- 2- 3- 4- 5-		Modbus Channel Server Ni Show	ng TCP (um Mess	Client 2 1 age	•	Receive 02 01 00 Send to 03 00 00 Receive 01 01 00 Send to 02 00 00 Receive 02 01 00 Send to 03 00 00 Receive 03 02 00	from server 1 000 01 from server 1 000 server 1 000 01 from server 1 000 01 from server 1 000 01 from server 1 000 01	ver 1 ver 1 ver 1 ver 1 ver 1										5	Send
																		(6

ModBus Monitor interface window (e.g., using Modbus TCP Client)

Modbus monitor setting description table

No.	Name	Description
1	Fieldbus mode display	Displays the connection mode for the current channel.
2	Channel selection	Protocol selection. It can be Channel1 or Channel2.
3	Corresponding server number	The message sending server number selected for client mode.
4	Message display selection	Check tickbox to display/hide the transmission messages.
5	Export button	Requires connecting a USB hard drive and export output messages
6	Send message button	Users enter the message to send into the message field, then click the message to send test manually.



7.8 FieldBus Application Description

7.8.1 Field Bus Input(SI[n])

Operating steps

- 1. Click the [I/O] sub tab.
- 2. Click the [SI/O] sub tab.

Description

- A. When using Protocol1, SI[1]~SI[128] can be used.
 - a. When Occupancy is 1, SI[1]~SI[32] can be used.
 - b. When Occupancy is 2, SI[1]~SI[64] and so on.
- B. When using Protocol 2, SI[129]~SI[256] can be used.
 - a. When Occupancy is 1, SI[129]~SI[160] can be used.
 - b. When Occupancy is 2, SI[129]~SI[192] and so on.
- C. SI[1]~SI[8] are reserved and have similar function as FI[1]~FI[8].
- D. Interface can be used directly for selection.
 - a. SI[1]~SI[8] cannot be set directly.
 - b. Comment for SI[1]~SI[8] is unmodifiable, the reset will be stored.
- E. Can be controlled by command.
 - a. The command \$SI[n] can be used to read Input status.
 - b. Other instruction can be used such as IF $\, \sim \,$ WAIT FOR.



7.8.2 Field Bus Output(SO[n])

Operating steps

- 1. Click the [I/O] sub tab.
- 2. Click the [SI/O] sub tab.

Description

A.When using Protocol1, SO[1]~SO[128] can be used.

- a. When Occupancy is 1, SO[1]~SO[32] can be used.
- b. When Occupancy is 2, SO[1]~SO[64] and so on.

B.When using Protocol2, SO[129]~SO[256] can be used.

- a. When Occupancy is 1, SO[129]~SO[160] can be used.
- b. When Occupancy is 2, SO[129]~SO[192] and so on.
- C.SO[1]~SO[8] are reserved and have similar function as FO[1]~FO[8].

D.Interface can be used directly for selection.

- a. SO[1]~SO[8] cannot be set directly.
- b. Comment for SO[1]~SO[8] is unmodifiable, the reset will be stored.

 $E.\ensuremath{\mathsf{Can}}$ be controlled by command.

c. Then command \$SO[n] can be used to write Output status.

Position	Point	1/0	Counter	Alarm LogBo	ok Comm	unication N	lastering Start Up	Fieldbus	Tracking
DI/O	SI/O	RSR	PNS	DIO Setting					
	SI	SI SIM	SI Value	SI Comment	SO	SO Value	SO Comment		
•	SI1		□Off	FI1(Start)	SO1	□Off	FO1(Run)		
	SI2		□Off	FI2(Hold)	SO2	□Off	FO2(Held)		
	SI3		□Off	FI3(Stop)	SO3	□Off	FO3(Fault)		
	SI4		□Off	FI4(Enable)	SO4	On	FO4(Ready)		
	SI5		□Off	FI5(RSR1)	SO5	□Off	FO5(ACK1)		
	SI6		□Off	FI6(RSR2)	SO6	□Off	FO6(ACK2)		
	SI7		□Off	FI7(RSR3)	SO7	□Off	FO7(ACK3)		
	SI8		□Off	FI8(RSR4)	SO8	□Off	FO8(ACK4)		
	SI9		□Off		SO9	□Off			
	SI10		□Off		SO10	□Off			
	CI11		TOff		6011	LOU			



											<	
- 1	Position	Point	I/O	Ti	mer	Counter	Alarm	LogBook	Commun	cation St	tart Up	Fi
1)—	DI	DO	_SI/O	FI	0	PNS	DIO Sett	ing				
	SI	SI SIM	SI Val	lue	SI Co	mment	SO	SO Valu	e SO Co	omment		
- 1	SI1			ff	FI1(Start	t)	SO1		f FO1(Ru	n)		
_	SI2			ff	FI2(Hold	:l)	SO2		f FO2(He	ld)		
	SI3			ff	FI3(Stop)	SO3	DOf	f FO3(Fai	ult)		
	SI4			ff	FI4(Enal	ole)	SO4	Or	FO4(Real	ady)		
	SI5			ff	FI5(RSR	1)	SO5	DOf	f FO5(AC	CK1)		
	SI6			ff	FI6(RSR	2)	SO6		f FO6(AC	(K2)		
	SI7			ff	FI7(RSR	3)	SO7	DOf	f FO7(AC	(K3)		
	SI8			ff	FI8(RSR4	4)	SO8	DOf	f FO8(AC	:K4)		
	SI9			ff			SO9	DOf	f			

FieldBus I/O Interface

No.	Description
1	SI/O tab page.
	SI SIM,
2	If simulation is enabled, the box will appear red, otherwise it will
	appear white.
	SI Value.(It only can be set when enable simulation.)
3	If input signal is ON, the box will appear red, if input signal is OFF, the
	box will appear white.
4	SI Comment.(Double click to modify.)
	SO Value.
5	If output signal is ON, the box will appear red, if output signal is OFF,
	the box will appear white.
6	SO Comment.(Double click to modify.)



7.8.3 FieldBus Register Mapping

A.Click Fieldbus \rightarrow Register, Open Fieldbus Register Mapping Setting interface.

Position	Point	I/O	Timer	Counter	Alarm	Lo	ogBook	Communi	cation	Start Up	Fieldbus
Register	Setting										
Field	bus Registe	r Mapping									
A1_4	CTUAL	~	1 ~	Set							
No.		SRR	SRW	1	Comme	ent	Par	ameter			
1		0	0				A1_AC	TUAL			
2		0	0				A1_ACT	TUAL			
3		0	0				A2_ACT	TUAL			
4		0	0				A2_ACT	TUAL			
5		0	0								
6		0	0								
7		0	0								
8		0	0								
9		0	0								
10		0	0								
11		0	0								

Fieldbus Register Mapping Setting interface

B.Select system parameters that user required.

Parameter Name:

A1_ACTUAL: Actual angle of 1st axis

A2_ACTUAL: Actual angle of 2nd axis

A3 ACTUAL: Actual angle of 3rd axis

A4_ACTUAL: Actual angle of 4th axis

A5_ACTUAL: Actual angle of 5th axis

A6_ACTUAL: Actual angle of 6th axis

X_ACTUAL: Actual X coordinate of TCP

Y_ACTUAL: Actual Y coordinate of TCP

Z_ACTUAL: Actual Z coordinate of TCP

A_ACTUAL: Actual A coordinate of TCP

B_ACTUAL: Actual B coordinate of TCP

C_ACTUAL: Actual C coordinate of TCP

ERR_CODE: Error code

TCP_SPEED: Actual speed of TCP



Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus
Register	Setting								
Fieldb	ous Registe	r Mappi	ng						
A1_A	CTUAL	N	1 ~	Set					
A1_A	CTUAL	45							
A2_A	CTUAL								
A3_A	CTUAL		SRV	N	Comment	Par	ameter		
A4_A	CTUAL		0			A1_AC	TUAL		
A6_A	CTUAL		0			A1_AC	TUAL		
	TUAL	- H	0			42.40			
	TUAL		0			AZ_AC	TUAL		
A AC	TUAL		0			A2_AC	TUAL		
B_AC	TUAL		0						
ERR_(CODE		0						
TCP_	SPEED	_	0						
8		0	0						
9		0	0						
10		0	0						
11		0	0						

Select system parameter interface

C.Select saving register number storage for parameter interface.



選擇系統參數儲存在哪個暫存器編號的介面

D. Click [Set] to save the setting.



Register	Setting					
Field	ous Register M	Mapping				
A1_A	CTUAL	~ 3	~	Set		
No.	SF	RR	SRW	Comment	Parameter	
1	0)	0			
2	0)	0			
3	()	4437		A1_ACTUAL	
4	()	1		A1_ACTUAL	
5	()	0			

Click [Set] button to save parameters interface

E.Click parameter column to remove the stored parameter from register.

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	Display	Mastering
Register	Setting											
Field	bus Registe	er Mapping										
A1_4	ACTUAL	~	3 ~	Set				Set Para	neter			×
No.		SRR	SRV	V	Comment	Par	ameter		Perm	we the na	rameter?	
1		0	0							ve tre pa	ameter:	45
2		0	0									
3		0	0			A1_AC	TUAL	1				
4		0	0			A1_AC	TUAL					
5		0	0					1				OK Cancel
6		0	0					-				
7		0	0									
8		0	0									
9		0	0									
10		0	0									

Remove the parameters in the register interface



F.Register parameters explanation:

A1_ACTUAL:

No.	SRR	SRW	Comment	Parameter	Angle			
1	0	0			A 1	A2	A 2	
2	0	0				AZ.	AS	A4
3	0	4437	K	A1_ACTUAL				
4	0	1	\mathbf{k}	A1_ACTUAL	60 072	0.000		0.000
5	0	0	$\backslash \backslash$		09.975	0.000	0.000	0.000
6	0	0						
7	0	0			degree	degree	mm	degre
8	0	0						
9	0	0						
			A1(69.9)	73)*1000	= 69973 =	1 * 65536 +	4437	
ieldbus R	ting egister Mapping E ~	5 ~	A1(69.97	73)*1000	= 69973 =	1 * 65536 +	4437	
ter Set ieldbus R RR_CODI	ting egister Mapping E V	5 ~	A1(69.9)	73)*1000	= 69973 =	1* 65536 +	4437	
ter Set ieldbus R RR_CODI	ting egister Mapping E	5 V	A1(69.9)	73)*1000 Parameter	= 69973 =	1 * 65536 + A2	4437 A3	Α4
ter Set ieldbus R RR_CODI	ting egister Mapping E V SRR 0	5 ~ SRW 0	A1(69.9)	73)*1000	= 69973 =	1 * 65536 + A2	4437 A3	A4
ter Set ieldbus R RR_CODI No. 1 2	ting egister Mapping E SRR 0 0	5 V SRW 0 0	A1(69.9)	Parameter	= 69973 =	A2	4437 A3	A4
ter Set ieldbus R RR_CODI No. 1 2 3 4	ting egister Mapping E SRR 0 0 0 0	5 V SRW 0 0 20436 65525	A1(69.9)	73)*1000 Parameter A1_ACTUAL A1_ACTUAL	= 69973 =	A2	A3	A4 0.000
ter Set ieldbus R RR_CODI No. 1 2 3 4 5	ting egister Mapping E SRR 0 0 0 0 0 0	5 V SRW 0 20436 65535 0	A1(69.9)	Parameter Parameter A1_ACTUAL A1_ACTUAL ERB CODE	= 69973 =	A2	A3 0.000	A4 0.000
ter Set ieldbus R RR_CODI No. 1 2 3 4 5 6	ting egister Mapping E SRR 0 0 0 0 0 0 0 0 0 0	5 V SRW 0 20436 65535 0 0	A1(69.9)	Parameter A1_ACTUAL A1_ACTUAL ERR_CODE	= 69973 =	A2	A3 0.000	A4
ter Set ieldbus R RR_CODI No. 1 2 3 4 5 6 7	ting egister Mapping E SRR 0 0 0 0 0 0 0 0 0 0 0 0 0	5 V SRW 0 20436 65535 0 0 0	A1(69.9)	Parameter Parameter A1_ACTUAL A1_ACTUAL ERR_CODE ERR_CODE ERR_CODE	= 69973 =	A2 0.000 degree	4437 A3 0.000 mm	A4 0.000 degree
ter Set ieldbus R RR_CODI No. 1 2 3 4 5 6 6 7 8	ting egister Mapping E SRR 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	5 V SRW 0 0 20436 65535 0 0 0 0	A1(69.9)	Parameter A1_ACTUAL A1_ACTUAL A1_ACTUAL ERR_CODE ERR_CODE ERR_CODE	= 69973 =	A2 0.000 degree	4437 A3 0.000 mm	A4 0.000 degree
ster Set ieldbus R RR_CODI No. 1 2 3 4 5 5 6 6 7 7 8	ting egister Mapping SRR 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	5 V SRW 0 0 20436 65535 0 0 0 0 0 0	A1(69.9)	Parameter A1_ACTUAL A1_ACTUAL ERR_CODE ERR_CODE ERR_CODE	= 69973 =	A2 0.000 degree	4437 A3 0.000 mm	A4 0.000 degree

Error Code:

				Register	Setting					
				Fieldb	us Registe	r Mapping				
Clear				A1_ACTUAL V 1 V						
Date	Time	Error Code	Description							
2020/03/30	12:01:36	Err03-03-41	A3 error - S-2220	No.		SRR	SRW	Comment	Parameter	
				1		0	0			
Driver Error Code 2220(hex) = 8736(dec)						0	0			
NULL.define 0 🔸				3		0	4437		A1_ACTUAL	
Error Code 0341(hex) = 833(dec) Device = 03(hex) = 3(dec)						0	1		A1_ACTUAL	
						0	8736		ERR_CODE	
						0	0		ERR_CODE	
				7		0	833		ERR_CODE	
				8		0	3		ERR_CODE	
				9		0	0			



7.8.4 Field Bus Register(SRR SRW)

Operating steps

- 3. Click the tab of [FieldBus].
- 4. Click the sub tab of [Register].

Description

- A. SRR (Register for Read) and SRW (Register for Write).
- B. When using Protocol1, SRR[1]~SRR[16]
 SRW[1]~SRW[16] can be used.
 - a. When Occupancy is 1, SRR[1]~SRR[4] 、 SRW[1]~SRW[4] can be used.
 - b. When Occupancy is 2, SRR[1]~SRR[8] 、 SRW[1]~SRW[8] and so on.
- C. When using Protocol2, SRR[17]~SRR[32]
 SRW[17]~SRW[32] can be used.
 - a. When Occupancy is 1, SRR[17]~SRR[20] 、 SRW[17]~SRW[20] can be used.
 - b. When Occupancy is 2, SRR[17]~SRR[24] SRW[17]~SRW[24] and so on.
- D. Value can be written or read directly through interface.
 - a. SRR column can be read but not modify.
 - b. SRW column can modify when clicked.
 - c. Range of input value is -32767~-32767.
 - d. Comment after modified will be saved.
- E. Can be controlled by command.
 - a. Command \$SRW[n] can be used to set SRW status.
 - b. Command \$SRR[n] can be used to set SRR status.



FieldBus RS interface



項號	說明			
	Select system parameters that user required.			
	Parameter Name:			
	A1_ACTUAL: Actual angle of 1 st axis			
	A2_ACTUAL: Actual angle of 2 nd axis			
	A3_ACTUAL: Actual angle of 3 rd axis			
	A4_ACTUAL: Actual angle of 4 th axis			
	A5_ACTUAL: Actual angle of 5 th axis			
1	A6_ACTUAL: Actual angle of 6 th axis			
1	X_ACTUAL: Actual X coordinate of TCP			
	Y_ACTUAL: Actual Y coordinate of TCP			
	Z_ACTUAL: Actual Z coordinate of TCP			
	A_ACTUAL: Actual A coordinate of TCP			
	B_ACTUAL: Actual B coordinate of TCP			
	C_ACTUAL: Actual C coordinate of TCP			
	ERR_CODE: Error code			
	TCP_SPEED: Actual speed of TCP			
2	Register number storage for parameter interface.			
3	Click [Set] to save the setting.			
4	The value of SRR for the specific register.			
5	The value of SRW for the specific register.			
6	The comment of the specific register.			
7	System parameter name for the specific register.			
	Click parameter column to remove the stored parameter from			
	register.			



7.8.5 Fieldbus EtherNet IP

<u>Description</u>

Adding EtherNet\IP Adapter communication into the current Fieldbus function; this is mainly used for hidden message communication (Implicit Message). It provides IO and Register data transmission, which means SI, SO, SRR and SRW data transmissions.

Instructions

- 1.Click the FieldBus tab in the function tab.
- 2.Click the Setting tab.

3.Set the EtherNet\IP Adapter parameters; refer to the table below for parameter descriptions.



FieldBus EtherNet IP interface window

No.	Name	Description
1	Brotocol Status	Displays the connection status of the protocol.
	Display	If connected successfully, a red block will be displayed; if connection
		failed or it is not set as enabled, a white block will be displayed.
2	Protocol number	Select the protocol to connect; either Channel 1 or Channel 2 can be
	Protocornumber	selected.
3	Connection type	Select the connection type; please select [EtherNet/IP Adapter].
4	Connect button	Performs connection or disconnection.
5	Remote IP setting	The IP address of the IP Adapter must be set.
6	Length setting	Input/output length must be set; allowed ranges are 0~83 Bytes.
7	Register length	Input/output register length must be set; allowed ranges are 0~83
	setting	Words.

FieldBus EtherNet IP parameter description table

4. When selection is completed, click the "Connect" button to connect and save settings. Next time it restarts, this setting will be used to perform in this connection.


8. Inquire Error Message And Solution Description

The error message with * symbol, on behalf of this error does not stop robot.

8.1 Robot system software,01-XX-XX)

Error Code	Error Name	Message	Reason	Solution	
01-01-10	System initialization	System initialization	Software damaged		
01-01-10	failure	failure	or lost		
01 01 11	Motion library load	Motion library load			
01-01-11	failure	failure			
01 01 12	Motion library			Need to re-install	
01-01-12	initialization failure		Matian libuan	software.	
	Motion library	initialization failure		Please contact the	
01-01-13	memory initialization	Initialization failure	damaged or lost	engineer from	
	failure			manufacturer.	
	Motion library start	Motion library start			
01-01-14	failure	failure			
	EtherCAT library	EtherCAT library loading			
01-01-20	loading failure	failure	Software damaged		
	EtherCAT				
01-01-21	disconnection				
	EtherCAT				
01-01-22	initialization failure				
	EtherCAT line				
01-01-23	crossing alarm			1.Check the drive	
	EtherCAT none slave			EtherCAT	
01-01-24	alarm			connection status.	
	EtherCAT can't check		EtherCAT	2.Please turn off	
01-01-25	slave	EtherCAT anomalies	connection	then restart.	
	EtherCAT slave none		anomalies	3.Please contact	
01-01-26	response			the engineer from	
				manufacturer.	
01-01-27	EtherCAT cycle alarm				

8.1.1 System Error Message(01-01-XX)



Error Code	Error Name	Message	Reason	Solution
01-01-28	EtherCAT cycle jitter			
01 01 20	EtherCAT cycle			
01-01-29	counter error			
01-01-2A	EtherCAT cycle			
01-01-2A	watchdog error			
01 01 20	EtherCAT INIT			
01-01-2B	switching error			1.Check the
	EtherCAT PREOP			drive EtherCAT
01-01-20	switching error			connection status.
01 01 20	EtherCAT SAFEOP		EtherCAT	2.Please turn
01-01-20	switching error	EtherCAT anomalies	connection	off the power and
01-01-2F	EtherCAT OP		anomalies	then restart.
01-01-21	switching error			3.Please contact the engineer from manufacturer.
01-01-2E	EtherCAT master			
01-01-26	none response			
	EtherCAT master			
	initialization error			
	EtherCAT busbar	-		
01-01-31	scan error			
01 01 02	EtherCAT frame			
01-01-32	response error			1.Check the
01-01-33	EtherCAT frame lost			drive EtherCAT
	EtherCAT master			connection status.
01 01 24	counter error of		EtherCAT	2.Please turn
01-01-34	initialization	EtherCAT anomalies	connection	off the power and
	command		anomalies	then restart.
	EtherCAT master			3.Please contact
01 01 25	response error of			the engineer from
01-01-22	initialization			manufacturer.
	command			
	EtherCAT slave			1.Check the
01-01-36	counter error of		FtherCAT	drive EtherCAT
01-01-20	initialization	FtherCAT anomalies	connection	connection status.
	command		anomalies	2.Please turn
01-01-37	EtherCAT slave			off the power and
01-01-37	response error of			then restart.



Error Code	Error Name	Message	Reason	Solution
	initialization			3.Please contact
	command			the engineer from
01-01-38	EtherCAT mailbox			manufacturer.
	time out			
01 01 20	EtherCAT mailbox			
01-01-39	SDO cancel			
	EtherCAT mailbox			
01-01-3A	COE counter receive			
	error			
	EtherCAT mailbox			
01-01-3B	COE counter send			
	error			
01 01 20	EtherCAT mailbox			
01-01-3C	receive invalid data			
01 01 25	EtherCAT master			
01-01-3D	alarm			
01 01 40	Axis 1 parameter			
01-01-40	setting fail			
01 01 41	Axis 2 parameter			
01-01-41	setting fail			
01 01 42	Axis 3 parameter			
01-01-42	setting fail			If reinstall software
01 01 42	Axis 4 parameter			is required, please
01-01-43	setting fail	Custom on omolios	Software damaged	contact engineer
01 01 44	Axis 5 parameter	System anomalies	or lost	from the original
01-01-44	setting fail			equipment
04.04.45	Axis 6 parameter			manufacturer.
01-01-45	setting fail			
01 01 50	Conveyor 1 encoder			
01-01-20	initial fail			
01 01 51	Conveyor 2 encoder			
01-01-51	initial fail			



Error Code	Error Name	Message	Reason	Solution
01-01-52	Conveyor 3 encoder initial fail			
01-01-53	Conveyor 4 encoder initial fail	System	Software damaged	If reinstall software is required, please contact
01-01-54	External parameter initial fail	anomalies	oriost	equipment manufacturer.
01-01-55	HRSS Loading fail			
01-01-58	FBWF memory consumption 128MB	FBWF memory consumption 128MB	FBWF anti-write memory is full to 128 MB	User needs to reboot
01-01-59	FBWF memory consumption 512MB	FBWF memory consumption 512MB	FBWF anti-write memory is full to 512 MB	User needs to reboot
01-01-60	FBWF file failed to open	FBWF file failed to open	File damage	Confirm that the file is damaged
01-01-80	Set infinite rotation for the external axis failed	Set infinite rotation for the external axis failed	The external axis is set to enable coupled coordinated movement, and cannot be set as an infinite rotation function.	Please disable the coordinated movement of the external axis first and then set the infinite rotation function.
01-01-81	The external axis must be set to synchronous mode	The external axis must be set to synchronous mode	It Was not set as synchronous mode correctly; movement abnormal.	Please set the external axis as synchronous mode.
01-01-82	The external axis must be set to asynchronous mode	The external axis must be set to asynchronous mode	It Was not set as asynchronous mode correctly; movement abnormal.	Please set the external axis as as asynchronous mode.
01-01-83	External axis movement type error	External axis movement type error	External axis movement type setting error.	If it was originally set as linear axis, please change it to rotation axis; if it was



Error Code	Error Name	Message	Reason	Solution
				originally set as rotation axis, please change it to linear axis.
01-01-84	External axis tracking number error	External axis tracking number error	External axis tracking currently only supports E2 axis tracking E1; tracking number setting error.	The correct setting is to set the E2 axis to track the E1 axis.
01-01-85	External axis motion base error	External axis motion base error	Motion base of the external axis could not be correctly set.	Please confirm whether the calibration point for the coordinated coupling of the external axis is correct.



8.1.2 Program Error(01-02-XX)

Error Code	Error Name	Message	Reason	Solution
	Program code incorrect	Program code format incorrect	Syntax error.	Check robot language. Please refer to 8.1.11Message modification.
01-02-10	Program syntax error. Start Symbol should less than two	More than two starting symbol characters are set	More than two starting symbol characters are set	Set the correct starting symbol
	Program syntax error. Split Symbol should less than two	More than two delimiter characters are set	More than two delimiter characters are set	Set the starting symbol for the delimiter
	Program syntax error. End Symbol should less than two	More than two end symbol characters are set	More than two end symbol characters are set	Set the starting symbol for the end
	Format error	Argument format error	 1.It is set as both the starting symbol and ending symbol simultaneously 2.Delimiter not set Set the symbol as matching format 	 Set the start symbol and end symbol Set the delimiter Confirm that the symbol input conforms to the hexadecimal ASCII CODE
01-02-11	Try to repair the corrupted file. Please confirm the program content is correct before execute.	Program file open failure.	Files are damaged or lost.	Use backup file or create new file.
01-02-12	Program copy error	Program file copy error	Program file copy error	Please export the history record and send it back to original factory for analysis.



8.1.3 Motion Error(01-03-XX)

Error Code	Error Name	Message	Reason	Solution
01-03-10	Axis 1 following error too big	Axis 1 position over deviation	Axis 1 motion command or actual position exceeded deviation too big.	
01-03-11	Axis 2 following error too big	Axis 2 position over deviation	Axis 2 motion command or actual position exceeded deviation too big.	1. Reduce speed •
01-03-12	Axis 3 following error too big	Axis 3 position over deviation	Axis 3 motion command or actual position exceeded deviation too big.	3. Reduce acceleration.
01-03-13	01-03-13	Axis 4 following error too big	Axis 4 motion command or actual position exceeded deviation too big.	
01-03-14	01-03-14	Axis 5 following error too big	Axis 5 motion command or actual position exceeded deviation too big.	 Reduce speed ° Reduce load. Reduce acceleration. °
01-03-15	01-03-15	Axis 6 following error too big	Axis 6 motion command or actual position exceeded deviation too big.	
01-03-16	Axis 1 position overlimit of positive	Axis 1 exceeded positive rotation limit	Motion to Axis 1 reach positive limit	Axis 1 move negative
01-03-17	Axis 1 position overlimit of negative	Axis 1 exceeded negative rotation limit	Motion to Axis 1 reach negative limit	Axis 1 move positive



Error Code	Error Name	Message	Reason	Solution
	Axis 2 position	Axis 2 exceeded	Motion to Axis 2	
01-03-18	overlimit of	positive rotation	reach positive	Axis 2 move negative
	positive	limit	limit	
	Axis 2 position	Axis 2 exceeded	Motion to Axis 2	
01-03-19	overlimit of	negative	reach negative	Axis 2 move positive
	negative	rotation limit	limit	
	Axis 3 position	Axis 3 exceeded	Motion to Axis 3	
01-03-1A	overlimit of	positive rotation	reach positive	Axis 3 move negative
	positive	limit	limit	
	Axis 3 position	Axis 3 exceeded	Motion to Axis 3	
01-03-1B	overlimit of	negative	reach negative	Axis 3 move positive
	negative	rotation limit	limit	
	Axis 4 position	Axis 4 exceeded	Motion to	
01-03-10	overlimit of	nositive rotation	Axis 4 reach	Axis 4 move negative
01 00 10	positive	limit	positive limit	nuis 4 move negative
	positive		Motion to	
	Axis 4 nosition	Axis 4 exceeded	Axis 4 reach	
01-03-1D	overlimit of	negative	negative limit	Axis 4 move positive
01 00 10	negative	rotation limit	Motion to Axis 5	
			reach	
	Axis 5 position	Axis 5 exceeded		
01-03-1E	overlimit of	positive rotation	positive limit	Axis 5 move negative
	positive	limit		
	Axis 5 position	Axis 5 exceeded	Motion to Axis 5	
01-03-1F	overlimit of	negative	reach negative	Axis 5 move positive
	negative	rotation limit	limit	
	Axis 6 position	Axis 6 exceeded	Motion to Axis 6	
01-03-20	overlimit of	positive rotation	reach positive	Axis 6 move negative
	positive	limit	limit	
	Axis 6 position	Axis 6 exceeded	Motion to Axis 6	
01-03-21	overlimit of	negative	reach negative	Axis 6 move positive
	negative	rotation limit	limit	
	XY coordinate	XY coordinates	Motion to XY	Clear error and move in
01-03-30	overlimit of	reached the	coordinate limit	opposite limit direction
	software	limit		
01-03-31	Joint overspeed	Shaft over	Reverse solution	Clear error and use PTP motion
01-02-21	Joint Overspeed	speed	to determine a	



Error Code	Error Name	Message	Reason	Solution
			shaft speed too	
			fast.	
01-02-22	Wrist singularity	Near wrist	Near wrist	Try to avoid the singular point of
01-03-32	01-05-52 Whise singularity	singular point	singular point	motion
01-02-22	Shoulder	Near shoulder	Near shoulder	
01-03-33	singularity	singular point	singular point	
01-03-34	Elbow	Near elbow	Near elbow	
01-03-34	singularity	singular point	singular point	
01-03-40	Circle command 3 reference points on the same line	Circle command on the same line		
01-03-41	Circle comm can't found center point	Unable to calculate center of circle in two point space	Command setting error.	Check CIRC description.
01-03-42	Circle comm can't calculate transpose matrix	Circle command parameter error, unable to calculate transpose matrix		
01-03-50	Synchronize output queue overflow	Synchronize output command buffer overflow	Synchronize output command too much, causing buffer overflow	1. Please check if the connecting line is correctly connected, and turn off the power and then re-start.
01-03-51	Synchronize output overlimit	Synchronize output control command overlimit	Synchronize activate output command too much	2. Please contact engineer from the original equipment manufacturer.
01-03-52	Found motion command when compliance teaching	During compliance tuning, send motion command	Motion command cannot be performed during compliance tuning.	Clear error and stop sending motion command
(110x1 hage)				



Error Code	Error Name	Message	Reason	Solution
01-03-53	Collision behavior occurred to axis 1			
01-03-54	Collision behavior occurred to axis 2			
01-03-55	Collision behavior occurred to axis 3			
01-03-56	Collision behavior occurred to axis 4			1 Clear the alarm and check
01-03-57	Collision behavior occurred to axis 5	Collision behavior occurred to robot	1. Collision occurred 2. False alarm occurred	whether the movement caused collision behaviors. 2. Please contact the engineer
01-03-58	Collision behavior occurred to axis 6			from the manufacturer.
01-03-59	Collision behavior occurred to axis E1			
01-03-5A	Collision behavior occurred to axis E2			
01-03-5B	Collision behavior occurred to axis E3			



Error Code	Error Name	Message	Reason	Solution
01-03-60	Load estimation file processing abnormal		1. Missing file 2. File data error	1. Execute the load estimation
01-03-61	Load identification file abnormal	File error	1. Missing file 2.	function again.2. Please contact the engineer from the manufacturer.
01-03-62	Identification parameter abnormal		File open error	
01-03-70	Axis 1 exceeded software lower limit	Position of axis 1 exceeded the setting value of the software lower limit	 The end position command issued exceeded the setting value for the software lower limit of axis The position of the robot while moving exceeded the setting value for the software lower limit of axis 1 	 Adjust the movement instruction position and avoid issuing commands that exceed the software limit movement direction. Adjust the software limit setting value so that the robot movement range does not exceed the setting value.
01-03-71	Axis 1 exceeded software upper limit	Position of axis 1 exceeded the setting value of the software upper limit	 The end position command issued exceeded the setting value for the software upper limit of axis The position of the robot while moving exceeded the setting value for the software upper limit of axis 	 Adjust the movement instruction position and avoid issuing commands that exceed the software limit movement direction. Adjust the software limit setting value so that the robot movement range does not exceed the setting value.



Error Code	Error Name	Message	Reason	Solution
01-03-72	Axis 2 exceeded software lower limit	Position of axis 2 exceeded the setting value of the software lower limit	 The end position command issued exceeded the setting value for the software lower limit of axis The position of the robot while moving exceeded the setting value for the software lower limit of axis 2 	
01-03-73	Axis 2 exceeded software upper limit	Position of axis 2 exceeded the setting value of the software upper limit	 The end position command issued exceeded the setting value for the software upper limit of axis The position of the robot while moving exceeded the setting value for the software upper limit of axis 2 	
01-03-74	Axis 3 exceeded software lower limit	Position of axis 3 exceeded the setting value of the software lower limit	 The end position command issued exceeded the setting value for the software lower limit of axis 3 	



Error Code	Error Name	Message	Reason	Solution
01-03-75	Axis 3 exceeded software upper limit	Position of axis 3 exceeded the setting value of the software upper limit	2. The position of the robot while moving exceeded the setting value for the software lower limit of axis 3 1. The end position command issued exceeded the setting value for the software upper limit of axis 3 2. The position of the robot while	Solution
01-03-76	Axis 4 exceeded software lower limit	Position of axis 4 exceeded the setting value of the software lower limit	moving exceeded the setting value for the software upper limit of axis 3 1. The end position command issued exceeded the setting value for the software lower limit of axis 4 2. The position of the robot while moving exceeded the setting value for the software lower limit of axis 4	 Adjust the movement instruction position and avoid issuing commands that exceed the software limit movement direction. Adjust the software limit setting value so that the robot movement range does not exceed the setting value.



Error Code	Error Name	Message	Reason	Solution
01-03-77	Axis 4 exceeded software upper limit	Position of axis 4 exceeded the setting value of the software upper limit	 The end position command issued exceeded the setting value for the software upper limit of axis The position of the robot while moving exceeded the setting value for the software upper limit of axis 4 	
01-03-78	Axis 5 exceeded software lower limit	Position of axis 5 exceeded the setting value of the software lower limit	 The end position command issued exceeded the setting value for the software lower limit of axis 2. The position of the robot while moving exceeded the setting value for the software lower limit of axis 5 	
01-03-79	Axis 5 exceeded software upper limit	Position of axis 5 exceeded the setting value of the software upper limit	 The end position command issued exceeded the setting value for the software lower limit of axis 	 Adjust the movement instruction position and avoid issuing commands that exceed the software limit movement direction. Adjust the software limit setting value so that the robot



Error Code	Error Name	Message	Reason	Solution
Error Code	Error Name Axis 6 exceeded software lower limit	Message Position of axis 6 exceeded the setting value of the software lower limit	Reason2. The position ofthe robot whilemoving exceededthe setting valuefor the softwarelower limit of axis51. The endpositioncommand issuedexceeded thesetting value forthe softwarelower limit of axis62. The position ofthe robot whilemoving exceededthe setting valuefor the software	Solution movement range does not exceed the setting value.
01-03-7B	Axis 6 exceeded software upper limit	Position of axis 6 exceeded the setting value of the software upper limit	lower limit of axis 6 1. The end position command issued exceeded the setting value for the software upper limit of axis 6 2. The position of the robot while moving exceeded the setting value for the software upper limit of axis 6 1. The end	
01-03-7C	Tool center exceeded the	Position of tool center exceeded	1. The end position	



Error Code	Error Name	Message	Reason	Solution
	software lower	the setting value	command issued	
	limit of X	for the software	exceeded the	
		lower limit of X	setting value for	
			the software	
			lower limit of X	
			2. The position of	
			the robot while	
			moving exceeded	
			the setting value	
			for the software	
			lower limit of X	
			1. The end	
			position	
			command issued	
			exceeded the	
	Tool contor	Position of tool	setting value for	
	roor center	center exceeded	the software	
01-03-7D	exceeded the	the setting value	upper limit of X	
	limit of X	for the software	2. The position of	
		upper limit of X	the robot while	
			moving exceeded	1 Adjust the movement
			the setting value	instruction position and avoid
			for the software	issuing commands that exceed
			upper limit of X	the software limit movement
			1. The end	direction
			position	2. Adjust the software limit
			command issued	setting value so that the robot
			exceeded the	movement range does not
	Tool center	Position of tool	setting value for	exceed the setting value.
	exceeded the	center exceeded	the software	
01-03-7E	software lower	the setting value	lower limit of X	
	limit of Y	for the software	2. The position of	
		lower limit of Y	the robot while	
			moving exceeded	
			the setting value	
			for the software	
			lower limit of X	
01-03-7F	Tool center	Position of tool	1. The end	
	exceeded the	center exceeded	position	



Error Code	Error Name	Message	Reason	Solution
	software upper	the setting value	command issued	
	limit of Y	for the software	exceeded the	
		upper limit of Y	setting value for	
			the software	
			upper limit of X	
			2. The position of	
			the robot while	
			moving exceeded	
			the setting value	
			for the software	
			upper limit of X	
			1. The end	
			position	
			command issued	
			exceeded the	
	Tool contor	Position of tool	setting value for	
	roor center	center exceeded	the software	
01-03-80	exceeded the	the setting value	lower limit of X	
	software lower	for the software	2. The position of	
	limit of Z	lower limit of Z	the robot while	
			moving exceeded	
			the setting value	
			for the software	
			lower limit of X	
			1. The end	
			position	
			command issued	
			exceeded the	1. Adjust the movement
		Position of tool	setting value for	instruction position and avoid
	1001 center	center exceeded	the software	issuing commands that exceed
01-03-81	exceeded the	the setting value	upper limit of Z	the software limit movement
	software upper	for the software	2. The position of	direction.
	limit of Z	upper limit of Z	the robot while	2. Adjust the software limit
			moving exceeded	setting value so that the robot
			the setting value	movement range does not
			for the software	exceed the setting value.
			upper limit of Z	
01 02 02	Tool center	Position of tool	1. The end	
01-03-82	exceeded the	center exceeded	position	



Error Code	Error Name	Message	Reason	Solution
	software lower	the setting value	command issued	
	limit of the	for the software	exceeded the	
	radius	lower limit of	setting value for	
		the radius	the software	
			lower limit of the	
			radius	
			2. The position of	
			the robot while	
			moving exceeded	
			the setting value	
			for the software	
			lower limit of the	
			radius	
			1. The end	
			position	
			command issued	
			exceeded the	
		Position of tool	setting value for	
	Tool center	center exceeded	the software	
	exceeded the	the setting value	upper limit of the	
01-03-83	software upper	for the software	radius	
	limit of the	upper limit of	2. The position of	
	radius	the radius	the robot while	
			moving exceeded	
			the setting value	
			for the software	
			upper limit of the	
			1 Torque limit	
			detection limit	
			range setting	
			error	
	Instruction	Instruction	2 Setting limit	Refer to the software manual
01-03-84	TL_SET	TL_SET	narameter issued	and follow the instructions
	execution error	execution error	while stonning	carefully.
			the execution of	
			torque limit	
			detection	



Error Code	Error Name	Message	Reason	Solution
			Start instruction	
	Instruction	Instruction	issued while	Refer to the software manual
01-03-85	TL_START	TL_START	torque limit	and follow the instructions
	execution error	execution error	parameters not	arefully.
			set	
	Axis 1 torque	Axis 1 overload,		
01-03-87	over max setting	excessive	Axis 1 overload.	
	value.	torque.		
	Axis 2 torque	Axis 2 overload,		
01-03-88	over max setting	excessive	Axis 2 overload.	
	value.	torque.		
	Axis 3 torque	Axis 3 overload,		
01-03-89	over max setting	excessive	Axis 3 overload.	
	value.	torque.		1. Reduce the operating speed.
	Axis 4 torque	Axis 4 overload,		2. Reduce the payload.
01-03-8A	over max setting	excessive	Axis 4 overload.	
	value.	torque.		
	Axis 5 torque	Axis 5 overload,		
01-03-8B	over max setting	excessive	Axis 5 overload.	
	value.	torque.		
	Axis 6 torque	Axis 6 overload,		
01-03-8C	over max setting	excessive	Axis 6 overload.	
	value.	torque.		



8.1.4 Operation Erro(01-04-XX)

Error Code	Error Name	Message	Reason	Solution
	Read driver 1	Axis 1 absolute	Read axis 1	
01-04-10	encoder is	encoder position	encoder under	
	abnormality	error	moving status	
	Read driver 2	Axis 2 absolute	Read axis 5	
01-04-11	encoder is	encoder position	encoder under	
	abnormality	error	moving status	
	Read driver 3	Axis 3 absolute	Read axis 3	
01-04-12	encoder is	encoder position	encoder under	
	abnormality	error	moving status	Please confirm whether the
	Read driver 4	Axis 4 absolute	Read axis 4	brake shaft is falling.
01-04-13	encoder is	encoder position	encoder under	
	abnormality	error	moving status	
	Read driver 5	Axis 5 absolute	Read axis 5	
01-04-14	encoder is	encoder position	encoder under	
	abnormality	error	moving status	
	Read driver 6	Axis 6 absolute	Read axis 6	
01-04-15	encoder is	encoder position	encoder under	
	abnormality	error	moving status	
	Write data to	Axis 1 driver	Driver 1	Check driver 1 connection.
01-04-16	driver 1 is	parameter write	connection is	
	abnormality	back failed	abnormality	
	Write data to	Axis 2 driver	Driver 2	Check driver 2 connection.
01-04-17	driver 2 is	parameter write	connection is	
	abnormality	back failed	abnormality	
	Write data to	Axis 3 driver	Driver 3	Check driver 3 connection.
01-04-18	driver 3 is	parameter write	connection is	
	abnormality	back failed	abnormality	
	Write data to	Axis 4 driver	Driver 4	Check driver 4 connection.
01-04-19	driver 4 is	parameter write	connection is	
	abnormality	back failed	abnormality	
	Write data to	Axis 5 driver	Driver 5	Check driver 5 connection.
01-04-1A	driver 5 is	parameter write	connection is	
	abnormality	back failed	abnormality	
	Write data to	Axis 6 driver	Driver 6	Check driver 6 connection.
01-04-1B	driver 6 is	parameter write	connection is	
	abnormality	back failed	abnormality	



Error Code	Error Name	Message	Reason	Solution
01-04-1C	Clear driver 1 encoder is abnormality	Clear Axis 1 driver encoder failed	Driver 1 connect is abnormality. 2. The command is forbidden	 Check driver 1 connected. Check driver 1 status.
01-04-1D	Clear driver 2 encoder is abnormality	Clear Axis 2 driver encoder failed	Driver 2 connect is abnormality. 2. The command is forbidden	 Check driver 2 connected. Check driver 2 status.
01-04-1E	Clear driver 3 encoder is abnormality	Clear Axis 3 driver encoder failed	Driver 3 connect is abnormality. 2. The command is forbidden	 Check driver 3 connected. Check driver 3 status.
01-04-1F	Clear driver 4 encoder is abnormality	Clear Axis 4 driver encoder failed	Driver 4 connect is abnormality. 2. The command is forbidden	 Check driver 4 connected. Check driver 4 status.
01-04-20	Clear driver 5 encoder is abnormality	Clear Axis 5 driver encoder failed	Driver 5 connect is abnormality. 2. The command is forbidden	 Check driver 5 connected. Check driver 5 status.
01-04-21	Clear driver 6 encoder is abnormality	Clear Axis 6 driver encoder failed	Driver 6 connect is abnormality. 2. The command is forbidden	 Check driver 6 connected. Check driver 6 status.
01-04-30	Start position declination is abnormality			
01-04-31	A1 declination is abnormality			
01-04-32	A2 declination is abnormality	Robot position	The robot's position is different	Please move to the origin and confirm that the
01-04-33	-04-33 A3 declination is abnormality	declination	last powered off.	Refer 3.6
01-04-34	A4 declination is abnormality			
01-04-35	A5 declination is abnormality			



Error Code	Error Name	Message	Reason	Solution	
01 04 20	A6 declination is				
01-04-30	abnormality				
	Axis E1 position				
01-04-37	exceeded				
	deviation				
	Axis E2 position				
01-04-38	exceeded				
	deviation				
	Axis E3 position				
01-04-39	exceeded				
	deviation				
01 04 40	RSR(&NUM) no	DSD file not cot	RSR execution file	Confirm that the execution	
01-04-40	file	KSK ME HOLSEL	not set	file is set.	
01 04 41	PNS(&NUM) no	DNS file not cot	PNS execution file		
01-04-41	file	FINS THE HOL SEL	not set		
				1. Please turn off the power	
	ISB delay stack	ISR delay huffer	ISB delay buffer	and then re-start.	
01-04-50	overflow	overflow	overflow	2. please contact engineer	
	overnow	overnow	overnow	from the original equipment	
				manufacturer.	
	Motion	Motion command	Motion command	1. Please turn off the power	
01-04-51	command	buffer overflow	too much, causing	and then re-start.	
	queue overflow		buffer overflow	2. If it is still unable to	
	log queue	log command	Jog command too	resolve,please contact	
01-04-52	overflow	buffer overflow	much, causing	engineer from the original	
			buffer overflow	equipment manufacturer.	
		Interpolation	Interpolation		
01-04-53	Interpolation	command buffer	command too		
	buffer overflow	overflow	much, causing		
			buffer overflow		
	Modify Time	* Time is	Time Setting is	Inform user time setting is	
01-04-60	Setting	modified, will not	modified, will not	modified, will not shutdown	
		shutdown.	shutdown	· · · · · · · · · · · · · · · · · · ·	
	Modify NTP	*NTP is modified,	NTP Setting is	Inform user NTP is modified.	
01-04-61	Setting	will not	modified, will not	will not shutdown	
		shutdown.	shutdown		
01-04-70	Infinite rotation	Infinite rotation is	User operates	After the user turns on the	
	is not turned on.	not turned on.	infinite rotation in	infinite rotation function in	



Error Code	Error Name	Message	Reason	Solution
			infinite rotation	the interface, the user
			function interface,	executes the CT_A6
			and executes the	command.
			CT_A6 command.	



8.1.5 IO & Communication(01-05-XX)

Error Code	Error Name	Message	Reason	Solution
01-05-10	Teach Pendant connection error	TP connection error	 1.TP destroy. 2.TP connection port is abnormal. 	1.Change TP. 2.Check connect port.
01-05-20	ROBOT IO connection error	Robot IO connection error	Interference	Confirm RIO wire.
01-05-21	ROBOT IO disconnection	Robot IO disconnection	1.Robot IO destroy 2.Robot IO port is abnormal.	 Change Robot IO. Confirm RIO port.
01-05-30	Network disconnection	Network disconnection	Network is abnormal.	Check network connection.
01-05-31	Network connect failure	Network connect failure	Network server is abnormal.	 1.Check network connection server. 2.Check network domain. 3.Check connection IP and PORT setting
01-05-32	Server opened failure	Server opened failure	Server opened failure	Check connection IP and PORT setting
01-05-33	Server closed the connection	Sever connection closed	Sever automatically closed connection	Prevent sever automatically disconnect from client
01-05-34	Network port setting error	Network port setting error	Network port setting error	Check port setting.
01-05-35	Network client disconnect time out	Network client disconnect time out	Network client disconnect time out	Check sever whether interact with client disconnect message
01-05-42	Serial IO disconnected	Serial IO disconnected	Cause of disconnection	Reconnect serial IO



8.1.6 Operator Error(01-06-XX)

Error Code	Error Name	Message	Reason	Solution
01-06-10	Motion delay command abnormality	Parameter	Parameter is not within	
01-06-11	Acceleration setting command abnormality	Parameter cannot be set	the range to be set	Check parameter.
01-06-12	PTP motion command abnormality	PTP motion failed	1.Command	1 Confirm the
01-06-13	Circle motion command abnormality	CIRC motion failed	format error. 2.Unable to give motion command instruction	command format. 2. Confirm the motion
01-06-14	Line motion command abnormality	LIN motion failed		
01-06-15	Feedspeed setting command abnormality	Parameter cannot be set	Parameter cannot be set.	Check parameter.
01-06-16	Path abnormality	Moving path abnormality	The moving path is out of working range.	Re-design the position of point and the action instruction, or check if the setting of Tool and Base has any error.
01-06-17	Setting conveyor tracking acceleration error	Parameter	Parameter out of the	Check the parameter
01-06-18	Setting conveyor pick acceleration error	Parameter setting error	range	setting is correct.
01-06-19	Enable smooth motion error			



Error Code	Error Name	Message	Reason	Solution
01.00.14	Disable smooth			
01-06-1A	motion error			
01 06 20	Counter index			
01-06-20	abnormality			
01 06 21	Timer index			
01-00-21	abnormality			
	Counter stop			
01-06-22	number			
	abnormality			
01-06-22	DI index			
01-00-23	abnormality			
01 06 24	DO index			
01-00-24	abnormality			
01-06-25	RI index		Index not within setting	Confirm Index No.
01-00-25	abnormality			
01-06-26	RO index			
01-00-20	abnormality		lange	
01 06 27	-27 VI index abnormality			
01-00-27				
01-06-28	VO index	cannot bo sot		
01-00-28	abnormality			
01-06-20	SI index			
01-00-23	abnormality			
01-06-24	SO index			
01-00-2A	abnormality			
01-06-2B	SR index			
01-00-28	abnormality			
01-06-20	SRW index			
01-00-20	abnormality			
01-06-20	DI can't be		DI sotting upavailable	DI not cot
01-00-30	setting		Di setting unavaliable	Di not set
01 06 21	RI can't be		Pl cotting upavailable	Pl not sot
01-00-21	setting			
01-06-22	SI can't be		SI setting unavailable	SI not set
01-00-22	setting			
01-06-22	SO can't be		Specific SO setting not	Specific SO not sot
01-00-22	setting		available	Specific SO not set



Error Code	Error Name	Message	Reason	Solution
01-06-34	SRR can't be setting		SRR setting not available	SRR not set
01-06-35	SRW value abnormality	SRW value is abnormal.	Parameter error.	Check setting command.
01-06-36	Fieldbus Slot1 abnormality	Fieldbus Slot1 abnormality	1.Parameter	1.Set the correct parameters.
01-06-37	Fieldbus Slot2 abnormality	Fieldbus Slot2 abnormality	2.Driver is not installed. 3. Fieldbus connection abnormal.	2.Confirm that the driver installation is completed. 3Check the hardware wiring.



8.1.7 External Axis Error(01-07-XX)

Error Code	Error Name	Message	Reason	Solution
01-07-10	E1 axis following error overlimit	E1 axis position over deviation	E1 axis motion command and actual position exceeded deviation	1. Reduce the speed
01-07-11	E2 axis following error overlimit	E2 axis position over deviation	E2 axis motion command and actual position exceeded deviation	 Reduce the load weight Reduce acceleration in
01-07-12	E3 axis following error overlimit	E3 axis position over deviation	E3 axis motion command and actual position exceeded deviation	percentage
01-07-13	E1 axis position overlimit of positive	E1 axis exceeded positive rotation limit	Over the positive limit.	E1 axis move towards negative
01-07-14	E1 axis position overlimit of negative	E1 axis exceeded negative rotation limit	Over the negative limit.	E1 axis move towards positive
01-07-15	E2 axis position overlimit of positive	E2 axis exceeded positive rotation limit	Over the positive limit.	E2 axis move towards negative
01-07-16	E2 axis position overlimit of negative	E2 axis exceeded negative rotation limit	Over the negative limit.	E2 axis move towards positive
01-07-17	E3 axis position overlimit of positive	E3 axis exceeded positive rotation limit	Over the positive limit.	E3 axis move towards negative
01-07-18	E3 axis position overlimit of negative	E3 axis exceeded negative rotation limit	Over the negative limit.	E3 axis move towards positive



01-07-19	E1 axis clear encoder error	E1 axis driver clear encoder failed	 1.Connection with axis E1 is abnormal. 2.Axis E1 prohibits this command. 	 1.Check Axis E1 is connected. 2.Check Axis E1 status.
01-07-1A	E2 axis clear encoder error	E2 axis driver clear encoder failed	 1.Connection with axis E2 is abnormal. 2.Axis E2 prohibits this command. 	 1.Check Axis E2 is connected. 2.Check Axis E2 status.
01-07-1B	E3 axis clear encoder error	E3 axis driver clear encoder failed	 Connection with axis E3 is abnormal. Axis E3 prohibits this command. 	 Check Axis E3 is connected. Check Axis E3 status.
01-07-1F	Axis E1 torque over max setting value	Axis E1 overload, excessive torque.	Axis E1 overload.	
01-07-20	Axis E2 torque over max setting value	Axis E2 overload, excessive torque.	Axis E2 overload.	 Reduce the operating speed. Reduce the payload.
01-07-21	Axis E3 torque over max setting value	Axis E3 overload, excessive torque.	Axis E3 overload.	



8.1.8 Conveyor Tracking Error(01-08-XX)

Error Code	Error Name	Message	Reason	Solution
01-08-10	Camera connection failure	Connection with the vision system is failed.	1.IP setting error. 2.PORT setting error.	1.Check IP setting. 2.Check Port setting.
01-08-11	Camera connection abnormality	Connection with the vision system is failed.	Vision system no	Confirm the connection
01-08-12	Camera disconnect fail	Connection with the vision system is failed.	response.	with the vision system.
01-08-13	Pick command error	Execution	Point sotting orror	Please confirm if the information of point
01-08-14	Place command error	failed.	Point setting error.	position is entered into the instruction.
01-08-15	Conveyor encoder clear error	Encoder clear failed.	Encoder clear failed.	Check the conveyor wiring
01-08-16	Setting latch source error	Setting latch source error	Setting latch failed	
01-08-17	Start conveyor command error	Start conveyor failed	Conveyor setting failed	Check conveyor setting is correct.
01-08-18	Read encoder count error	Read encoder error	Encoder fault	Check encoder and wiring.



Error Code	Error Name	Message	Reason	Solution
01-08-19	Clear place data error	Data clearing failed	Place clearing failed	Contact an engineer from the original equipment manufacturer.
01-08-1A 01-08-1B 01-08-1C	CNV_OBJECT can't be setting CNV_FULL can't be setting CNV_EMPTY can't be setting	Unavailable to set parameters	Unavailable to set parameters	Check Robot Language.
01-08-1E	Encoder latch value inconsistent	Encoder latch value inconsistent	Trigger sensor or encoder error.	Check the trigger sensor and the encoder is normal.

8.1.9 User-Defined Error(01-09-XX)

Error Code	Error Name	Message	Reason	Solution
01 00 10	User-defined	User-defined	User defined error 1	User defined error 1
01-09-10	error 1	error 1	User-defined erfor 1	
01 00 11	User-defined	User-defined	User defined error 2	Liser defined error 2
01-09-11	error 2	error 2	User-defined erfor 2	Oser-defined erfor 2
01 00 12	User-defined	User-defined	User defined error 2	Licar defined error 2
01-09-12	error 3	error 3	User-defined erfor 5	User-defined erfor 5
01 00 12	User-defined	User-defined	User defined error 4	Lisor defined error 4
01-09-13	error 4	error 4	User-defined error 4	User-defined erfor 4
01-09-14	User-defined	User-defined	User-defined error 5	User-defined error 5
01-09-14	error 5	error 5		
01-09-15	User-defined	User-defined	Lison defined error 6	User-defined error 6
01-09-15	error 6	error 6	Oser-defined erfor 0	
01-09-16	User-defined	User-defined	User-defined error 7	User-defined error 7
01-09-10	error 7	error 7	Oser-defined erfor 7	
01-00-17	User-defined	User-defined	Usor-dofined error 8	User-defined error 8
01-03-17	error 8	error 8	Oser-defined erfor 8	User-defined error 8
01-00-18	User-defined	User-defined	User-defined error 9	User-defined error 9
01-09-18	error 9	error 9	Oser-defined erfor 5	Oser-defined erfor 5
01-09-10	User-defined	User-defined	Usor-dofined error 10	User defined error 10
01-09-19	error 10	error 10		User-defined error 10



8.1.10Authorization	Error(01-0B-XX)
---------------------	-----------------

Error Code	Error Name	Message	Reason	Solution
01-0B-10	You have no	You have no license of		
		HRSDK		
	You have no	You have no		
01-0B-11	license of	license of		
	Fieldbus	Fieldbus	1 SDK is not	1.With the original
	You have no	You have no	enabled.	purchase authorization.
01-0B-12	license of	license of	2. Function is not	2. Check whether the
	External Axis	External Axis	authorized.	authorized device is
	You have no	You have no		connected normally.
01-0B-13	license of	license of		
	External TCP	External TCP		
	You have no	You have no		
01-0B-14	license of	license of		
	Continuous Turn	Continuous Turn		



8.1.11 Windows Information

When the program is executed, if the program syntax is wrong, the following window will appear



- 1. The above figure as an example, the message is divided into two main parts:
- 1. Error location: (2: 9), on behalf of 9th words on line 2 is wrong.
- 2. Error message: syntax error

Error message description:

Error Code	Error Name	Message	Reason	Solution
01-02-10	syntax error	Syntax error	Command spelling error. Wrong space.	Check spelling and spaces.
01-02-10	ID not exist	Variable not exist	Variable not declared.	Declare variable before use.
01-02-10	Unknown character	Character cannot be recognized	Use special symbols.	Change variable name.
01-02-10	is not declared	Variable not declared	Variable not declared.	Declare variable before use.
01-02-10	Invalid value	Invalid value	Value out of range	Modify value according to instruction
01-02-10	Index of is out of range	Index is out of range	Array index out of range	Modify array index
01-02-10	Type should be	Type error	Type error.	Change to the correct type.
01-02-10	Fail in handling STRUC member expression	Structure member variable expression error	Struct member not declared.	Check the declaration of structure variables.



8.2 HIWIN robot controller(02-XX-XX)

Error Code	Error Name	Message	Reason	Solution
02-01-10	Emergency input	Emergency stop signal disconnect	Emergency stop trigger.	Release the emergency stop and clear the error.
02-01-11	Enable switch down	Enable switch down	Enable switch is pressed to the third paragraph.	Release enable switch.

8.2.1 Safety Input(02-01-XX)

8.2.2 Hardware Error(02-02-XX)

Error Code	Error Name	Message	Reason	Solution
02-02-11	No motor brake signal	Do not receive motor brake signal	 Hardware abnormalities. The emergency stop status is excluded within 500 milliseconds. 	 Contact with the engineer from the original equipment manufacturer. Press emergency stop again, over 500 millisecond.



8.3 Axis amplifier(03-XX-XX)

Error Code	Error Name	Message		
Axis number(m)	0m	m: axis umber. ex 03-01-21:axis 1 alarm, 03-02-21:axis 2 alarm, and so on.		
Ext axis number (n)	En	n: external axis number ex : 03-E1-21-> external axis 1 alarm, 03-E2-21->external axis 2 alarm, and so on.		

8.3.1 Function Name and Number Description

8.3.2 Driver Alart Number

Error Code	Error Name	Message	Reason	Solution
03-0m(En)-21	overcurrent	Current exceeds the specified value	 Driver is abnormal. Motor U, V, W is short circuit. Motor is broken. 	 Check the servomotor main circuit cable connection. Replace the driver. Replace the motor.
03-0m(En)-25	STO	Safety input protection.	Safety input signal.	Check the safety input signal status.
03-0m(En)-26	Safe torque off abnormal	Safe torque off abnormal.	Safety input signal.	Check the safety input signal status.
03-0m(En)-27	Single circuit STO	Safe input protection.	Safety input signal.	Check the safety input signal status.
03-0m(En)-30	Current control error	Current control error	 Servo malfunction. Motor malfunction. 	 Check the parameter pwr_board, write pwr_board, write pwr_board, write manufacture_data l2CEE.Sate=11 anufacture_data l2CEE.Sate=11 Change the motor.
03-0m(En)-32	HFLT inconsistent	HFLT inconsistent	1. Servo malfunction.	1. Change the DA module of that axis.



Error Code	Error Name	Message	Reason	Solution
			2. Electrical	2. Keep away and remove
			interference.	interference sources, or
				implement EMC
				countermeasures of
				magnetic rings.
	DC bus voltage abnormal	DC bus voltage abnormal	1. Servo malfunction	1. Change the DA/DP
03-0m(En)-34			2. Insufficient	module.
			capacitance for the	2. Change the HCV1
			driver.	module.
				1. Confirm that the
			1. Firmware version	firmware version is 8.197
	ECAT interface	ECAT interface cannot be detected	error.	or above.
03-0m(En)-35	cannot be		2. EtherCAT	2. Check whether the
	detected		communication	connector pins of the DA
			interface of driver	module are short-
			malfunctioned.	circuited, and replace the
				DA module.
02.0(5).26	CiA-402 reset error	CiA-402 reset error	This process cannot be completed.	Reconnect the power and
03-0m(En)-36				execute (reload the DA
			4 Faceshie	module parameters).
			1. Fan Cable	1. Change the fan.
			stuck or too dirty	
03-0m(En)-37	Fan error	Fan error	2 Continuous alarm	2. Change the HCV1
			from the DA module	backboard or DA module.
			of a specific axis	
			1 Power of encoder	
	Absolute encoder error	Absolute encoder error	in robot abnormal	
			2 Battery has no	 Change the power supply. Change the battery. Confirm the battery life or change the battery. Adjust the wiring. Send the correct clear instruction (enter the value 7 for SDO object number: 0x2060).
			voltage or low	
			voltage	
			3 Parallel battery	
03-0m(En)-38			failure or reversed	
			polarity	
			4. Battery wiring	
			installation	
			abnormal.	
			5. Did the upper	
			position send the	


Error Code	Error Name	Message	Reason	Solution
			correct clear	
			instruction?	
			1.The effective	
			torque exceeds the	1. Change the motion
		Tanana ia ta a	rated torque.	plan, or reduce load.
03-0m(En)-41	overload	lorque is too	2. The motor's hold	2. Check that the wiring
		large.	brake is not released.	and the driver voltage are
			3. Power supply	correct.
			wiring is incorrect	
			1. Insufficient	
	regenerative	Regenerative	external	1.Replace the external
03-0m(En)-43	resistor	load rate is too	regeneration resistor	regeneration resistor
	overload	large.	capacity.	
			2. Amplifier failed.	2. Replace amplifier
		Eveneded	The servomotor	
02.0m/[m] 45	overspeed	Exceeded	speed is above the	Change operating
03-0m(En)-45	overspeed	average	maximum rotational	conditions.
		rotational speed	speed	
			1. Regenerative	
			power is too large.	1. Change the
	amplifier	The amplifier	2. The surrounding	amplifier installation
03-0m(En)-51	thermal	temperature is	air temperature is	conditions.
	abnormality	too high.	too high.	2. Check whether the
			3. Built-in Fan in	cooling fan is running.
			amplifier Stopped.	
			1.Power switch	1.Reduce the power
	Anti surgo	Anti Surgo	frequency is too	switch frequency.
02.0m(En) = 52	Anti-Surge	rosistor	high.	2-1.Check the cooling
05-011(E11)-52	overheat	overbeated	2.Ambient	fan is running.
	overneat	overneateu.	temperature is too	2-2. Change the amplifier
			high.	installation conditions.
	dynamic brake	Dynamic brake	Dynamic brake	Used within the allowable
03-0m(En)-53	resistor	resistor	action frequency is	operating frequency range
	overheat	overheated.	too high.	operating frequency range
			1. Drive	1. Confirm drive cooling
	Drive	Drive	environment is	mode is normal.
03-0m(En)-58	temperature	temperature	overheated.	2. Confirm electrical
	overheat	overheat	2. Motor	control box is in a
			overload.	ventilated condition



Error Code	Error Name	Message	Reason	Solution
			3. Motor speed too	3. Reduce the load weight.
			fast.	4. Reduce arm speed.
03-0m(En)-61	overvoltage	Main circuit DC voltage is excessively high.	 The power supply exceeded the allowable range. The moment of inertia ratio exceeded the allowable value. 	 Measure the power supply voltage Confirm that the moment of inertia ratio is within the allowable range.
03-0m(En)-62	undervoltage	Main circuit DC voltage is excessively low.	 Input supply voltage is below the allowable range. The power supply is unstable, or was influenced by a lightning surge. 	Set AC power supply voltage within the specified range.
03-0m(En)-71	control power source voltage shortage	The voltage of the control power is too low.	 Input supply voltage is below the allowable range. The power supply is unstable, or was influenced by a lightning surge. 	1. Set AC power supply voltage within the specified range.
03-0m(En)-72	control circuit voltage shortage	The control circuit voltage is insufficient	 Contact fault of connector or incorrect wiring for encoder cable. The amplifier internal circuit is bad. 	 Re-insert the connector and confirm that the encoder is correctly wired. Replace amplifier.
03-0m(En)-81	encoder disconnect	Encoder signal is disconnected.	 Wrong connection. Connector off. Poor connection 	 1.Check the encoder cable. 2. Check the power supply voltage(5VDC) on the motor side.
03-0m(En)-84	encoder communication abnormality	Encoder Communications Error	1. Malfunction caused by noise interference.	 Correct the wiring around the encoder by separating the encoder



Error Code	Error Name	Message	Reason	Solution
			2. Contact fault of	cable from the servomotor
			connector or	main circuit cable or by
			incorrect wiring for	checking the grounding
			encoder cable.	and other wiring.
				2. Check the encoder
				cable.
	an an dan initial		1. Wrong	1.Check the encoder
02.0	encoder Initial	Encoder initial	connection.	cable. 2. Check the power
03-0m(En)-85	error(5v	error	2. Connector off.	supply voltage(5VDC) on
	abhormality)		3. Poor connection.	the motor side.
		E a a da a con	1. Wrong	1.Check the encoder
	encoder CS	Encoder CS	connection.	cable. 2. Check the power
03-0m(En)-87	abnormality	signal	2. Connector off.	supply voltage(5VDC) on
		disconnect.	3. Poor connection.	the motor side.
	an an dan mulat		1. The encoder cable	1. Check the encoder
	encoder multi-	Frankan Daaluur	disconnected,	connector battery or the
03-0m(En)-A1	(battery	Error	and connected again.	connect or contact status.
			2. The battery	2. Measure the battery
	abhormality)		voltage is low.	voltage.
	a va a a al a v		Companyation and in	Motor acceleration
03-0m(En)-A3	encoder	overspeed	Servomotor speed is	exceeds allowable
	overspeed		too nign.	acceleration range.
	oncodor cinglo	Detected	1 Excessive poise to	1. Check noise in the cable
03-0m(En)-A5	turn orror	encoder single	the opendor cable	between the SERVOPACK
	turnerror	turn error	2 The amplifier	and the host controller.
	oncodor multi	Detected	2. The amplifier	2. Re-insert the connector
03-0m(En)-A6	turn orror	encoder single	had	and confirm that the
	tumenoi	turn error	bau.	encoder is correctly wired.
			1. The surrounding	
	ancodor	The amplifier	air temperature is	Change motor installation
03-0m(En)-A9	encouer	temperature is	too high.	mothed
	overneat	too high.	2. Motor is	methou.
			overheated.	
			1. Excessive noise to	1. Check noise in the cable
		An encoder	the encoder cable.	between
03-0m(En)-AB	encoder error	error was	2. The amplifier	2. If the restart cannot be
		detected.	internal circuit is	solved, please replace the
			bad.	motor.



Error Code	Error Name	Message	Reason	Solution
03-0m(En)-C1	speed overlimit	The speed of the motor exceeds 120% of the maximum speed.	Overshoot too big.	 Adjust the servo parameters. Slow command acceleration and deceleration mode.
03-0m(En)-D1	position error too big	Position deviation exceeded the set value	 Load inertia is too large. The brake is not released. The position command frequency is too high. 	 Change the load conditions, or replace a larger capacity motor. Check the encoder cable. Change the controller's position command.
03-0m(En)-E1	EEPROM abnormality	EEPROM abnormality	The driver internal circuit is bad.	
03-0m(En)-E2	EEPROM check is abnormality	EEPROM check is abnormality	The CPU cannot read the correct data from the driver's built-in EEPROM.	Replace the driver.
03-0m(En)-EF	Motor not matching	The amplifier does not match the motor.	Use the wrong driver or motor.	Replace the correct driver or motor.
03-0m(En)-F3	amplifier error	amplifier error	amplifier error	According to the driver brand, compare the driver Error code.
03-0m(En)-F4	software thermal reach limit	Motor reaches temperature limit.	Motor temperature is too high.	Reduce speed or reduce load.
03-0m(En)-F5	motor disconnect	Motor cannot connect.	Motor disconnect.	Check the motor cable.
03-0m(En)-F6	amplifier phase initial error	amplifier phase initial error	Phase initialization failed.	
03-0m(En)-F7	Hall sensor error	Hall sensor error.	Hall sensor error.	 Replace motor or driver. Check the cable.
03-0m(En)-F8	Hall phase error	Hall phase error.	Hall phase check error.	
03-0m(En)-F9	overload warning	* Overload warning. Robot will not stop	The effective torque exceeds the set torque.	Relax the conditions of use.



Error <u>Code</u>	Error Name	Message	Reason	Solution
03-0m(En)-FA	amplifier overheating warning	*Amplifier overheated warning. Robot will not stop.	The temperature around the amplifier is greater than the preset temperature range.	Reduce the ambient temperature.
03-0m(En)-FB	regenerated overload warning	 Regenerative overload warning. Robot will not stop 	Regenerated resistance overload.	Relax the conditions of use.
03-0m(En)-FC	detecting power failure	* Detecting power failure. Robot will not stop.	Detected control power input voltage is insufficient.	 Check if the input power supply has momentary or low voltage status. Maybe the internal circuit of the amplifier is abnormal. If this alarm occurs for a long time, replace an amplifier.
03-0m(En)-FD	main circuit is abnormal	* Main voltage is abnormal. Robot will not stop.	Main power voltage exceeds DC 105V.	 Check input mains voltage is within specifications. (Three- phase : AC200~ 230V+10, -15%, 50/60Hz±3Hz) The inertia of the load may be too large, reducing the load inertia. For regenerative resistors, the wiring may not be correct or the impedance does not match the cause of the problem. Check that the impedance of the wiring or external resistor meets the specifications in this manual.



Error Code	Error Name	Message	Reason	Solution
03-0m(En)-FE	battery	* The battery	Measure the battery	Replace the battery.
	insufficient	voltage is low.	voltage.	
03-0m(En)-FF	hotton constru	The battery	Pottonu is omntu	User should replace with a
	ballery emply	voltage is empty.	Battery is empty	new battery immediately.



8.3.3 DAC - Y Driver Alarm Code(Y-XXX)

Error Code	Error Name	Message	Reason	Solution
Y-020	Parameters and check abnormal.	Servo unit is abnormal	Data of internal parameter of SERVOPACK is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-021	Parameters format abnormal.	Servo unit is abnormal	Data format of internal parameter of SERVOPACK is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-022	System and calibration abnormal.	Servo unit is abnormal	Data of internal parameter of SERVOPACK is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-030	Main loop detected abnormal.	Servo unit is abnormal	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-040	Parameters setting abnormal.	Servo unit is abnormal.	Data of internal parameter of SERVOPACK is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-041	Division pulse output setting abnormal.	Parameter setting abnormal.	Parameter setting is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-042	Parameters combinatio n abnormal.	Parameter setting abnormal.	Parameter setting is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.



Error Code	Error Name	Message	Reason	Solution
Y-044	Semi/closed loop/ Full close loop parameters.	Parameter setting abnormal.	Parameter setting is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-050	Combinatio n error.	Servo unit is abnormal.	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-051	Product is not supported.	Servo unit is abnormal.	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-0B0	Servo ON command is invalid.	Servo unit is abnormal.	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-100	Overcurrent detection	Servo unit is abnormal.	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-300	Abnormal regeneratio n	Servo unit is abnormal.	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-320	Regenerativ e overload	Regeneration overload alarm.	Regenerative resistor capacity is insufficient or it is in a continuous regeneration state.	 Please turn off the power and restart. Review the operating conditions. Please contact the engineer from manufacturer.
Y-330	Main circuit power	Servo unit is abnormal.	Servo unit is abnormal.	1. Please turn off the power and restart.



Error Code	Error Name	Message	Reason	Solution
	wiring			2. Please contact the
	error.			engineer from
				manufacturer.
				1. Please turn off the power
		Servo unit is	Servo unit is	and restart.
Y-400	Overvoltage	servo unit is	abnormal	2. Please contact the
				engineer from
				manufacturer.
				1. Please turn off the power
	Insufficient	Sorvo unit is	Sonvo unit is	and restart.
Y-410	voltago	servo unit is	abnormal	2. Please contact the
	voltage			engineer from
				manufacturer.
	Main circuit			1. Please turn off the power
	canacitor	Servo unit is abnormal.	Servo unit is abnormal.	and restart.
Y-450	overvoltage			2. Please contact the
				engineer from
				manufacturer.
				1. Adjust the operating
				conditions.
		Motor speed is	Command input value	2. Please turn off the power
Y-510	Overspeed	above maximum	is too high or the servo unit is abnormal.	and restart.
		speed.		3. Please contact the
				engineer from
				manufacturer.
	Division			1. Please turn off the power
	pulse	Servo unit is	Servo unit is	and restart.
Y-511	output	abnormal.	abnormal	2. Please contact the
	overspeed.			engineer from
				manufacturer.
				1. Adjust the operating
		Abnormal		conditions.
Y-520	Vibration	vibration of	Command input value	2. Please turn off the power
	alarm	motor speed is	is too high or the servo	and restart.
		detected.	unit is abnormal.	3. Please contact the
				engineer from
				manufacturer.



Error Code	Error Name	Message	Reason	Solution
Y-521	Advanced auto-tune alert.	The vibration was detected in the adjustment- free function.	When the adjustment function is executed, the motor vibrates greatly.	 Adjust the operating conditions. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-710 (moment) Y-720 (continuous)	Overload	Exceeded the maximum payload.	The motor runs beyond the overload protection feature.	 Adjust the operating conditions. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-730 Y-731	DB overload.	The power consumption of the detected DB is too large.	The motor is driven by an external force or the servo unit is abnormal.	 Do not drive the motor by external force. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-740	The surge current limit resistor is overloaded.	Main circuit is energized too high.	Servo unit is abnormal.	 Adjust the operating conditions. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-7A0	Heat sink is overheated.	The heat sink temperature exceeds 100 °C.	The ambient temperature is too high or the servo unit is abnormal.	 Adjust the operating conditions. Please turn off the power and restart. Please contact the engineer from manufacturer.



Error Code	Error Name	Message	Reason	Solution
Y-7AB	Built-in fan stopped.	The internal fan of the SERVOPACK stopped.	There is a foreign object entering, or the servo unit is abnormal.	 Remove foreign objects. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-810	Encoder backup alert.	The encoder data is abnormal.	The power is turned on for the first time, or the servo unit is abnormal.	 Make the settings of the encoder. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-820	Encoder and number alarm.	Encoder and number verification errors.	Servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-830	Encoder battery alarm.	The battery voltage of the absolute encoder is lower than the specified value.	The battery voltage is insufficient or the servo unit is abnormal.	 Replace the battery. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-840	Encoder data alert.	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-850	Encoder overspeed.	When the control power is turned on, the encoder overspeed is detected.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-860	The encoder is overheated.	The encoder exceeds the upper	The ambient temperature is too high or the servo unit is abnormal.	 Adjust the ambient temperature to below 40 °C.



Error Code	Error Name	Message	Reason	Solution
		temperature		2. Please turn off the power
		limit.		and restart.
				3. Please contact the
				engineer from
				manufacturer.
		When the servo		1. Please turn off the power
	The speed	is turned ON,		and restart.
V D10	command	the speed	The servo unit is	2. Please contact the
I-BIO	A/D is	command input	abnormal.	engineer from
	abnormal.	is incorrectly		manufacturer.
		operated.		
	The speed			1. Please turn off the power
	command	The speed		and restart.
V D11	A/D	command input	The servo unit is	2. Please contact the
Y-B11	conversion	is incorrectly	abnormal.	engineer from
	data is	operated.		manufacturer.
	abnormal.			
		When the servo		1. Please turn off the power
	The torque	is turned ON,		and restart.
	command	the torque	The servo unit is	2. Please contact the
1-020	A/D is	command input	abnormal.	engineer from
	abnormal.	is incorrectly		manufacturer.
		operated.		
				1. Please turn off the power
	Current	U phase current	The serve unit is	and restart.
Y-B31	detection	detection loop is	abnormal	2. Please contact the
	error 1	abnormal.		engineer from
				manufacturer.
				1. Please turn off the power
	Current	V phase current	The servo unit is	and restart.
Y-B32	detection	detection loop is	abnormal	2. Please contact the
	error 2	abnormal.		engineer from
				manufacturer.



Error Code	Error Name	Message	Reason	Solution
Y-B33	Current detection error 3	The current detection loop is abnormal.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-BFO Y-BF1 Y-BF2 Y-BF3 Y-BF4	System alarm 0~4	The servo unit is abnormal.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-C10	Detected out of control.	When the servo is turned ON, the detected motor is out of control.	The motor wiring is incorrect or the servo unit is abnormal.	 Confirm that there is no problem with the motor wiring. Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-C80	The clearing of encoder is abnormal.	The upper limit of the number of revolutions setting is abnormally.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-C90	The encoder communica tion is abnormal.	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-C91	The encoder communica tion position data acceleration is abnormal.	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.



Error Code	Error Name	Message	Reason	Solution
Y-C92	The encoder communica tion timer is abnormal.	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-CA0	The encoder parameters are abnormal.	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-CB0	Encoder calibration returned abnormal.	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-CC0	The upper limit of the number of revolutions is inconsistent	The encoder is malfunctioning.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-D00	The position deviation is too large.	In the state of servo ON, the position deviation exceeds the upper limit.	The position command is too fast, or the servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-D01	The position deviation is too large when the servo is turned ON.	When the servo is OFF and the position deviation is too large, the servo is directly turned ON.	The servo unit is abnormal.	 Please turn off the power and restart. Please contact the engineer from manufacturer.
Y-D02	The positional deviation caused by	In the accumulated position deviation state,	The servo unit is abnormal.	1. Please turn off the power and restart.



Error Code	Error Name	Message	Reason	Solution
	the speed	the servo is ON,		2. Please contact the
	limit at	and the position		engineer from
	servo ON is	command is		manufacturer.
	too large.	input in this		
		state, and the		
		position		
		deviation		
		excessive alarm		
		value is		
		exceeded.		
		When the main		1. Confirm that there is no
		circuit power is		problem with the power
Y-F10 The power of phase.	ON, the low	The three-phase	wiring.	
	cable is out	voltage state of	power supply wiring is	2. Please turn off the power
	cable is out	one of the R, S,	defective, or the servo	and restart.
	of priase.	and T phases	unit is abnormal.	3. Please contact the
		lasts for more		engineer from
		than 1 second.		manufacturer.



8.3.4 DAC – S Driver Alarm Code(S-XXXX)

Error Code	Error Name	Message	Reason	Solution
	Power	Power supply	Main circuit AC	Check if the power supply
S-3110	supply	overvoltage	voltage is out of	voltage is within the specified
	overvoltage		range.	range or install an external
				regenerative resistor.
	Main power	Main power phase	One of the phases	Check wiring or replace the
	phase error	error	is disconnected	drive.
S-3130			from three-phase	
			main power	
			supply.	
	Overvoltage	Overvoltage	Mains DC	Replace the drive.
			overvoltage.	Reduce the power supply
S-3211				voltage to the specified
				range.
				Reduce the load rate.
	Regenerativ	Regenerative	Regenerative	Confirm that the operating
S-3212	e resistor	resistor overload.	resistance load is	conditions are correct.
	overload.		too large.	
S-3220	Main circuit	Main circuit low	Main circuit DC	Check if the power supply
	low voltage.	voltage.	low voltage.	voltage is within the specified
				range.
				Replace the drive.
	Drive	Drive temperature	Ambient	Confirm that the drive
S-4110	temperatur	is abnormal.	temperature is	ambient temperature does
• • • • • • • • • • • • • • • • • • • •	e error.		too high or the	not exceed 55°C.
			drive is damaged.	Replace the drive.
	Anti-surge	Anti-surge resistor	Drive failure or	Replace the drive.
S-4210	resistor	overheating.	ambient	Confirm that the ambient
	overheating		temperature is	temperature does not exceed
			too high.	55°C.
S-5113	Control	Control power	Undervoltage ±5V	Replace the drive or
	power	supply low voltage	control switching	Confirm external circuit.
	supply low	2.	power supply.	
	voltage 2.			
	Control	Control power	Control power	Replace the drive
S-5114	power	supply low voltage.	supply voltage is	Check if the power supply
	supply low		too low.	voltage is within the specified
	voltage.			range.



Error Code	Error Name	Message	Reason	Solution
	Control	Control power	Undervoltage	Replace the drive or
C F11F	power	supply low voltage	±12V control	Confirm external circuit.
5-5115	supply low	1.	switching power	
	voltage 1.		supply.	
	Abnormal	Abnormal current.	Drive damage or	Replace the motor or drive.
S-5210	current		motor damage.	
	detection.			
\$ 5220	System	System error.	Setting mismatch.	Replace the drive.
5-5220	error.			
	Main power	Abnormal power	Abnormal power	Confirm wiring, replace servo
	supply	supply.	supply, over-	motor or drive.
5-5400	equipment		current or	Confirm that the
3-3400	error.		overheating of	environment does not
			the servo	exceed 55°C.
			module.	
	Memory	Memory error.	CPU access error	Replace the drive.
S-5510	error.		of CPU built-in	
			memory.	
	EEPROM	EEPROM error	Drive built-in	Replace the drive.
S-5530	error		EEPROM	
			abnormal.	
	Initialization	Initialization thread	The initialization	Replace the drive.
	thread	timeout.	thread was not	Confirm that the drive is
S-6010	timeout.		completed within	properly grounded.
			the initialization	
			time.	
	EEPROM	EEPROM	CPU access error	Replace the drive.
S-6310	calibration	calibration code	of CPU built-in	
	code error.	error.	EEPROM.	
	System	System parameter	System	Replace the drive.
S-6320	parameter	error.	parameter	
	error.		abnormal.	
	Motor	Abnormal motor	Motor damage,	Replace the servo motor.
	temperatur	temperature.	high ambient	Confirm that the ambient
S-7120	e error.		temperature,	temperature does not exceed
			short circuit.	55°C.
				Confirmation cable.



Error Code	Error Name	Message	Reason	Solution
	Speed	Speed feedback	Motor power	Confirm wiring.
S-7122	feedback	error.	cable	Replace the drive or motor.
	error.		disconnection.	
	Encoder	Encoder	Cable break.	Confirm wiring.
\$ 7200	initialization	initialization failed.		Check if the encoder power
5-7500	failed.			supply is higher than 4.75V
				Replace the motor or drive.
	Encoder	Encoder connector	Power supply	Confirm wiring.
S 720E	connector 1	1 is broken.	cable	Check if the encoder power
3-7305	is broken.		disconnection.	supply is higher than 4.75V or
				replace the motor
\$ 7510	Communica	Communication	Abnormal	Check if the communication
3-7310	tion error.	error.	communication.	format is correct.
	Link lost.	Communication	Communication	Confirm that the
S-7520		disconnects.	cable is damaged	communication cable is
			or not connected.	connected or normal.
C 0211	Overload	Overload	Motor load is too	Reduce load or slow down.
3-0311			large.	
	STO safe	STO safe torque off	STO input is	Confirm stop.
S-8312	torque off	abnormal.	abnormal.	
	abnormal.			
	Average	Average	Motor speed	Reduce operating speed.
5 9400	continuous	continuous speed	overspeed.	
3-8400	speed	overspeed.		
	overspeed.			
	Position	Position command	Position	Reduce the amount of input
S-8500	command	error.	command is out	movement command.
	error.		of setting range.	
	Position	Position deviation	Position deviation	Confirm wiring.
S 9611	deviation is	is too large.	exceeds the set	Confirm the power supply
3-0011	too large.		value.	voltage.
				Replace the drive or motor.
\$ 9700	Task thread	Task thread error.	CPU interrupt	Replace the drive.
S-8700	error.		error.	



8.4 Electric gripper(04-XX-XX)

8.4.1 Hardware Error(04-01-1X)

Error Code	Error Name	Message	Reason	Solution
	Electric	Electric gripper	Electric gripper	Check that the 24V power
	gripper data	data return error.	connection failed,	supply is properly
	return error.		and no data was	connected.
			returned.	Check that the USB cable is
04-01-11				properly connected,
				Check that the serial port is
				set correctly.
				Refer to the manual to install
				the gripper driver.
	Number of	Number of gripper	Exceeded the	Modify the connection port
	gripper serial	serial port exceeds	connection port	setting is less than or equal
04-01-12	port exceeds	the upper limit.	name limit.	to COM99.
	the upper			
	limit.			
	Gripper	Gripper hardware	Connection port	Re-plug the USB cable and
04-01-13	hardware is	is not connected.	is disconnected.	reconnect it.
04 01 13	not			
	connected.			
	Gripper	Gripper serial port	Gripper serial	Close this serial port and
04-01-14	serial port	are closed.	port is not turned	reconnect.
	are closed.		on.	
	Gripper	Gripper serial port	Unable to achieve	Re-plug the USB cable and
04-01-15	serial port	not available.	serial port.	reconnect it.
	not			Replace the USB cable.
	available.			
	Gripper	Gripper	Connection port	Re-plug the USB cable and
04-01-16	reconnection	reconnection	is interrupt and	reconnect it.
_	failed.	failed.	an attempt to	Replace the USB cable.
			reconnect failed.	
	Gripper	Gripper serial port	When a duplicate	Check if the gripper is
	serial port is	is repeatedly	connection port	repeatedly connected.
04-01-17	repeatedly	connected.	is detected, the	
	connected.		connection is	
			automatically	
			disconnected.	



8.4.2 Operation Error(04-01-2X > 04-01-8X)

Error Code	Error Name	Message	Reason	Solution
	Gripper	Gripper model	Gripper type	Check that the gripper type
04-01-20	model setting	setting error.	setting is	setting is correct.
	error.		incorrect.	
	Repeat	Repeat gripper	Repeat the	Wait for the gripper Busy to
04-01-21	gripper	command.	instructions in	end, and then issue a new
	command.		succession.	order.
	Repeat	Popost grippor	Repeat the	Wait gripper end "Busy"
04-01-22	gripper	command	instructions in	signal, then give new
	command.	command.	succession.	commend.
	Gripper	Gripper position	Gripper position	Check that the gripper
04-01-22	position	setting error.	setting is greater	movement position input is
04-01-23	setting error.		than the total	correct.
			stroke.	
			Gripper position	
04-01-24			setting is less	
			than zero	
	Gripper	Gripper speed	Gripper moving	Check if the gripper moving
04-01-25	speed setting	setting error.	speed setting is	speed input is correct.
04-01-25	error.		greater than the	
			preset range.	
			Gripper moving	
04-01-26			speed setting is	
04-01-20			less than the	
			preset range.	
	Gripper	Gripper position	Gripper	Check that the gripper
04-01-27	position	direction setting	movement	movement direction input is
04-01-27	direction	error.	direction setting	correct.
	setting error.		is incorrect.	
	The gripping	The gripping	Gripping	Check that the gripping
	displacement	displacement	displacement	displacement input is correct.
04-01-28	setting is	setting is incorrect.	setting is greater	
	incorrect.		than the range of	
			motion.	
			Gripping	
04-01-29			displacement	
			setting is smaller	



Error Code	Error Name	Message	Reason	Solution
			than the range of	
			motion.	
	Gripping	Gripping speed	Gripping speed is	Check that the gripping
04-01-2A	speed setting	setting is incorrect.	greater than the	speed input is correct.
	is incorrect.		preset range.	
			Gripping speed is	
04-01-2B			smaller than the	
			preset range.	
04 01 20	Gripping	Gripping force	Gripping force is	Check that gripping force
04-01-20	force setting	setting is incorrect.	greater than the	input is correct.
	is incorrect.		preset range.	
04 01 20			Gripping force is	
04-01-20			smaller than the	
			preset range.	
	Gripping	Gripper failed to	After the user	This alarm is used to detect if
	failed.	grip.	turns on the grip	the jaws are clamped to the
			detection	object. If you do not need to
			function, the	send this detection alarm,
04 01 25			gripping action is	you can cancel this function
04-01-22			performed and	in the setting interface.
			the electric	
			gripper detects	
			the unwound	
			object.	
	Gripper is set	Gripper is set	Gripper exceeds	Check if the gripper moving
	incorrectly	incorrectly with	the movable	distance and the total
04-01-2F	with respect	respect to the total	range with	gripping displacement are
	to the total	stroke.	respect to the	correct.
	stroke.		total stroke.	
			Gripper is less	
04-01-80			than the movable	
04 01 80			range relative to	
			the total stroke	
	Gripper	Gripper speed	Gripper moving	Check that the gripper
04-01-81	speed setting	setting error.	speed is less than	moving speed input is
04 01-01	error.		the gripping	correct.
			speed.	



	8.4.3	Electric Gripper	Controller Alarm	Signal Error(04-01-3X)
--	-------	-------------------------	-------------------------	------------------------

Error Code	Error Name	Message	Reason	Solution
	Gripper reset	Gripper reset error	Some workpieces	Check that there are no
	error		have not been	foreign objects in the
			removed during	itinerary.
04-01-30			the route.	Modify the finger design.
			Finger design	
			interferes with	
			the stroke	
	Gripper	Gripper position	Obstacles in the	Check and eliminate
04-01-31	position error	error	movement of the	obstacles in the route.
			gripper.	
	Gripper	Gripper overtravel	Gripper	Check that the gripper
04-01-32	overtravel		displacement	displacement input is correct.
			setting is greater	
			than the range of	
			motion.	
04.04.22	Gripper	Gripper return	Gripper didn't	Check that gripper power is
	return home	home position	connect power.	correct.
04-01-33	position error	error	Gripper obstacles	Check and exclude obstacles
			in the itinerary.	in the itinerary.



8.4.4 Electric Gripper Commend Communication Timeout(04-01-4X)

Error Code	Error Name	Message	Reason	Solution
04-01-41	Gripper connection timeout	Gripper connection timeout		
04-01-42	Gripper firmware communicatio n timeout	Gripper firmware communication timeout		
04-01-43	Gripper stop action timeout	Gripper stop action timeout		Check that the 24V power supply is properly connected.
04-01-44	Gripper reset timeout	Gripper reset timeout	command	properly connected,
04-01-45	Gripper movement timeout	Gripper movement timeout.	failed and data returned timeout.	set correctly. Refer to the manual to install
04-01-46	Gripping timeout	Gripping timeout		Replace the controller unit.
04-01-47	Gripper expert mode action timeout	Gripper expert mode action timeout		
04-01-48	Gripper state reading timeout	Gripper state reading timeout		



9. Program Examples

9.1 Register Class

9.1.1 COUNTER Register

Program: **\$C** [1] = 10

Description:

The constant 10 is saved into COUNTER 1. After the program is closed, the number of the variable definition still registered.

Hint:

There are 20 COUNTERs from 1 to 20. The saved number is integer. The storage capacity is 32bit, which is -2147483648(2¹⁶)~ 2147483647(2¹⁶-1)..

9.1.2 TIMER Register

```
Program:

$T[1] = 0

WAIT SEC 0

$T_STOP[1] = FALSE

PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

WAIT SEC 0

$T_STOP[1] = TRUE
```

Description:

Calculate the period when the robot moves from the original position to PO. After the program is closed, the number of the variable definition still registered.

Parameter explanation: Start counting when \$T_STOP[n]=FALSE. And stop when \$T_STOP[n]=TRUE.

Hint:

There are 20 TIMERs, from 1 to 20. \$T[n] represents the TIMER n. Before starting and ending \$T_Stop, "WAIT SEC 0" command which can stop pre-read is necessary. Every TIMER is 32bit, the display range is from -2147483648(2¹⁶)~ 2147483647(2¹⁶-1). (ms).



9.2 Variable Type Class

9.2.1 REAL (Floating Point)

Program:

REAL One

One = 1

Description:

The format is similar to the data type of the decimal data. This variable will disappear after the program is closed.

Hint: The storage capacity is 32bit about $10^{-37} \sim 10^{38}$, effective to 6 digits after the decimal point.

9.2.2 INT (Integer)

Program:

INT Two = 2

Description:

Which is a format of the integer-type data, and will disappear after the program is closed.

Hint: The storage capacity is 32bit, which are -2147483648(2¹⁶)~ 2147483647(2¹⁶-1).

9.2.3 UINT (Unsigned Integer)

Program: UINT Three = 3

Description:

Format is unsigned type integer, and will disappear after the program is closed.

Hint:The storage capacity is 32bit, which are 0~4294967295(2³²-1)。可輸入十進位整數或使用 0x 開頭表示十六進位整數。

9.2.4 BOOL

Program: BOOL K = TRUE

Description:

Which means "Boolean", is a logically variable. Will disappear after the program is closed.

Hint: Used to declare the variable represents TRUE or FALSE.



9.2.5 CHAR (Character)

Program: CHAR COLOR = 'R'

Description:

Which represents the character variable. Will disappear after the program is closed.

Hint: Used to declare the variable represents the specific characters.

9.2.6 E6POS Point (Cartesian Coordinate Point)

Program:

E6POS POINT = {X 0,Y 300,Z 200}

PTP POINT CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

Define POINT in Cartesian coordinate, and move the robot to POINT.

Hint:

If the parameter is not set, its value will not changed(A, B, C in this case). This point doesn't define E6AXIS (A1~A6) values.

9.2.7 E6AXIS Point(Joint Coordinate Point)

Program: E6AXIS POINT = {A1 90} PTP POINT CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] Description: Define POINT in the joint coordinate, and move the robot to POINT.

Hint:

Parameter A2, A3, A4 are not set, and will remain the original value. This point doesn't define E6POS (X, Y, Z, A, B, C) value.

9.2.8 E6POINT (Cartesian Coordinate Point and Joint Coordinate Point)

```
Program:

E6POINT HOME = {Y 200,Z -1000,A 90}

PTP HOME CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

or you change the definition of HOME like this:

E6POINT HOME = {A1 90}

Description:
```



The first definition of HOME is in Cartesian coordinate, and then move the robot to HOME. The second definition is in Joint coordinate.

Hint:

If there is parameter not defined, it will remain the current value.

9.3 Logical Operator Class

9.3.1 Arithmetic Operator

Program:

```
INT a, b, e
REAL c, d, f
a= 3
b= 5
c= 0.6
d= 12.2
e= 10
f= 10.0
a= a*b; a= 3*5= 15
b= b+d; b= 5+12.2= 17.2 \rightarrow round off, b= 17
c= c*d; c= 0.6*12.2= 7.32
d= b+d; d= 17+12.2= 29.2
e= e/2; e= 5
e= 10/4; e= 2(round down)
e= f/4; e= 2(round down)
f= f/4; f= 2.5
```

Hint: If the format is INT and there are decimals after operation, decimals will be removed. After INT and REAL are operated by "+", "-", or "*", the result format will be REAL.

9.3.2	Logical	Operator				
Logic Operator				A AND B	A OR B	
A=TRUE	B=TRUE			TRUE	TRUE	
A=TRUE	B=FALSE			FALSE	TRUE	
A=FALSE	B=TRUE			FALSE	TRUE	
A=FALSE	B=FALSE		FALSE	FALSE		
9.3.3	Relatio	n Operato	or			
Relation	A > B	A >= B	A < B	A <= B	A == B	A != B
Operator						
A = 2,B = 1	TRUE	TRUE	FALSE	FALSE	FALSE	TRUE
A = 1,B = 1	FALSE	TRUE	FALSE	TRUE	TRUE	FALSE
A = 1,B = 2	FALSE	FALSE	TRUE	TRUE	FALSE	TRUE



9.4 Input / Output Class

9.4.1 Digital Input

Program: WAIT FOR \$DI[1] == TRUE Parameter explanation: The Digital Channel 1 inputs TRUE.

9.4.2 Digital Output

Program: \$DO[1] = TRUE Parameter explanation: The Digital Channel 1 outputs TRUE.

9.4.3 Robot Input

Program: WAIT FOR \$RI[1] == TRUE Parameter explanation:

The Channel 1 of Robot signal inputs TRUE.

9.4.4 Robot Output

Program: \$RO[1] = TRUE Parameter explanation: The Channel 1 of Robot signal outputs TRUE.

9.4.5 Valve Input

Program: \$VO [1] = TRUE Parameter explanation: The Channel 1 of Solenoid Valve outputs TRUE.



9.5 Motion Function Class

The way to define the point can be:

1. Establish the point with the software frame.

2. Establish the point of E6POS or E6AXIS.

3. Define the point parameter directly. The coordinates not defined will remain the same, for example, PTP {X 200}.

4. Define the joint angle directly, and the parameter not defined will be the current value, like PTP {A1 90, A3 60}.

9.5.1 PTP (Point-to-point Absolute Motion)

Point Definition 1

Program:

PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

Only require the position of the starting point and the terminal point. There is no limit for the middle process. TCP will be guided with the fastest trace of the robot to the target point. P0 is additionally established for TCP except for the Home status. TCP will move point-to-point from Home to P0.

Parameter explanation:

PTP; name of point-to-point command, the shortest trace for the robot

P0; any point except for Home

CONT; smooth extent

Vel; moving velocity relative to maximum velocity

Acc; moving acceleration relative to maximum acceleration

Point Definition 2

Program:

E6POS POINT = {X 0,Y 300,Z 200}

PTP POINT CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

Move to POINT.

Hint: The same way to establish points with E6AXIS.

Point Definition 3

Program:

PTP {X 100} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]



Description:

The TCP moves to this coordinate (refer to the base coordinate). The parameters not defined will remain the same.

Point Definition 4 Program: PTP {A1 45} CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

The A1 axis of TCP moves to +45° (refer to the base coordinate). For the axis not defined, the angle will not change.

9.5.2 PTP_REL (Point-to-point Relative Motion)

Point Definition 1

Program:

PTP_REL {X 100 } CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

The TCP moves to this coordinate (refer to the base coordinate). The coordinates not defined will remain the same.

Point Definition 2 Program: PTP_REL {A1 45} CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

The A1 axis of TCP moves at +45° relative to the original A1 axis (refer to the base coordinate). For the axis not defined, the angle will not change.



9.5.3 LIN (Linear, Absolute Motion)

Point Definition 1 Program: LIN P0 CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

P0 is additionally established for TCP except for the Home status. TCP will move point-to-point from Home via P0 to P1. The robot will guide TCP to the target point along the linear trace with the defined velocity.

Parameter explanation: LIN; name of point-to-point command, linear trace connecting two points P0; any point except for Home CONT; smooth extent Vel; velocity moving on linear trace Acc; acceleration moving on linear trace

Point Definition 2

Program:

E6POS POINT = {X 0,Y 368,Z 293}

LIN POINT CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description: move to POINT

Hint: Same method to establish points with E6AXIS

Point Definition 3 Program: LIN {X 100} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

The TCP moves to this coordinate (refer to the base coordinate). The coordinates not defined will remain the same.



Point Definition 4 Program: LIN {A1 45} CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

The A1 axis of TCP moves at +45° relative to the original A1 axis (refer to the base coordinate). For the axis not defined, the angle will not change.

9.5.4 LIN_REL (Linear, Relative Motion)

Point Definition 1

Program:

LIN_REL {X 100 } CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

The coordinates of TCP move in relative to this coordinate (refer to the base coordinate). For the direction not defined, the coordinates will not change.

Point Definition 2 Program: LIN_REL {A1 45} CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

The A1 axis of TCP moves at +45° relative to the original A1 axis (refer to the base coordinate). For the axis not defined, the angle will not change.

Program:

LIN_REL {X 100 } CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]



9.5.5 LIN_REL_TOOL (Linear, Relative Motion for Tool coordinate)

Point Definition 1

Program:

LIN_REL_TOOL {X 100 } CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

The TCP of the robot will move along the axis of the command("X" in this case) by increasing the value("100" in this case).

Point Definition 2 Program: LIN_REL_TOOL {A 45} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

In this case, the TCP will rotate +45° along the X axis of the TCP coordinate. And the command "B"("C") means to rotate along "Y"("Z") axis.



9.5.6 CIRC (Arc, Absolute Motion)

Point Definition 1 Program: CIRC P0 P1 CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

P0 and P1 are additionally established for TCP except for the Home status. TCP will move with circular trace from Home via P0 to P1. The robot will guide TCP to the target point along the circular trace with the defined velocity.

Parameter explanation:

CIRC; name of point-to-point command, the starting point arrives the target point via the auxiliary point along the circular trace

P0; any point except for Home as auxiliary point

P1; any point except for Home as target point

CONT; smooth extent

Vel; velocity moving on circular trace

Acc; acceleration moving on circular trace

Hint: P0 and P1 should be established first.

Point Definition 2 Program: E6POS POINT1 = {X 0,Y 300,Z 200} E6POS POINT2= {X 20,Y 320,Z 220} CIRC POINT1 POINT2 CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description: Move to POINT2 via POINT1.

Hint: The points are established the same method as E6AXIS.

Point Definition 3 Program: CIRC {X 0, Y 450} {X -150, Y 300} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0] Description:



TCP based on the starting point as the original coordinate moves to the auxiliary point and then arrives the destination point (refer to the base coordinates).

Point Definition 4

Program:

CIRC {A1 5.0, A2 5.0, A3 5.0, A4 5.0} {A1 10.0, A2 10.0, A3 10.0, A4 10.0} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

TCP based on the starting point as the original coordinate moves to the auxiliary point and then arrives at the destination point (refer to the base coordinates).

9.5.7 CIRC_REL (Arc, Relative Motion)

Point Definition 1

Program:

CIRC_REL {X -150, Y 150} {X -150, Y -150} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

TCP based on the starting point as the original coordinate moves to the auxiliary point and then arrives the destination point (refer to the base coordinates).

Point Definition 2 Program: CIRC_REL {A1 5.0, A2 5.0, A3 5.0, A4 5.0} {A1 10.0, A2 10.0, A3 10.0, A4 10.0} CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Description:

TCP based on the starting point as the original coordinate moves to the auxiliary point and then arrives at the destination point (refer to the base coordinates).



```
9.5.8 SPLINE (Spline Motion)
    Point Definition 1
    Program:
E6POINT P1 ={ X 95, Y 0, Z -500 }
E6POINT P2 ={ X 94.63849632 , Y 3.922008424 , Z -500 }
.....
E6POINT P54 ={ X -8.279795561, Y -44.82876141, Z -500 }
E6POINT P55 ={ X 0 , Y -45 , Z -500 }
E6POINT P56 ={ X 8.279795561 , Y -44.82876141 , Z -500 }
.....
E6POINT P73 ={ X 95 , Y 0 , Z -500 }
SPLINE
SPL P1
SPL P2
.....
SPL P54
SPL P55
SPL P56
....
SPL P73
ENDSPLINE
```

Description:

Start from P1 point and move to P73 point with B-Spline curvilinear motion.

9.5.9 Array Accumulation

```
Program:

PTP P0 CONT=100% Vel=100% Acc=100% TOOL[0] BASE[1]

P0.A1 = P0.A1 + 10

PTP P0

P0.A1 = P0.A1 + 10

PTP P0
```

Description:

The A1 coordinate of P0 accumulates 10 degrees every time, and the other coordinates will not change.
```
HIWIN
C21UE703-2208
```

9.5.10CT_A6 (Axis 6 Continuous Turning)

```
Program:
LIN PO FINE=1 Vel=100mm/s Acc=100% TOOL[0] BASE[0]
CT A6 100
WHILE $C[1] <2
$C[1] = $C[1]+1
LIN P1 FINE=1 Vel=100mm/s Acc=100% TOOL[0] BASE[0]
LIN P2 FINE=1 Vel=100mm/s Acc=100% TOOL[0] BASE[0]
ENDWHILE
[1] = 0
CT_A6 -50
WHILE $C[2] <2
$C[2] = $C[2]+1
LIN P1 FINE=1 Vel=100mm/s Acc=100% TOOL[0] BASE[0]
LIN P2 FINE=1 Vel=100mm/s Acc=100% TOOL[0] BASE[0]
ENDWHILE
$C[2] = 0
CT_A6 0
WAIT SEC 1
LIN PO FINE=1 Vel=100mm/s Acc=100% TOOL[0] BASE[0]
```

Description:

The sixth axis of the robot first reciprocates between P1 and P2 at a speed of 100% in the positive direction, and then reciprocates between P1 and P2 at a speed of 50% in the negative direction, and then ends infinite rotation and returns to the P0 point.



9.5.11 BRAKE

 Program:

 LIN P0 FINE=1 Vel=3000mm/s Acc=100% TOOL[0] BASE[0]

 LIN_REL {Z -200}

 LOOP

 IF \$DI[1] == TRUE THEN

 BRAKE

 EXIT

 ENDIF

 ENDLOOP

 LIN_P1 FINE=1 Vel=3000mm/s Acc=100% TOOL[0] BASE[0]

Description:

The robot moves to PO, it moves 200mm down along Z axis. The sensor of DI[1] is triggered on the way, the robot stops the motion and moves linearly from the stop point to P1.



9.5.12EXT_TCP(Option)

Front work:

At the external tool point, teach a Base coordinate system, and the origin of the Base coordinate system is at the tool processing point.

Teaching starting point is at point P1 and ending point at P2



Description:

After the robot moves to P1, it is processed (polished) along the straight line of the workpiece and moved to P2. During the process, the workpiece remains in contact with the tool. If EXT_TCP is not used, the workpiece and tool will only be in contact at the start and end points





Not using EXT_TCP

9.6 Contol Flow Function Class

9.6.1 IF

■Format 1 of IF

IF condition THEN

•••••

ENDIF

Program: INT n = 1 IF n > 0 THEN PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ENDIF

Description: Because the *condition* is true, TCP will move to P0.

Parameter description: *Condition*; condition Because the condition is true, the statement in IF will be executed.

Format 2 of IF

IF condition THEN

.....

ELSE

.....

ENDIF

Program: INT n = 0 IF n > 0 THEN PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ELSE PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ENDIF

Description:

Because the condition is false, TCP will execute ELSE and move to PO.



■Application for determining IF condition

IF ((TRUE) AND (TRUE)) THEN

ENDIF

.....

Program: INT n, m n = 1 m = 2 IF ((n == 1) AND (m ==2)) THEN PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ENDIF

Description:

Because the condition is true, TCP will move to P0.

IF ((TRUE) OR (FALSE)) THEN

.....

ENDIF

Program: INT n,m n =1 m = 3 IF ((n == 1) OR (m == 2)) THEN PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ENDIF

Description: Because the condition is true, TCP will move to PO.

IF condition THEN

•••••

ENDIF



```
Program:
IF $DI[1] == TRUE THEN
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDIF
```

Description:

If DI[1] is true, the condition will be true. TCP will move to P0.

9.6.2 FOR

FOR start TO last STEP increment

ENDFOR

Program:

```
INT n
FOR n = 0 TO 2 STEP 1
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDFOR
```

Description:

TCP moves to and fro between P0 and P1 three times.

Parameter explanation:

start ; start

last ; condition

increment ; increment

After FOR is executed from the start to the condition, FOR will end.

If the STEP increment is omitted, the increment default is 1.

■FOR application

```
Program:
INT n
FOR n = 0 TO 20 STEP 10
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDFOR
```

Description:



TCP moves to and fro between P0 and P1 three times.

Program:

```
INT n
FOR n = 2 TO 0 STEP 1
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDFOR
```

Description: TCP moves to and fro between P0 and P1 three times.

Program:

INT n FOR n = -1 TO 3 STEP 2 PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ENDFOR

Description: TCP moves to and fro between P0 and P1 three times.



9.6.3 LOOP LOOP ENDLOOP

LOOP

ENDLOOP Program: LOOP PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] ENDLOOP

Description:

TCP repeatedly moves to and fro between P0 and P1.

Parameter explanation: LOOP is an infinite loop.

■LOOP EXIT ENDLOOP

LOOP EXIT ENDLOOP Program: INT n =0 LOOP IF n == 1 THEN EXIT ELSE n = n + 1ENDIF PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] **ENDLOOP** Description: TCP will move to PO. Parameter explanation:



LOOP execute to EXIT and end LOOP.

9.6.4 WHILE WHILE ENDLOOP

WHILE condition ENDWHILE Program: INT n = 2 WHILE n > 0 PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] n = n - 1 ENDWHILE

Description: TCP moves to and fro between P0 and P1 twice.

Parameter explanation:

condition ; condition

When the condition of WHILE is true, repeatedly execute the statement in WHILE until the condition is false and ends.

■Application for determining WHILE condition

```
WHILE ((TRUE) AND (TRUE))
.....
ENDWHILE
Program:
INT n,m
n = 1
m = 2
WHILE ((n == 1) AND (m == 2))
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
n = n + 1
ENDWHILE
Description:
```



TCP moves to and fro between PO and P1 once.

```
WHILE ((TRUE) OR (FALSE))
.....
ENDWHILE
Program:
INT n,m
n = 1
m = 2
WHILE ((n == 1) OR (m == 3))
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDWHILE
```

Description: TCP moves to and fro between P0 and P1 once.

```
9.6.5 REPEAT
REPEAT UNTIL
```

```
REPEAT
```

UNTIL condition

```
Program:

INT n =0

REPEAT

PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

n = n + 1

UNTIL n > 2
```

Description:

TCP will move to P0 and P1 as well as repeatedly execute twice.

Parameter explanation:

Condition; condition

Repeatedly execute the statement in REPEAT until the condition is true, and end REPEAT.

Application for determining REPEAT condition



REPEAT

.....

UNTIL((FALSE) OR (TRUE))

```
Program:

INT n =0

INT k =1

REPEAT

PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

n = n + 1

UNTIL (k ==2) OR (n > 2)
```

Description:

TCP will move to PO and P1 as well as repeatedly execute twice.

REPEAT

..... UNTIL((TRUE) AND (TRUE))

Program: INT n =0 INT k =1 REPEAT PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] n = n + 1 UNTIL(k ==1) AND (n > 2)

Description:

TCP will move to PO and P1 as well as repeatedly execute twice.



9.6.6 GOTO

IF condition THEN GOTO LABEL1 ENDIF IF condition THEN GOTO LABEL 2 ENDIF IF condition THEN GOTO LABEL 3 ENDIF

LABEL 1:

.....

LABEL 2:

.....

LABEL 3:

.....

Program:

INT n =0 LOOP IF n == 0 THEN GOTO STEP0 ENDIF IF n == 1 THEN GOTO STEP1 ENDIF IF n == 2 THEN GOTO STEP2 ENDIF

PRO:

n = n + 1 ENDLOOP

STEPO:

PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] GOTO PRO STEP1: PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]



GOTO PRO STEP2:

> Description: TCP moves from P0 to P1, and then ends LOOP.

Parameter explanation:

LABEL ; label

The label of GOTO corresponds to the following statement of the label. If the label doesn't have the statement, it will end program.



9.6.7 SWITCH

SWITCH without default

SWITCH number

.....

CASE number1

.....

CASE number2

.....

ENDSWITCH

Program: INT n =0 LOOP SWITCH n CASE 0 PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] CASE 1 PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] CASE 2 EXIT ENDSWITCH n = n + 1 ENDLOOP

Description:

TCP moves from P0 to P1, and then executes EXIT to end LOOP.

Parameter explanation:

number ; argument

The argument of SWITCH corresponds to the statement of CASE.

When the argument of SWITCH doesn't correspond to CASE, it will directly correspond to ENDSWITCH.

SWITCH with default

SWITCH number

.....

CASE number1

.....



```
CASE number2
.....
DEFAULT
EXIT
ENDSWITCH
Program:
INT n =0
LOOP
SWITCH n
CASE 0
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
CASE 1
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
DEFAULT
EXIT
ENDSWITCH
n = n + 1
ENDLOOP
```

Description:

TCP moves from P0 to P1, and then executes EXIT to end LOOP.

Parameter explanation:

The argument of SWITCH corresponds to CASE. If there is no correspondence, the statement of DEFAULT will be executed.

When the argument of SWITCH doesn't correspond to CASE, the statement with DEFAULT will jump to the statement of DEFAULT.

SWITCH Extension 1

```
SWITCH number
```

.....

CASE number1, number3, number5

.....

CASE number2, number4

.....

DEFAULT



EXIT ENDSWITCH

Program: INT n =0 LOOP SWITCH n CASE 0,2,4 PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] CASE 1,3 PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] CASE 5 EXIT ENDSWITCH n = n + 1 ENDLOOP

Description:

TCP moves to and fro between P0 and P1, moves to P0, and then executes EXIT to end LOOP.

SWITCH Extension 2

SWITCH character

.....

CASE character1

.....

CASE character2

.....

DEFAULT

EXIT

ENDSWITCH

Program: CHAR COLOR = 'R' LOOP SWITCH COLOR CASE 'R'

```
HIWIN
C21UE703-2208
```

```
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
CASE 'G'
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
DEFAULT
EXIT
ENDSWITCH
IF COLOR =='G' THEN
COLOR ='G' THEN
COLOR ='Y'
ENDIF
IF COLOR =='R' THEN
COLOR ='G'
ENDIF
ENDIF
```

Description:

TCP moves from P0 to P1, and then executes EXIT to end LOOP.



9.6.8 WAIT

■WAIT SEC

Program: WAIT SEC 3 PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description: After the program waits for three second, TCP will move to P0.

■WAIT INPUT

Program: WAIT FOR \$DI[1] == TRUE PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

When the program waits the Digital INPUT Channel 1 is TRUE, TCP will move to PO.

Program: WAIT FOR \$RI[1] == TRUE PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

When the program waits the INPUT Channel 1 for the robot is TRUE, TCP will move to PO.

9.6.9 QUIT

Program:

```
LOOP
IF $DI[1] == TRUE THEN
QUIT
ENDIF
ENDLOOP
```

Description:

The program will be closed when executing "QUIT" command(when DI[1] == TRUE in this case).



9.7 Definition of Structure Class

STRUC LABEL INT PARAMETER1, REAL PARAMETER2 DECL LABEL PART1 ,PART2, , PART1 = { PARAMETER1 10, PARAMETER2 500 } PART2 = { PARAMETER1 20, PARAMETER2 100 }

.....

Program: STRUC CASTING_TYPE INT MASS, REAL VOLUME DECL CASTING_TYPE PART1 ,PART2 PART1 = {MASS 10, VOLUME 500 } PART2 = {MASS 20, VOLUME 100 }

Description:

For the different objects in the specific type, the different parameters can be assigned in the same variable.

Parameter explanation:

STRUC LABEL; define the type nameINT PARAMETER1; define the format of object parameterREAL PARAMETER2; define the format of object parameterPART1; define the objectPART2; define the objectHint:PART1. PARAMETER1 = K, which can obtain the parameter.

342



9.8 Function and Subprogram Class

9.8.1 Definition & Using Method of Function

Function is a program code which allows the user to execute the specific task or specific motion. User may write the frequently repeated program code in the function, and may also decide to write the program code with any length in the function. Usually, one function only performs one task.

The declaration of function tells the compiler with respect to the function name, post back value and parameters.

Definition of Function: DEFFCT return_type function_name (parameter list)

statement body of the function RETURN...

ENDFCT

The declaration of function includes the function header and function body. The description of each part is shown as follows:

return_type: Data type returns from function.

function_name: Function name.

parameter list: Function parameters. User may deliver the parameters into the function. The data type of parameter will refer to the data type and support point type declared in the function field. If the parameter is input, then use "parameter: IN" for indication, use as the input parameter, it will not affect the incoming variable even it is modified in the function. If it is used as the output variable and modified in the function, then use "parameter: OUT". As the output variable, if it is modified in the function, the originally incoming variable will also be changed accordingly. One function may have no function parameters, and up to five (5) parameters as the maximum.

statement body: Function body. If the function has parameter, then the user needs to declare the type of parameter in order to undertake.

Example of program 1:

INT iFUN iFUN = FCT_1(2,3) DEFFCT INT FCT_1(num1:IN,num2:IN) INT num1 INT num2 RETURN num1+num2



ENDFCT

Description:

Declare one function named as FCT_1, income two (2) INT parameters i.e. num1 and num2 respectively, and then post back after adding these two parameters.

Example of program 2:

```
E6POINT RE_E6,OUT_E6
INT iX
OUT_E6 = P1
RE_E6 = FCT_2(P0,OUT_E6)
```

```
DEFFCT E6POINT FCT_2(A:IN,B:OUT)
E6POINT A
E6POINT B
A.X = B.X
B.X = 100
PTP A
RETURN A
ENDFCT
```

 $iX = OUT_E6.X$

Description:

Declare one function named as FCT_2, income one parameter of E6POINT and one output parameter B of E6POINT, the function assigns the X value of B to X of A first, and then configures X of B to 100, and then executes the point to point moving to A, and finally post back A, and B is taken as output returning to the calling procedure.



9.8.2 Definition & Using Method of Subprogram

The difference between the defined subprogram and function are: the subprogram has no post back value and the declaration are different.

Definition of subprogram: DEF subprogram_name (parameter list)

statement body of the subprogram

END

The declaration of function includes the subprogram header and subprogram body. Description of each part is shown as follows:

subprogram_name: Subprogram name.

parameter list: Subprogram parameter and up to five (5) parameters as the maximum. statement body: Subprogram body.

Example of program 1:

INT iNUM iNUM = 4 \$C[4] = 0 PROG_1(3,iNUM) \$C[4] = iNUM

```
DEF PROG_1(num1:IN,num2:OUT)
INT num1
INT num2
num2= num1+num2
END
```

Description:

Declare one subprogram named as PROG_1, income one parameter num1 of INT and one output parameter num2 of INT, and then add these two parameters, and assign to num2 as the output.

Example of program 2:

E6POINT E6_OUT_A,E6_OUT_B E6_OUT_A = P0 E6_OUT_B = P1



PROG_2(E6_OUT_A,E6_OUT_B)

DEF PROG_2(A:OUT,B:OUT) E6POINT A E6POINT B A.X = B.X B.X = 100 PTP A END

Description:

Declare one subprogram named as PROG_2, income two (2) output parameters of E6POINT i.e. A and B respectively, the subprogram assigns X of B to X of A first, and then configures X of B to 100, and then executes the pint to point moving A, takes the modified A and B as the output returning to the calling procedure.



9.9 External Function & Subprogram Class

9.9.1 Definition & Using Method of External Function(EXTFCT)

Declare the external function which indicates that the user writes this function into a separate independent file, and the name of this independent file shall be the same as the function name, and call this function outside this independent file. The external function locates on the first line of program code and must begin with the keyword of DEFFCT, one file can only define one external function. If it desires to call the external function, it will have to declare the external function at the calling program. The declaration of external function must use the keyword of EXTFCT. After declaration, it will be the same as the calling of general function.

Definition of declaration for external function: EXTFCT return_type function_name (parameter list)

Description of each part of external function is shown as follows: return_type: Type of post back value, structure of supporting point position. function_name: Function name.

parameter list: Function parameters. Please be aware that the declaration of function parameter name (located in the procedure desired to call) must be consistent with the definition (located at the procedure being called) and up to five (5) parameters as the maximum, support the type of point position.

Example of program:

The program content of file named as FCT_1: DEFFCT INT FCT_1 (num1:IN,num2:IN) INT num1 INT num2 RETURN num1+num2 ENDFCT Content of external program: EXTFCT INT FCT_1(num1:IN,num2:IN) INT iNum

iNum = 10 iNum = FCT_1(6,8)

Description:

In the program with the file name of FCT_1, declare one function named as FCT_1, income two (2) parameters of INT i.e. num1 and num2 respectively, and then add these two parameters, and post back to the calling procedure, in addition, in another external file program, use EXTFCT to declare the external



function of FCT_1, and then perform the calling by using the function mode directly, please be aware that the calling of external function can be up to eight (8) layers as the deepest, the compiler will report error if exceeded.

9.9.2 Definition & Using Method of External Subprogram(EXT)

Declare the external subprogram which indicates that the user writes this subprogram into a separate independent file, and the name of this independent file shall be the same as the subprogram name, and call this program outside this independent file. The external subprogram locates on the first line of program code and must begin with the keyword of DEF, one file can only define one external function. If it desires to call the external subprogram, it will have to declare the external subprogram at the calling program. The declaration of external subprogram must use the keyword of EXT. After declaration, it will be the same as the calling of general subprogram.

Definition of declaration for external subprogram: EXT subprogram_name (parameter list)

Description of each part of external subprogram is shown as follows:

subprogram_name: Subprogram name.

parameter list: Subprogram parameters. The declaration of subprogram parameter name (located in the procedure desired to call) must be consistent with the definition (located at the procedure being called) and up to five (5) parameters as the maximum, support the type of point position.

Example of program:

The program content of file named as PROG_1: DEF PROG_1 (num1:IN,num2:OUT) INT num1 INT num2 num2 = num1+num2 END

```
Content of external program:
EXT PROG_1( num1:IN,num2:OUT )
INT iNum
```

```
iNum = 7
PROG_1(4,iNum)
```

Description:



In the program with the file name of PROG_1, declare one function named as PROG_1, income one (1) parameter num1 of INT and one output parameter num2 of INT, and then add these two parameters, and assign to num2 as the output returning to the calling procedure, in addition, in another external file program, use EXT to declare the external function of PROG_1, and then perform the calling by using the subprogram mode directly, please be aware that the calling of external subprogram can be up to eight (8) layers as the deepest, the compiler will report error if exceeded.

9.10 RS232 Communication Configuration Class

Program: **INT HANDLE** INT NUM **REAL SERDATA COPEN (SER , HANDLE)** LOOP IF HANDLE > -1 THEN CINQUIRE(HANDLE, NUM) If NUM>0 THEN **CREAD** (HANDLE, SERDATA) ENDIF **CCLEAR** (HANDLE) SERDATA = SERDATA + 1 **CWRITE** (HANDLE, SERDATA) **ENDIF** WAIT SEC 0.3 **ENDLOOP**

> Description: Program writing and reading the number via RS232.

Parameter explanation: SER; RS232 HANDEL; target folder CWRITE (HANDLE, SERDATA) ; write the number of SERDATA into HANDLE CREAD (HANDLE, SERDATA) ; give the number of HANDLE to SERDATA CCLEAR (HANDLE) ; clear the number of HANDLE CINQUIRE(HANDLE,NUM) ; read the received quantity



9.11 NET(Network) Communication Configuration Class

Program: **INT HANDLE INT NUM REAL** ETHDATR **COPEN (ETH**, HANDLE) LOOP IF HANDLE > -1 THEN CINQUIRE(HANDLE,NUM) If NUM>0 THEN CREAD (HANDLE, ETHDATR) ENDIF CCLEAR (HANDLE) ETHDATR = ETHDATR + 1 **CWRITE** (HANDLE, ETHDATR) ENDIF WAIT SEC 0.3 **ENDLOOP**

Description:

Program writing and reading the number via network

Parameter explanation:	
ETH	; Internet
HANDLE	; target folder
CWRITE (HANDLE, ETHDATR)	; write the number of ETHDATR into HANDLE
CREAD (HANDLE, ETHDATR)	; give the number of HANDLE to ETHDATR
CCLEAR (HANDLE)	; clear the number of HANDLE
CINQUIRE(HANDLE,NUM)	; read the received quantity



9.12 Conveyor Configuration Class

9.12.1 CNV_START

Description:

Start conveyor procedures, and connect with the system. The command for other conveyor can be executed after this command, used for the start of the conveyor program.

Format:

```
CNV_START CNV=1
...
CNV_END CNV=1
```

Format description:

CNV is the parameter for the conveyor number, which can be input from 1 to 4.

9.12.2 CNV_END

Description:

End the conveyor and the connection with the system, used for the end of the conveyor program.

Format:

```
CNV_START CNV=1
```

•••

CNV_END CNV=1

Format description:

CNV is the parameter for the conveyor number, which can be input from 1 to 4.



9.12.3CNV_PICK_QUANTITY

Description:

The variables for the conveyor are used to set the maximum quantity of the object that the robot can pick every time. When the quantity reaches this value, the following pick commands will not be executed. This variable will simultaneously affect CNV_FULL and CNV_EMPTY.

Format:

CNV_PICK_QUANTITY = 1

Format description:

The variable type is positive integer. The default is 1, which can be input from 1 to 8.

9.12.4CNV_TRIGGER_TIMES[NUM]

Description:

This is a variable for the conveyor, used when the conveyor is set as a sensor trigger. When the conveyor sensor is triggered, the robot will receive a task to pick or place. This variable can be set to increase the speed of a task after the sensor is triggered several times, require to specify a conveyor number, # as the conveyor number.

Format:

CNV_TRIGGER_TIMES[NUM] = 1

Format description:

This variable type is positive integer from 1 to 100. If no quantity is assigned, the default is 1. NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4.

9.12.5CNV_PICK

Description:

Pick the object. Automatically waits for messages from the system when the command is given that it can pick the object. After a successful pick, the robot will return to the height that the pick started from. If the pick fails, the robot will return to the starting position.

Format:

CNV_PICK CNV=1 OBJ=1 \$DO[1] P1 Down=5.000mm CONT=50% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Format description:

■CNV is the parameter for the conveyor number. When it is necessary to track the object, the CNV number will be set. If the number is obmitted, it will not track. The input range 1 to 4.

■OBJ is the object parameter, used to assign a number to the object. When it is omitted, no number is assigned to the object. All objects will be picked. The input range input is 1 to 8.

■\$DO[] is the parameter for the number O, which represents the Digital Output position to



pick the object. The input range input is 1 to 48.

■P is the position parameter. The number for this position is the coordinate when the object triggers the sensor signal; if the image trigger is employed, it can be omitted.

Down is the height that pressed downwardly to pick the object. During picking, the robot will stop a distance over the object and move downwardly. This parameter is used to assign this distance. The input range is a positive integer.

■FINE and CONT are the paramaters for the discontinuous and continuous motion. The percentage behind the paramter is the smooth extent. For the description of CONT, please see the Appendix at Chapter 4.7.

■Vel is the velocity parameter. The default is 2000mm/s.

■Acc is the acceleration. The default is 100%.

■TOOL is the parameter for the tool coordinates, which can be used to set the position of different end tools, input is from 0 to 15.

BASE is the parameters for base coordinate, which can be used to set the base number that the conveyor is calibrated, input is from 0 to 31.

Command flowchart:



PICK flowchart

Flowchart description:

- ■# is the number.
- CNV, OBJ, P, Vel and Acc can be omitted to input.
- ■Please select either CONT, CONT = #%, CONT = #mm or FINE.



9.12.6 CNV_PLACE

Description:

The objects can be picked and placed or selected according to the object number or O (chosen object); the object will return the safety height after successfully placed. When the place fails, the conveyor will return to the starting position.

Format:

CNV_PLACE CNV=1 OBJ=1 \$DO[1] P1 Down=5.000mm CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Format description:

■CNV is the parameter for the conveyor number. When it is necessary to track the object, the CNV number will be entered. If the number is omitted, it will not track. The input range is from 1 to 4.

■OBJ is the object parameter, which can be used to assign the picked object number. If it is omitted, the object number is not assigned. All objects are placed. The input range is 1 to 8.

■\$DO[] is the parameter for the number O, which represents the position to place the object in this time. If it is omitted, it will represent to place according to the object number.

■P is the position parameter, which represents the position to place the object.

Down is the height that pressed downwardly to pick the object. During picking, the robot will stop a distance over the object and move downwardly. This parameter is used to assign this distance, which should be positive integer or 0.

■FINE and CONT are the paramaters for the discontinuous and continuous motion. The percentage behind the paramter is the smooth extent. For the description of CONT, please see the Appendix at Chapter 4.7.

■Vel is the velocity parameter. The defaut is 2000mm/s.

■Acc is the acceleration parameter. The default is 100%.

■TOOL is the parameter for tool coordinate.

BASE is the parameter for the base coordinate.

Command flowchart:



PLACE flowchart

Flowchart description:

■# is the number.



CNV, OBJ, P, Vel and Acc can be omitted to input.Please select either CONT, CONT = #%, CONT = #mm or FINE.

9.12.7 CNV_OBJECT

Description:

The variable for picking represents the latest object number picked. After the object is placed, the number will be automatically reset, which can be used to determine the current object and perform the specific action. (ATTENTION: CNV_OBJECT can be used only after CNV_PICK)

Format:

CNV_PICK CNV=1 \$DO[1] P1 Down=5.000mm CONT=50% Vel=2000mm/s Acc=50% TOOL[0] BASE[0] IF CNV_OBJECT == 1 THEN CNV_PLACE CNV=1 \$DO[1] P3 Down=5.000mm CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0] ENDIF CNV_PLACE CNV=1 \$DO[1] P2 Down=5.000mm CONT=100% Vel=2000mm/s Acc=50% TOOL[0] BASE[0]

Format description:

The variable type is integer, which can be used for WHILE or IF.

9.12.8CNV_FULL

Description:

The Boolean variable for picking (For the description of Boolean, please see chapter 9.2.4) represents when the quantity of objects that have been picked by the robot reaches the upper limit. When the picking quantity has reached the value set by CNV_PICK_QUANTITY, this variable is TRUE; if the quantity doesn't reach the setting value, it will be FALSE.

Format:

```
CNV_PICK_QUANTITY = 2
WHILE CNV_FULL == FALSE
...
```

ENDWHILE

Format description:

The variable type is Boolean, which can be used for WHILE or IF.

9.12.9 CNV_EMPTY

Description:



The Boolean variable for picking (For the description of Boolean, please see the chapter 9.2.4) represents the quantity of the objects that have been picked by the robot. When no object is picked, this variable is TRUE; if one or more object is picked, this variable is FALSE.

Format:

WHILE CNV_EMPTY == FALSE ... ENDWHILE

Format description:

The variable type is Boolean, and can be used for WHILE or IF.

9.12.10 CNV_SET_DELAY_TIME[NUM]

Description:

This parameter is used to set the delay time for the conveyor. By setting this variable, the robot can continue to move with the object in the specific time and leave after reaching the position to pick or place.

As shown in below, the robot will move with the object in 50ms and leave after picking or placing.

Format:

CNV_SET_DELAY_TIME[NUM] = 50

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4.

The variable type is positive integer. The default is 0, which can be input from 0 to 1500 with a unit of ms.



Illustration of Delta positioning





Illustration of Delta delay 50 ms



9.12.11 CNV_QUEUE_SIZE[NUM]

Description:

This is the pick variable. This variable shows the sensor has been triggered on the conveyor, but there is a quantity of object not picked.

As shown in below, the sensor for the Conveyor 2 has triggered three objects, but the robot has not picked them. Therefore, this variable is 3.

Format:

IF CNV_QUEUE_SIZE[NUM] > 0 THEN

•••

ENDIF

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4.

The variable type is a positive integer, and can be used for WHILE or IF.



Illustration of CNV_QUEUE_SIZE



9.12.12 CNV_OBJ_CNT_DIST[NUM]

Description:

This is the conveyor variable. When the variable CNV_QUEUE_SIZE[NUM] is greater than or equal to 2 (Two or more objects on the conveyor have been triggered.) can be used immediately.

This variable can display the difference between the position of the first object and the second object triggered by the sensor from the difference in Encoder value. It is usually used to determine if the triggered objects are continuous.

Format:

```
IF CNV_QUEUE_SIZE[NUM] > 1 THEN
IF CNV_OBJ_CNT_DIST[NUM] < 2600 THEN
...
ELSE
...
ENDIF
ENDIF
```

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4.

The variable type is positive integer, and can be used for WHILE or IF.

9.12.13 CNV_PLACE_BATCH[NUM]

Description:

The place variable is used when many objects are placed in the same work space.

When the senor that releases an object is triggered, the robot will obtain a position where the object can be placed. The maximum number of times that the robot can place an object in this position can be set by this variable.

Format:

CNV_PLACE_BATCH[NUM] = 1

Format description:

The variable type is a positive integer. If no quantity is assigned, the default is 1. The input range is 1 to 100 and represented by CNV1 to CNV4.


9.12.14 CNV_RESET_ENC

Description:

Conveyor Tracking Instruction. The user can use this instruction to clear the counting value of the external encoder when writing program.

The effect of using this instruction is same as the effect of pressing "CLEAR" on the conveyor calibration interface.

Format:

CNV_RESET_ENC

Format description:

No need to enter parameter.

9.12.15 CNV_QUEUE_REMOVE[NUM]

Description:

Flying pick/flying place state variable. The user is able to remove the temporary value placed at the forefront of the waiting queue by using this instruction during the process of writing the program.

Format:

CNV_QUEUE_REMOVE[NUM]

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4.

9.12.16 CNV_PICK_ACC[NUM]

Description:

Flying pick state variable. The user is able to configure the acceleration time of tracking push-down by using this instruction when writing program.

Format:

CNV_PICK_ACC[NUM]

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4. The default value is 30, range from 10 to 100.

9.12.17 CNV_OFFSET_X[NUM]

Description:



Flying pick/flying place state variable. The user is able to configure the offset value of X by using this instruction when writing program.

Format:

CNV_OFFSET_X[NUM] = 10

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, the offset value of X is configured as 10mm.

9.12.18 CNV_OFFSET_Y[NUM]

Description:

Flying pick/flying place state variable. The user is able to configure the offset value of Y by using this instruction when writing program.

Format:

CNV_OFFSET_Y[NUM] = 10

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, the offset value of Y is configured as 10mm.

9.12.19 CNV_OFFSET_Z[NUM]

Description:

Flying pick/flying place state variable. The user is able to configure the offset value of Z by using this instruction when writing program.

Format:

CNV_OFFSET_Z[NUM] = 10

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, the offset value of Z is configured as 10mm.

9.12.20 CNV_SPEED[NUM]

Description:

Conveyor state variable, user is able to read the current speed of conveyor.

Format:



INT ISpeed ISpeed = CNV_SPEED[NUM]

Format description:

NUM is the number of the conveyor. Input can be from 1 to 4, and represented by CNV1 to CNV4.



9.13 Do Switching on the Path(SYN Out) Class

9.13.1 Program Example 1 of SYN

Program: LIN P1 FINE Vel=100% Acc=50% TOOL[0] BASE[0] SYN \$DO[1] = TRUE START DELAY = 50 ms SYN \$DO[2] = TRUE END DELAY = -50 ms LIN P2 FINE Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

As shown in below, the command for SYN is given when moving from P1 to P2. P1 and P2 are not in the smooth circumstance. The range of START is from the position of the accurate position for P1 to P2. The range for END is from P2 to P1; the command for START Delay in SYN is given to 50ms, which executes the command for DO[1]=True after the time elapses 50ms. The command for END Delay in SYN is given to - 50ms, which backwards 50ms from P2 to execute DO[2]=True.





9.13.2 Program Example 2 of SYN

Program:

LIN P1 FINE Vel=100% Acc=50% TOOL[0] BASE[0]

SYN \$DO[1] = TRUE START DELAY = 50 ms

SYN \$DO[2] = TRUE END DELAY = -50 ms

LIN P2 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

As shown in below, the command for SYN is given when moving from P1 to P2. P2 is in the smooth circumstance. The range of START is from the position of the smooth termination for P1 to the smooth start for P2. The range for END is from the position of the smooth start for P2 to the smooth termination for P2; the command for START Delay in SYN is given to 50ms, which executes the command for DO[1]=True after the time elapses 50ms from the position of the smooth termination for P1. The command for END Delay in SYN is given to -50ms, which executes the command for DO[2]=True after the time elapses 50ms from the position of the smooth range of P2. For the description of CONT, please see the Appendix at Chap. 4.7





9.13.3 Program Example 3 of SYN

Program: LIN P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] SYN \$DO[1] = TRUE START DELAY = 50 ms SYN \$DO[2] = TRUE END DELAY = -50 ms LIN P2 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

As shown in below, the command for SYN is given when moving from P1 to P2. P1 and P2 are in the smooth circumstance. The range of START is from the position of the smooth termination for P1 to the smooth start for P2. The range for END is from the position of the smooth start for P2 to the smooth termination for P2; the command for START Delay in SYN is given to 50ms, which executes the command for DO[1]=True after the time elapses 50ms from the position of the smooth termination for P1. The command for END Delay in SYN is given to -50ms, which executes the command for DO[2]=True after the time elapses 50ms from the position of the smooth termination for P1. The command for END Delay in SYN is given to -50ms, which executes the command for DO[2]=True after the time elapses 50ms forward from the central point of the Bezier curve in the smooth range of P2. For the description of CONT, please see the Appendix at Chap. 4.7.





9.13.4 Program Example 4 of SYN

Program:

LIN P1 FINE Vel=100% Acc=50% TOOL[0] BASE[0] SYN \$DO[1] = FALSE START PATH = 50 mm DELAY = -50 ms LIN P2 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] LIN P3 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] LIN P4 FINE Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

As shown in below, the command for SYN is given when moving from P1 to P2. The path is used, as well as P2 and P3 are in the smooth circumstance. The range of START is from the position of the smooth start for P1 to P4; PATH=50mm and DELAY = -50ms are in SYN, counting 50mm from the start of P1, moving to 50ms and executing DO[1] = False; if P3 is the accurate position, the range of START is from the smooth start of P1 to P3. For the description of CONT, please see the Appendix at Chap 4.7.



Illustration of Example 4



9.13.5 Program Example 5 of SYN

Program:

LIN P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] SYN \$DO[1] = FALSE START PATH = 50 mm DELAY = -50 ms LIN P2 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] LIN P3 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0] LIN P4 FINE Vel=100% Acc=50% TOOL[0] BASE[0]

Description:

As shown in below, the command for SYN is given when moving from P1 to P2. The path is used, as well as P1, P2 and P3 are in the smooth circumstance. The range of START is from the position of the smooth start for P1 to P4; PATH=50mm and DELAY = -50ms are in SYN, counting 50mm from the smooth start of P1, moving to 50ms and executing DO[1] = False; if P3 is the accurate position, the range of START is from the smooth start of P1 to P3. For the description of CONT, please see the Appendix at Chap 4.7.





9.14 Issue Self-defined Alarm Text Command

Description

If the user requires an alarm based on the self-determined condition during the execution of program, it is possible to use this instruction function to issue an alarm while the program is running. When using this instruction to issue the alarm, it has the function as temporary motion stop, the "Start" button will be used to continue executing the operation.

Setting alarm text refer to chapter 3.6.6.

<u>Format</u>

USER_ALARM [n]

Format description

The variable type is a positive integer, from 1 to 10 and cannot be 0.

Position	Point	I/O	Timer	Counter	Alarm	LogBook	Communication	Start Up	Fieldbus	Tracking	• •
Calibratio	n Hom	e Setting	Time Setting	User Alarn	n Setting						
NO.	C	ode				1	Message				
1		10	User Setting Erro	or							
2		11	User Setting Erro	or							
3		12	User Setting Error								
4		13	User Setting Error								
5		14	User Setting Error								
6		15	User Setting Error								
7		16	User Setting Error								
8		17	User Setting Error								
9		18	User Setting Erro	or							
10		19	User Setting Erro	or							

User Alarm Setting interface



10. Functional Program Application Example

10.1 Motion Commands Description

Motion commands:

Commands	Description
РТР	Point to point motion
PTP_REL	Point to point relative motion
LIN	Linear motion
LIN_REL	Linear relative motion
LIN_REL_TOOL	Circular motion
CIRC	Circular relative motion
CIRC_REL	B-Spline curvilinear motion
SPLINESPLENDSPLINE	Point to point motion

PTP&PTP_REL flowchart:



LIN&LIN_REL flowchart:



LIN_REL_TOOL flowchart:



CIRC&CIRC_REL flowchart:





SPLINE instructions:

SPLINE



SPL P1

..... SPL P73 ENDSPLINE

10.2 Register Commands Description

暫存器指令:	
Commands	Description
\$C[#]	Counter register
\$DI[#]	Digital input point register
\$DO[#]	Digital output point register
\$PR[#]	Robot input point register
\$RI[#]	Robot output point register
\$RO[#]	Timer register
\$T[#]	Start timer register
\$T_STOP[#]	Valve output register
\$VO[#]	Counter register

Example:

```
$C[1] = 0
$DO[1] = TRUE
WAIT FOR $DI[1] == TRUE
$RO[1] = TRUE
WAIT FOR $RI[1] == TRUE
$VO[1] = TRUE
$T STOP[1] = TRUE
$T[1] = 0
PR Example 1:
$PR[1] = {A1 1, A2 2, A3 3, A4 4, A5 5, A6 6}
$PR[2] = {X 7, Y 8, Z 9, A 10, B 11, C 12}
$PR[3] = {A1 1 , A2 2 , A3 3 , A4 4 ,A5 5 , A6 6, X 7 ,Y 8 , Z 9 , A 0,B 0, C 0}
PR Example 2:
E6POS A = {X 10, Y 10, Z 10, A 10, B 10, C 10}
E6AXIS B = {A1 20, A2 20, A3 20, A4 50, A5 10, A6 20}
E6POINT C = {X 5 ,Y 15 ,Z 25 ,A 35 ,B 45 ,C 55}}
$PR[1] = A
$PR[2] = B
$PR[3] = C
PR Example 3:
$PR[1] = GETPOINT
```



10.3 Variable Type Commands Description

Variable types:	
Commands	Description
BOOL	Boolean variable type
CHAR	Character variable type
E6AXIS	Angular variable value type
E6POINT	Coordinates or angular variable type
E6POS	Coordinates variable type
FRAME	BASE or TOOL coordinate system
INT	Integer variable type
REAL	Real point variable type

Example:

BOOL K = TRUE CHAR COLOR = 'R' INT I = 0 REAL R = 0

```
FRAME :
FRAME POINT = {A1 90}
```

E6POS/E6AXIS : E6POS POINT = {X 0,Y 300,Z 200} E6AXIS POINT = {A1 90} PTP POINT CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]

E6POINT: E6POINT HOME = {Y 200,Z -1000,A 90}



10.4 Trigonometric Function of Math Calculation Commands Description

Math Calculation:	
Commands	Description
ACOS	Arc cosine(X)
ASIN	Arc sine(X)
ATAN	Arc tangent(X)
ATAN2	Arc tangent(X, Y)
COS	Cosine(X)
SIN	Sine(X)
TAN	Tangent(X)
X,Y is angle degree.	
Example:	
REAL TESTA	
TESTA= <mark>ACOS</mark> (0)	
TESTA= <mark>ASIN(</mark> 0)	
TESTA= <mark>ATAN(</mark> 0)	
TESTA= <mark>ATAN2(</mark> 0,1)	
TESTA= <mark>COS(</mark> 0)	
TESTA= <mark>SIN(</mark> 0)	
TESTA= <mark>TAN</mark> (0)	

10.5 Control Flow Function Commands Description

Control function				
Commands	Description			
FORENDFOR	For loop			
GOTO	Go to label position			
IFENDIF	IF statement			
LOOPENDLOOP	LOOP			
REPEATUNTIL	Repeat loop			
SWITCHENDSWITCH	Switch statement			
WHILEENDWHILE	While loop			
Example:				
FORENDFOR :				
INT n				
FOR n = 0 TO 2 STEP 1				
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]				
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]				



```
ENDFOR
GOTO:
FOUND:
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
GOTO FOUND
IF...ENDIF:
INT n = 1
IF n > 0 THEN
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDIF
LOOP...ENDLOOP:
LOOP
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
ENDLOOP
REPEAT...UNTIL:
INT n = 0
REPEAT
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
n = n + 1
UNTIL n > 2
SWITCH...ENDSWITCH:
INT n = 0
LOOP
SWITCH n
CASE 0
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
CASE 1
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
CASE 2
EXIT
ENDSWITCH
n = n + 1
ENDLOOP
WHILE ... ENDWHILE :
INT n = 2
WHILE n > 0
PTP P0 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
PTP P1 CONT=100% Vel=100% Acc=50% TOOL[0] BASE[0]
```



n = n - 1 ENDWHILE

10.6 Other Function Commands Description

Other Commands:		
Commands	Description	Program Example
ADDTOOL	Add tool	ADDTOOL ee
ADDOBJECT	Add object	ADDTOOL table P:500,200
		C:200,50
SET_TOOL	Set tool coordinate	FRAME T_ONE
	system	T_ONE.X = 100
		SET_TOOL 1
		SET_TOOL T_ONE
SET_BASE	Set base coordinate	FRAME B_ONE
	system	B_ONE.Y = 100
		SET_BASE 1
		SET_BASE B_ONE
SET_OVERRIDE_SPEED	Set override speed ratio	SET_OVERRIDE_SPEED 100
SET_SPEED	Set line speed,	SET_SPEED 2000
	Uint:mm/s	
SET_ROTATION_SPEED	Set rotation speed,	SET_ROTATION_SPEED 100
	Uint:deg/sec	
SET_ACC	Set acceleration	SET_ACC 250
TRUE_PATH	Open or close trajectory	TRUE_PATH = TRUE
	accuracy control	
USER_ALARM	Configure user alarm	USER_ALARM[1]
SYN	Synchronous switch O	LIN P1 FINE Vel=100% Acc=50%
	pint in motion path	TOOL[0] BASE[0]
		SYN \$DO[1] = TRUE START DELAY
		= 50 ms
		SYN \$DO[2] = TRUE END DELAY = -
		50 ms
		LIN P2 FINE Vel=100% Acc=50%
		TOOL[0] BASE[0]
MOVEFLOOR	Move floor position	MOVEFLOOR 100
DEFFCTENDFCT	Define subprogram	PTP P0 CONT=100% Vel=100%
		Acc=50% TOOL[0] BASE[0]
		MY()



		DEFFCT INT MY()
		PTP P1 CONT=100% Vel=100%
		Acc=50% TOOL[0] BASE[0]
		RETURN 100
		ENDFCT
GETPOINT	Get coordinates or	E6POINT E6TEST
	angular value	E6TEST = GETPOINT
AXISON	Axis coordinates on	AXISON
AXISOFF	Axis coordinates off	AXISOFF
GET_MOTION_STATUS	Get motion status	INT Istatus
		Istatus = GET_MOTION_STATUS
WAIT SEC	Wait second	WAIT SEC 10
WAIT FOR \$DI[#]	Wait digital input	WAIT FOR \$DI[1] == TRUE
STRUC	Define structure	STRUC CASTING_TYPE INT MASS,
		REAL VOLUME

10.7 External Axis Commands Description

External Axis Commands :

Commands	Description	Program Example
EX_AX	Turns on or off the connected external	EX_AX[1] = TRUE
	axis	
		EX_AX[1] = FALSE
EX_AX_ASYNC	Sets the external axis as synchronous	EX_AX_ASYNC[1] = TRUE
	axis or asynchronous axis	EX_AX_ASYNC[2] = FALSE
EX_AX_SYNC_COUPLE	Turns on or off the coordinated control	EX_AX_SYNC_COUPLE[1] = TRUE
	function of the external axis	
EX_AX_SET_ACC	Sets the acceleration and deceleration	EX_AX_SET_ACC[1] 250
	time for the external axis	
EX_AX_SET_SPEED	Sets the speed of the specified external	EX_AX_SET_SPEED[1] 1000
	axis	
EX_AX_CT	Executes infinite rotation for the external	EX_AX_CT[1] 100
	axis	
ASYPTP	Performs point to point movement	ASYPTP{E1 60, E2 100} CONT=100%
	control for the asynchronous external	Vel=100% Acc=50%
	axis	



DTD		
	Performs synchronous point to point	E6POINT P1{A1 50, E1 60}
	movement control for the robot and	PTP P1 CONT=100% Vel=100% Acc=50%
	synchronous external axis	TOOL[0]BASE[0]
		PTP{A1 40, E1 50} CONT=100% Vel=100%
		Acc=50% TOOL[0]BASE[0]
		PTP{X 100, E1 50} CONT=100% Vel=100%
		Acc=50% TOOL[0]BASE[0]
LIN	Performs synchronous linear movement	E6POINT P1{A1 50, E1 60}
	control for the robot and synchronous	LIN P1 CONT=100% Vel=2000mm/s
	external axis	Acc=50% TOOL[0]BASE[0]
		LIN{A1 40, E1 50} CONT=100%
		Vel=2000mm/s Acc=50% TOOL[0]BASE[0]
		LIN{X 100, E1 50} CONT=100%
		Vel=2000mm/s Acc=50% TOOL[0]BASE[0]
CIRC	Performs synchronous arc movement	E6POINT P1{A1 50, E1 60}
	control for the robot and synchronous	E6POINT P2{X 100, E1 0}
	external axis	CIRC P1 P2 CONT=100% Vel=2000mm/s
		Acc=50% TOOL[0]BASE[0]
		CIRC{A1 50, E1 60} {X 100, E1 0}CONT=100%
		Vel=2000mm/s Acc=50% TOOL[0]BASE[0]
		CIRC{A1 50, E1 60} {X 100, E1 0}
		CONT=100% Vel=2000mm/s Acc=50%
		TOOL[0]BASE[0]



10.8 Network and RS232 Communication Application Example

RS232 or EtherNet Commands:	
Commands	Description
COPEN	Open RS232 or EtherNet
CCLOSE	Close RS232 or EtherNet
CCLEAR	Delete RS232 or EtherNet data
CREAD	Read received data from RS232 or
	EtherNet
CWRITE	Write RS232 or EtherNet data
CINQUIRE	Inquire RS232 or EtherNet package
	numbers
ETH Example:	
INT HANDLE	
INT NUM	
REAL SERDATA	
COPEN (ETH , HANDLE)	
LOOP	
IF HANDLE > -1 THEN	
CINQUIRE(HANDLE,NUM)	
If NUM>0 THEN	
CREAD (HANDLE, SERDATA)	
ENDIF	
CCLEAR (HANDLE)	
SERDATA = SERDATA + 1	
CWRITE (HANDLE, SERDATA)	
ENDIF	
WAIT SEC 0.3	
ENDLOOP	
CCLOSE (HANDLE)	



RS232 Example: INT HANDLE **INT NUM REAL** SERDATA **COPEN (SER , HANDLE)** LOOP IF HANDLE > -1 THEN CINQUIRE(HANDLE,NUM) If NUM>0 THEN **CREAD** (HANDLE, SERDATA) ENDIF CCLEAR (HANDLE) SERDATA = SERDATA + 1 **CWRITE** (HANDLE, SERDATA) ENDIF WAIT SEC 0.3 **ENDLOOP** CCLOSE (HANDLE)



10.9 Conveyor Tracking Application Example

This chapter explains the programming application example for conveyor tracking; please refer to Chapter 6-Conveyor tracking function application to perform conveyor pick-on-the-fly setting first, and then refer to the conveyor tracking type instructions in Chapter 9.12, and use it with the application sample program in this chapter.

10.9.1 Visual Way A Conveyor Pick/Place Object to B Conveyer Example(A)

Program description:

This is a visual example.

The robot picks the object from the Conveyor 1 to place on te Conveyor 2. The position is visually picked, and place P2 on the Conveyor 2.



Visual trigger way A conveyor pick/place object to B conveyer figure

Program example:

Correspond to line, robot program commands, robot program simple description.

LINE	Robot Program Command:	Robot Program Simple Description:
1	CNV_START CNV=1	;Start pick&place
2	CNV_PICK_QUANTITY = 2	;Set the maximum quantity to pick object,2
3	WHILE CNV_FULL == FALSE	;Go to loop when the quantity on the robot
		doesn't reach the upper limit
4	CNV_PICK CNV=1 OBJ=1 \$DO[1] Down=5.000mm	; Execute pick(object) motion; Setting
	FINE Vel=2000mm/s Acc=50% TOOL[0] BASE[0]	conveyor 1, object number 1, digital output
5	ENDWHILE	signal\$DO[1], down distance 5mm
6	WHILE CNV_EMPTY == FALSE	;Go to loop when the quantity on the robot
		is not empty.
7	CNV_PLACE \$DO[1] P2 FINE Vel=2000mm/s	; Execute place(object) motion; Digital
	Acc=50% TOOL[0] BASE[0]	output signal\$DO[1], place on P2 position
8	ENDWHILE	
9	CNV_END CNV=1	; End pick&place



10.9.2 Sensor Way A Conveyor Pick/Place Object to B Conveyer Example(B)

Program description:

When the position to trigger a sensor is within the picking range, P can be directly set as the pick and place position.

The robot picks and places the object from the Conveyor 1 to the Conveyor 2. When the object is triggered by the sensor, the robot will move to P0 and pick, and then move to P1 and finally place P2. Program:



Sensor trigger way A conveyor pick/place object to B conveyer example figure

■Program example:

Correspond to line, robot program commands, robot program simple description.

LINE	Robot Program Command:	Robot Program Simple Description:
1	CNV_START CNV=1	;Start pick&place
2	CNV_PICK_QUANTITY = 2	;Set the maximum quantity to pick object,2
3	WHILE CNV_FULL == FALSE	;Go to loop when the quantity on the robot
		doesn't reach the upper limit
4	CNV_PICK CNV=1 \$DO[1] P0 Down=5.000mm	Execute pick(object) motion; Setting
	FINE Vel=2000mm/s Acc=50% TOOL[0] BASE[0]	conveyor 1, object number 1, digital output
		signal\$DO[1], pick on P0 position, down
5	ENDWHILE	distance 5mm.
6	PTP P1 CONT Vel=100% Acc=50% TOOL[0] BASE[0]	; Move to P1 position
7	WHILE CNV_EMPTY == FALSE	; go to loop when the quantity on the robot
		is not empty.
8	CNV_PLACE CNV=2 \$DO[1] P2 FINE	; Execute place(object) motion; Setting
	Vel=2000mm/s Acc=50% TOOL[0] BASE[0]	conveyor 2, Digital output signal\$DO[1],
9	ENDWHILE	place on P2 position
10	CNV_END CNV=1	; End pick&place



10.9.3 Sensor Way A Conveyor Pick/Place Objects to B Conveyer Example(C)

Program description:

This example will release two objects after they are simultaneously picked.

When the position to trigger a sensor is beyond the picking range, the command E6POINT can be used to set the pick and place position.

(Before using the command E6POINT, please ensure the ToolBase coordinates have been parallel with those for the conveyor. So, you just need to adjust X coordinate or Y coordinate following P is adjusted).

The robot picks from the Conveyor 1 to the Conveyor 2, waits for the object to move to PICKPOINT, and then place to PLACEPOINT after moving to P1.



Sensor trigger way A conveyor pick/place two objects to B conveyer example figure (self-define point name)



■Program example:

Correspond to line, robot program commands, robot program simple description.

LINE	Robot Program Command:	Robot Program Simple Description:
1	CNV_START CNV=1	;Start pick&place
2	CNV_PICK_QUANTITY = 2	;Set the maximum quantity to pick object,2
3	E6POINT PICKPOINT = P0	;Set the pick point of E6POINT, P0
4	PICKPOINT.X = PICKPOINT.X – 200	; If our Tool/Base coordinate is parallel
		with the conveyor coordinate, X for
		PICKPOINT will be needed.
		; the coordinate position minus 200, no
		change for Y coordinate
5	E6POINT PLACEPOINT = P2	; Set the place point of E6POINT ,P2
6	PLACEPOINT.X = PLACEPOINT.X - 50	; If our ToolBase coordinate is parallel with
		the conveyor coordinate, X for PLACEPOINT
		will need to minus 50 and there is no
		change for Y coordinate.
7	WHILE CNV_FULL == FALSE	; go to loop when the quantity on the
		conveyor doesn't reach the upper limit.
8	CNV_PICK CNV=1 \$DO[1] PICKPOINT	; Pick the first object ; Setting conveyor 1,
	Down=0.000mm FINE Vel=2000mm/s Acc=50%	digital output signal\$DO[1], pick on
	TOOL[0] BASE[0]	PICKPOINT position, down distance 0mm.
9	CNV_PICK CNV=1 \$DO[2] PICKPOINT	; Pick the second object; Setting conveyor
	Down=0.000mm FINE Vel=2000mm/s Acc=50%	1, digital output signal\$DO[2], pick on
	TOOL[0] BASE[0]	PICKPOINT position, down distance 0mm.
10	ENDWHILE	
11	PTP P1 CONT Vel=100% Acc=50% TOOL[0] BASE[0]	;Move to P1 position.
12	WHILE CNV_EMPTY == FALSE	; go to loop when the quantity on the
13		conveyor is not empty.
	CNV_PLACE CNV=2 \$DO[1] PLACEPOINT FINE	; Execute place motion. ; Setting conveyor
	Vel=2000mm/s Acc=50% TOOL[0] BASE[0]	2, digital output signal\$DO[1], pick on
		PLACEPOINT position
14	ENDWHILE	
15	CNV_END CNV=1	; End pick&place



10.10 External Axis Application Example

The following is a sample program for using external axis related instructions; after setting the external axis parameters correctly, related instructions can be used to execute functions, including turning on the external axis, switching axis modes, infinite rotation, enabling synchronous coordination, etc.

LINE	Robot Program Command:	Robot Program Simple Description:
1	EX_AX[1] =TRUE	;Trun on external axis 1~3
	EX_AX[2] =TRUE	
	EX_AX[3] =TRUE	
2	EX_AX_ASYNC[2] =TRUE	;Sets the external axis as asynchronous axis
3	LIN P0 FINE=1 Vel=100mm/s Acc=100% TOOL[1]	;Move Robot and external axis to P0
	BASE[1]	(asynchronous)
4	ASYPTP{E2 90} FINE=1 Vel=100% Acc=100% TOOL[1]	; Move Robot and external axis of E2 to 90
	BASE[1]	mm position.(asynchronous)
5	EX_AX_SYNC_COUPLE[1] = TRUE	; Turns on or off the coordinated control
	EX_AX_SYNC_COUPLE[3] = TRUE	function of the external axis of 1&3.
6	EX_AX_CT [2] 100	;Executes infinite rotation for the external
		axis of second external axis.
7	LIN P1 FINE=1 Vel=100mm/s Acc=100% TOOL[1] BASE[1]	;Move Robot and external axis to P0
		(asynchronous)

10.11 Gripper Commands Description

Gripper commands :

Commands	Description	Example
EG_OPEN	Connect with XEG series electric gripper	EG_OPEN(Type)
EG_CLOSE	Disconnect current XEG series electric gripper	EG_CLOSE
	connection	
EG_RESET	Reset XEG series electric gripper	EG_RESET
EG_GET_STATUS	Get XEG series electric gripper status	IF EG_GET_STATUS == 2 THEN
		ENDIF
EG_RUN_MOVE	Move XEG series electric gripper	EG_RUN_MOVE(10,20)
EG_RUN_GRIP	Grip action of XEG series electric gripper	EG_RUN_GRIP(C,5,L,M)
EG_RUN_EXPERT	Grip action and movement of XEG series electric	EG_RUN_EXPERT(C,10,20,5,10,100)
	gripper	



EG_GET_POS	Get XEG series electric gripper position	IF EG_GET_POS > 5.00 THEN
		ENDIF

There is a sample program below. First of all, set the parameter "Wait Idle" to "ON". This sample will be using all commands of XEG (a kind of electric gripper), including "pick", "place", and changing to expert mode to recognize different items by picking status. Users can refer to this sample to develop their own programs.

LINE	Robot Program Command:	Robot Program Simple Description:
1	PTP P1 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	;Initialize: move the robot to the original
		position, connect to the XEG, and reset the
		XEG.
2	EG_OPEN(X32)	;try to connect to the XEG
3	EG_RESET	;reset the XEG
4	\$C [1]=0	
5	WHILE \$C[1] <= 100	;The major part of the program: recognize
		two different objects by pick and place.
6	\$C[1] = \$C[1]+1	
7	IF EG_GET_STATUS <0 THEN	;move XEG to a specific position
8	ENDIF	;TO DO the handling commands if XEG gets
		errors
9	EG_RUN_MOVE(26.5,80)	
10	PTP P6 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
11	PTP P3 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	;execute the picking command
12	IF EG_GET_STATUS <0 THEN	;TO DO the handling commands if XEG gets
		errors
13	ENDIF	
14	EG_RUN_GRIP(C,25,H,M)	
15	IF SelectObject(EG_GET_POS, EG_GET_STATUS) ==2	;recognize the objects by the position and
	THEN	status of XEG
16	PTP P6 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
17	PTP P2 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
18	ENDIF	
19	IF EG_GET_STATUS <0 THEN	;move XEG to a known position
20	ENDIF	;TO DO the handling commands if XEG gets
		errors
21	EG_RUN_MOVE(26.5,80)	
22	PTP P7 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
23	PTP P8 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	

WIN HT C21UE703-2208

~ .		
24	PTP P9 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
25	PTP P4 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
26	IF EG_GET_STATUS <0 THEN	
27	ENDIF	;change to expert mode to move XEG to pick
28	EG_RUN_EXPERT(C,3.5,60,20.5,20,50)	;TO DO the handling commands if XEG gets
	<pre>IF SelectObject(EG_GET_POS, EG_GET_STATUS) ==1</pre>	errors
29	THEN	
30	PTP P9 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
31	PTP P11 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
32	PTP P5 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
33	ENDIF	; move XEG to a known position
34	IF EG_GET_STATUS <0 THEN	;TO DO the handling commands if XEG gets
		errors
35	ENDIF	
36	EG_RUN_MOVE(26.5,80)	
37	PTP P10 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
38	PTP P5 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
39	IF EG_GET_STATUS <0 THEN	;pick
40	ENDIF	;TO DO the handling commands if XEG gets
		errors
41	EG_RUN_GRIP(C,25,H,M)	
42	IF SelectObject(EG_GET_POS, EG_GET_STATUS) ==1	; recognize the objects by the position and
	THEN	status of XEG
43	PTP P10 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
44	PTP P8 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
45	PTP P4 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
46	ENDIF	
47	IF EG_GET_STATUS <0 THEN	; move XEG to a known position
48	ENDIF	;TO DO the handling commands if XEG gets
		errors
49	EG RUN MOVE(26.5,80)	
50	PTP P8 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
51	PTP P7 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
52	PTP P2 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
53	IF EG GET STATUS <0 THEN	; change to expert mode to move XEG to
		pick
54	ENDIF	pick ;TO DO the handling commands if XEG gets
54	ENDIF	pick ;TO DO the handling commands if XEG gets errors
54 55	ENDIF EG RUN EXPERT(C,3.5,60,20.5,20,50)	pick ;TO DO the handling commands if XEG gets errors



	THEN	status of XEG
57	PTP P7 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
58	PTP P6 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
59	PTP P3 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	; move XEG to a known position
60	ENDIF	;TO DO the handling commands if XEG gets
		errors
61	IF EG_GET_STATUS <0 THEN	
62	ENDIF	
63	EG_RUN_MOVE(26.5,80)	
64	PTP P6 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
65	PTP P1 FINE Vel=100% Acc=100% TOOL[0] BASE[0]	
66	ENDWHILE	;disconnect from XEG
67	EG_CLOSE	;Subprogram: the function to recognize
		different objects
68	DEFFCT INT SelectObject(POSITION:IN,STATUS:IN)	
69	REAL POSITION	
70	INT STATUS	
71	IF POSITION>=18.5 AND POSITION<=20.5 AND	
72	STATUS==2 THEN	
73	RETURN 1	
74	ELSE	
75	IF POSITION>=3 AND POSITION<=4 AND STATUS==2	
76	THEN	
77	RETURN 2	
78	ELSE	
79	RETURN 0	
80	ENDIF	
81	ENDIF	
82	ENDFCT	



11. Safety Certification

RS405-LU \sim RS410-LU have CE marking and it fulfill related Directive and ISO standards.

CE Compliance			
	2006/42/EC		
	Safety of machinery — General		
	principles for design — Risk	EN ISO12100:2010	
Machinery Directives(MD)	assessment and risk reduction		
	Robots and robotic devices — Safety		
	requirements for industrial robots —	EN ISO 10218-1:2011	
	Part 1: Robots		
	2014/35/EU		
Low Voltage Directives (IVD)	Safety of Machinery - Electrical		
LOW VOILage Directives (LVD)	equipment of machines - Part 1:	EN 60204-1:2018	
	General requirements		
	2014/30/EU		
Electromagnetic	Generic standards - Immunity for	EN (1000 C 2	
Compatibility Directives	industrial environments	EN 61000-6-2	
(EMC)	Generic standards. Emission		
	standard for industrial environments	EN 81000-8-4	
	2011/65/EU+(EU)/2015/863		
Restriction of Hazardous			
Substances Directive(RoHS)	Cd(100 ppm↓)		
	Pb,Hg,Cr ⁶⁺ ,PBB,PBDE,DEHP,DBP,BBP,DIBP(1000 ppm \downarrow)		

Remote Operating Interface Software (Caterpillar) (Original Instruction) User Manual

Publication Date : August 2022

Copyright © HIWIN Technologies Corp.

^{1.} HIWIN is a registered trademark of HIWIN Technologies Corp.. For your protection, avoid buying counterfeit products from unknown sources.

^{2.} Actual products may differ from specifications and photos provided in this catalog. These differences may be the result of various factors including product improvements.

^{3.} HIWIN website for patented product directory: http://www.hiwin.tw/Products/Products_patents.aspx

^{4.} HIWIN will not sell or export products or processes restricted under the "Foreign Trade Act" or related regulations. Export of restricted products should be approved by proper authorities in accordance with relevant laws and shall not be used to manufacture or develop nuclear, biochemical, missiles or other weapons.





Global Sales and Customer Service Site

HIWIN GmbH OFFENBURG, GERMANY www.hiwin.de www.hiwin.eu info@hiwin.de

HIWIN JAPAN KOBE • TOKYO • NAGOYA • NAGANO • TOHOKU • SHIZUOKA • HOKURIKU • HIROSHIMA • FUKUOKA • KUMAMOTO, JAPAN www.hiwin.co.jp info@hiwin.co.jp

HIWIN USA CHICAGO, U.S.A. www.hiwin.us info@hiwin.com

HIWIN Srl BRUGHERIO, ITALY www.hiwin.it info@hiwin.it HIWIN Schweiz GmbH JONA, SWITZERLAND www.hiwin.ch info@hiwin.ch

HIWIN s.r.o. BRNO, CZECH REPUBLIC www.hiwin.cz info@hiwin.cz

HIWIN FRANCE STRASBOURG, FRANCE www.hiwin.fr info@hiwin.de

HIWIN SINGAPORE SINGAPORE www.hiwin.sg info@hiwin.sg HIWIN KOREA SUWON · CHANGWON, KOREA www.hiwin.kr info@hiwin.kr

HIWIN CHINA SUZHOU, CHINA www.hiwin.cn info@hiwin.cn

Mega-Fabs Motion Systems, Ltd. HAIFA, ISRAEL www.mega-fabs.com info@mega-fabs.com

Copyright © HIWIN Technologies Corp.

©2022 FORM C21UE703-2208 (PRINTED IN TAIWAN)

The specifications in this catalog are subject to change without notification.

HIWIN TECHNOLOGIES CORP. No. 7, Jingke Road, Taichung Precision Machinery Park, Taichung 40852, Taiwan Tel: +886-4-23594510 Fax: +886-4-23594520 www.hiwin.tw business@hiwin.tw (Sales) robotservice@hiwin.tw (Customer Service)